Arebos AR-HE-EA28TTR

Areobos Automatic Preserving Cooker AR-HE-EA28TTR User Manual

Model: AR-HE-EA28TTR | Brand: Arebos

Introduction

This manual provides essential information for the safe and efficient operation of your Areobos Automatic Preserving Cooker, Model AR-HE-EA28TTR. Please read all instructions carefully before first use and retain this manual for future reference. This appliance is designed for preserving food in jars and for heating and keeping warm various beverages.



Image: Front view of the Areobos Automatic Preserving Cooker, showing the main unit, control dials, and integrated tap.

Safety Instructions

- Always ensure the appliance is placed on a stable, heat-resistant surface.
- Do not immerse the appliance in water or other liquids.
- Keep out of reach of children.
- Do not operate if the power cord or plug is damaged.
- Always unplug the appliance from the power outlet when not in use and before cleaning.
- The appliance becomes hot during operation. Use oven mitts or the cool-touch handles when moving or handling.
- Ensure adequate ventilation around the appliance during use.

- Do not use abrasive cleaners or scouring pads, as these can damage the surface.

Product Overview and Components

The Areobos Automatic Preserving Cooker is a versatile appliance designed for both food preservation and beverage heating. It features a robust stainless steel construction with a scratch-resistant finish, a powerful 1800W heating element, and a generous 28-liter capacity.



Image: Diagram illustrating key components of the preserving cooker, including handles, lid, tap, control dials, and indicator lights.

Key Components:

- **Main Unit:** Stainless steel body with scratch-resistant paint.
- **Lid:** Removable lid with heat-insulating handle.
- **Cool-Touch Handles:** For safe transport of the appliance.

- **Integrated Drain Tap:** For serving beverages or emptying the pot.
- **Temperature Control Dial:** Adjustable from 30°C to 110°C.
- **Timer Control Dial:** Adjustable from 20 to 120 minutes.
- **Indicator Lights:** For heating and keep-warm functions.
- **Overheating Protection:** Automatic shut-off feature.
- **Removable Grid Insert:** For placing preserving jars.



Image: The preserving cooker shown with its accessories, including the grid insert, power cable, jar lifter, and funnel.

Setup

1. **Unpacking:** Carefully remove all packaging materials and check for any damage.
2. **Initial Cleaning:** Before first use, clean the interior of the pot and the lid with warm soapy water. Rinse thoroughly and dry. Wipe the exterior with a damp cloth.
3. **Placement:** Place the appliance on a flat, stable, and heat-resistant surface, away from walls or other objects to ensure proper ventilation.
4. **Power Connection:** Ensure the voltage specified on the appliance matches your local power supply. Plug the power cord into a grounded outlet.

Operating Instructions

1. Preserving Food (Canning)

1. **Insert Grid:** Place the removable grid insert at the bottom of the cooker.
2. **Load Jars:** Arrange your filled and sealed preserving jars on the grid. The cooker can accommodate up to 14 x 1-liter jars. Ensure jars do not touch each other or the sides of the pot.

3. **Add Water:** Pour water into the cooker until the jars are covered by approximately two-thirds. Do not fill above the MAX mark.
4. **Secure Lid:** Place the lid on the cooker and ensure it is properly seated.
5. **Set Temperature:** Turn the temperature control dial to the desired preserving temperature (e.g., 100°C for most vegetables).
6. **Set Timer:** Turn the timer control dial to the required preserving time (e.g., 90 minutes). The heating indicator light will illuminate.
7. **Process:** The appliance will automatically heat the water to the set temperature and maintain it for the set duration. Once the time elapses, the appliance will switch off automatically.
8. **Cool Down:** Allow the jars to cool inside the cooker or carefully remove them using a jar lifter.



Image: Preserving jars arranged on the internal grid, with water being added to the cooker.



Image: A jar lifter being used to safely handle a preserving jar, demonstrating safe removal.

2. Heating and Serving Beverages

1. **Fill Pot:** Pour the desired beverage (e.g., glühwein, punch, tea) into the cooker. Do not exceed the MAX fill line.
2. **Set Temperature:** Turn the temperature control dial to the desired serving temperature (e.g., 70-80°C for mulled wine).
3. **Set Timer:** Set the timer to the desired heating duration or to "ON" for continuous heating. The heating indicator light will illuminate.
4. **Serve:** Once the beverage reaches the set temperature, the appliance will maintain it. Use the integrated drain tap to dispense the beverage into cups.



Image: The preserving cooker positioned on a kitchen counter, dispensing a beverage into a glass, highlighting its use as a hot drink dispenser.



Image: A detailed view of the integrated drain tap, showing its design for easy dispensing.

Maintenance and Cleaning

Regular cleaning ensures the longevity and hygienic operation of your appliance.

1. **Disconnect Power:** Always unplug the appliance and allow it to cool completely before cleaning.
2. **Interior Cleaning:**
    - Remove the grid insert.
    - Empty any remaining liquid using the drain tap or by carefully pouring it out.
    - Clean the interior with warm soapy water and a soft sponge or cloth.
    - For stubborn stains, a mild descaling agent suitable for stainless steel can be used, following the product instructions.
    - Rinse thoroughly with clean water and dry completely.
3. **Drain Tap Cleaning:**
    - Regularly clean the tap by flushing it with warm water.
    - If necessary, disassemble the tap according to the manufacturer's instructions (if applicable) for thorough cleaning.
4. **Exterior Cleaning:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or immerse the appliance in water.
5. **Dishwasher Safety:** This appliance is **not** dishwasher safe.



Image: A close-up view of the water outlet at the bottom of the cooker's interior, facilitating easy emptying and cleaning.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not heat up.	Not plugged in; power outage; overheating protection activated.	Check power connection; check circuit breaker; press the reset button on the bottom of the device if it has overheated.
Temperature not reached.	Incorrect temperature setting; too much liquid.	Adjust temperature dial; ensure liquid level is within limits.
Timer not working.	Timer dial not set correctly.	Ensure the timer dial is set to a specific time or "ON" position.
Leakage from tap.	Tap not fully closed; seal damaged.	Ensure tap is firmly closed; inspect tap seal for damage and replace if necessary.

Specifications

Feature	Detail
Brand	Arebos
Model Number	AR-HE-EA28TTR
Power	1800 W
Capacity	28 Liters
Temperature Range	30°C to 110°C

Feature	Detail
Timer Range	20 to 120 minutes
Material	Stainless steel with scratch-resistant paint
Product Dimensions	42.5D x 42.5W x 49H cm
Control Method	Rotary Dials
Dishwasher Safe	No

Warranty and Support

Your Areobos Automatic Preserving Cooker is covered by a manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included with your product or contact the manufacturer directly.

For technical support, spare parts, or service inquiries, please contact Arebos customer service. Contact details can typically be found on the manufacturer's website or in the product packaging.

© 2023 Arebos. All rights reserved. Information in this manual is subject to change without notice.