Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KitchenBoss G560B

KitchenBoss G560B 1L Gooseneck Electric Pour Over Coffee Kettle User Manual

Model: G560B

Important Safety Information

Please read all instructions carefully before using the KitchenBoss G560B Electric Pour Over Coffee Kettle. Retain this manual for future reference.

- Always ensure the kettle is placed on a stable, flat, heat-resistant surface.
- Do not immerse the kettle, power base, cord, or plug in water or other liquids.
- Avoid touching hot surfaces. Use handles and knobs. Steam emitted during boiling can cause burns.
- This appliance is equipped with Dry-boil protection and an Auto Shut-Off function for safety. Do not operate the kettle without water.
- Ensure the lid is securely closed during operation to prevent hot water from splashing.
- Unplug the kettle from the outlet when not in use and before cleaning. Allow it to cool before handling.
- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- Keep the appliance out of reach of children.
- The internal body of the G560B kettle is made of food-grade 304 stainless steel, ensuring zero plastic contact with water.

Product Overview

The KitchenBoss G560B is a 1-liter electric gooseneck kettle designed for precise temperature control and pouring, ideal for pour-over coffee and various hot beverages.



Figure 1: KitchenBoss G560B Electric Pour Over Kettle

Components:

- **Gooseneck Spout:** 8mm diameter for precise, steady water flow.
- **Kettle Body:** 1-liter capacity, 304 food-grade stainless steel interior.
- **Lid:** Securely fits the kettle opening.
- **Handle:** Ergonomically designed and counter-balanced for comfortable pouring.
- **Power Base:** Houses the heating element and control panel.
- **Digital Display:** Shows current and target temperature.
- **Control Knob:** Aluminum alloy dial for temperature adjustment and confirmation.
- **Power Switch:** Located at the back of the power base.



Figure 2: Key Features of the KitchenBoss G560B Kettle

This diagram highlights the precision spout, ergonomic counter-balance handle, 18/8 304 grade stainless steel construction, UK Strix controller, PID temperature control, HD LED display, and premium aluminum die-casting smart dial.

Setup

1. **Unpack:** Carefully remove all packaging materials from the kettle and its base.
2. **Initial Cleaning:** Before first use, fill the kettle with water to the MAX line. Boil the water, then discard it. Repeat this process 2-3 times to ensure cleanliness.
3. **Placement:** Place the power base on a dry, stable, heat-resistant surface. Ensure the power cord is not dangling or in contact with hot surfaces.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet.

Operating Instructions

1. Filling the Kettle

- Remove the lid.
- Fill the kettle with fresh water. Do not fill below the MIN line or above the MAX line indicated inside the kettle. Overfilling may cause boiling water to spill out.
- Replace the lid securely.



Figure 3: Kettle Interior with Fill Lines

2. Powering On/Off

- Ensure the kettle is properly seated on the power base.
- Locate the power switch at the back of the power base. Flip it to the 'ON' position. The digital display will illuminate.
- To power off, flip the switch to the 'OFF' position.

3. Setting Temperature

- The kettle offers variable temperature control from 37°C to 100°C (98°F to 212°F).
- Rotate the silver control knob on the base to adjust the desired temperature. Rotating the knob two 'clicks' will adjust the temperature by ±1°C or ±1°F.
- To switch between Celsius (°C) and Fahrenheit (°F), press and hold the control knob for approximately 3 seconds until the unit

changes.



Figure 4: Temperature Control Dial and Display

4. Heating Water

- Once the desired temperature is set, press the control knob once to start the heating process. The display will show the current water temperature as it rises.
- The kettle features 1350W high power for fast heating, typically reaching boiling point in 4-5 minutes.



Figure 5: Heating Performance Graph

5. Keep Warm Function

- After reaching the target temperature, the kettle will automatically enter a 'Keep Warm' mode, maintaining the set temperature for up to 120 minutes.
- To activate the 'Keep Warm' function from a cold start, press and hold the control knob for 3 seconds after setting the desired temperature. The kettle will heat to and then hold that temperature.

6. Mute Function

- To mute the kettle's beeping sounds, press the silver control knob three times in a row. Repeat the action to unmute.

7. Pouring

- The precisely engineered gooseneck spout allows for a steady and controlled 90-degree vertical pour, ideal for pour-over coffee.
- Hold the kettle by its ergonomic handle for balanced and comfortable pouring.



Figure 6: Kettle in Use for Pour-Over Coffee

Maintenance

1. Cleaning

- Always unplug the kettle and allow it to cool completely before cleaning.
- Wipe the exterior of the kettle and the power base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
- The stainless steel interior can be cleaned with a soft brush or sponge and mild dish soap. Rinse thoroughly.
- Do not immerse the power base in water.

2. Descaling

Mineral deposits (limescale) can build up inside the kettle over time, especially in hard water areas. Regular descaling is recommended to maintain performance.

- Fill the kettle with a mixture of 1 part white vinegar and 2 parts water, or use a commercial descaling solution according to its instructions.
- Bring the mixture to a boil and let it stand for at least 30 minutes, or longer if scaling is heavy.
- Discard the mixture and rinse the kettle thoroughly several times with fresh water.
- Boil fresh water in the kettle and discard it once or twice to remove any residual vinegar taste.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat	No power; Kettle not properly seated on base; Power switch off.	Check power outlet; Ensure kettle is correctly placed on base; Turn power switch to 'ON'.
Temperature display is inaccurate	Minor variations are normal; Sensor issue.	Allow for slight variations (±1°C/°F). If consistently inaccurate, contact customer support.
Kettle beeps loudly	Mute function is off.	Press the control knob three times in a row to activate the mute function.
Lid feels loose or difficult to remove	Design characteristic; Lid not aligned.	Ensure the lid is properly aligned and seated. Exercise caution when removing if hot.
Water has an unusual taste	New appliance residue; Limescale buildup.	Perform initial cleaning steps again. Descale the kettle if necessary.

Specifications

Feature	Detail
Brand	KitchenBoss
Model Number	G560B
Capacity	1 Liter
Power/Wattage	1350 Watts
Voltage	120 Volts
Material	Stainless Steel (Food-grade 304)
Product Dimensions	25.91 x 19.05 x 16 cm (10.2 x 7.5 x 6.3 inches)
Item Weight	1.36 kg (3 lbs)
Temperature Control	37°C to 100°C (98°F to 212°F) with ±1°C/°F precision
Special Features	Electric coffee pour over kettle, Mute function, Keep Warm function, Dry-boil protection, Auto Shut-Off
Certifications	ETL, FCC, UK Strix Controller

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact KitchenBoss directly through their official website or the retailer where the product was purchased.
When contacting support, please have your model number (G560B) and proof of purchase readily available.

© 2023 KitchenBoss. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B2HVXH5Z

More documents and user manuals: **https://manuals.plus/**