Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Naxa NDS-1253

Naxa NDS-1253 Portable Party Speaker User Manual

Model: NDS-1253 | Brand: Naxa

Introduction

Welcome to the user manual for your Naxa NDS-1253 Portable Dual 12-inch Bluetooth Party Speaker. This manual provides essential information for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device. Please read this manual thoroughly before using the product.

Important Safety Instructions

To reduce the risk of electric shock, fire, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before operating the speaker.
- Keep this manual for future reference.
- Do not use this apparatus near water or in excessively humid environments.
- Clean only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Package Contents

Verify that all items listed below are included in your package:

- Speaker
- Remote control
- Aux-in Cable

- Wired Microphone
- UL Power Adapter
- User manual

Product Overview

Familiarize yourself with the NDS-1253 speaker's design and key components.





Figure 1: Front view of the Naxa NDS-1253 Portable Party Speaker, showcasing its dual 12-inch woofers with blue LED lighting and top-mounted controls.





Figure 2: Angled view of the Naxa NDS-1253 speaker, highlighting its robust build and integrated handles for portability.

Control Panel and Ports (Top/Rear)

- **Power Button:** Turns the speaker on or off.
- **Volume Knob:** Adjusts the master volume level.
- **USB Port:** For playing audio files from a USB flash drive.
- **MicroSD Card Slot:** For playing audio files from a MicroSD card.
- **MIC IN 1/2:** 6.35mm inputs for connecting wired microphones.
- **AUX IN:** 3.5mm input for connecting external audio devices.
- **FM Antenna:** For improved FM radio reception.
- **LED Display:** Shows current mode, track number, or FM frequency.
- **Mode Button:** Switches between Bluetooth, USB, MicroSD, FM, and AUX modes.
- **Light Mode Button:** Cycles through various LED light effects.
- **TWS Button:** Initiates True Wireless Stereo pairing.

Setup Guide

Powering On Your Speaker

1. Connect the UL Power Adapter to the DC IN port on the speaker.
2. Plug the power adapter into a standard wall outlet.

3. Press and hold the Power button on the speaker's control panel to turn it on. The LED display will illuminate.

Connecting the Microphone

1. Insert the plug of the wired microphone into either the MIC IN 1 or MIC IN 2 port on the speaker.
2. Adjust the microphone volume using the dedicated microphone volume knob (if available) or the main volume control.

Aux-in Connection

1. Use the provided 3.5mm Aux-in cable to connect an external audio device (e.g., smartphone, MP3 player) to the AUX IN port on the speaker.
2. Press the Mode button on the speaker until "AUX" mode is selected on the LED display.
3. Control playback and volume from your connected device or the speaker's main volume knob.

Operating Your Speaker

Bluetooth Pairing

1. Turn on the NDS-1253 speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing Bluetooth icon or a voice prompt.
2. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
3. Search for "NAXA NDS-1253" in your device's Bluetooth list and select it to connect.
4. Once successfully paired, you will hear a confirmation sound, and the Bluetooth indicator will stop flashing.
5. You can now stream audio wirelessly from your device to the speaker.

True Wireless Stereo (TWS) Pairing

TWS allows you to connect two NDS-1253 speakers for a true stereo sound experience.

1. Ensure both NDS-1253 speakers are powered on and in Bluetooth mode, but not yet connected to any other Bluetooth device.
2. On one of the speakers (this will be the primary speaker), press and hold the TWS button. You will hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. Once connected, you will hear a confirmation sound.
4. Now, connect your Bluetooth device to the primary speaker as described in the "Bluetooth Pairing" section. Audio will play through both speakers in stereo.

USB/MicroSD Playback

1. Insert a USB flash drive or MicroSD card (with supported audio files) into the respective port on the speaker.
2. The speaker will automatically switch to USB or MicroSD mode and begin playing audio. If not, press the Mode button to select the correct source.
3. Use the playback controls (Play/Pause, Next/Previous Track) on the speaker or remote control to manage your music.

FM Radio Operation

1. Press the Mode button until "FM" mode is selected on the LED display.
2. Press and hold the Play/Pause button to initiate an automatic scan for FM stations. The speaker will save all found stations.
3. Use the Next/Previous Track buttons to navigate between saved FM stations.

Microphone Usage

- Ensure the wired microphone is securely connected to a MIC IN port.
- Adjust the microphone volume to your desired level.
- For optimal sound, speak directly into the microphone.

Light Effects

The NDS-1253 features multi-color disco lights to enhance your audio experience.

- Press the Light Mode button on the speaker or remote control to cycle through different light patterns and effects.
- Press and hold the Light Mode button to turn the lights off or on.

Remote Control

The included remote control provides convenient access to various functions:

- Power On/Off
- Mode Selection
- Volume Up/Down
- Play/Pause, Next/Previous Track
- Light Mode Control
- Numeric Keypad for direct track selection (in USB/MicroSD mode) or FM station input.

Care and Maintenance

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry cloth to wipe the exterior of the speaker. Do not use liquid cleaners or aerosol cleaners.
- **Storage:** If the speaker will not be used for an extended period, store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.
- **Handling:** Avoid dropping or subjecting the speaker to strong impacts, as this can damage internal components.

Troubleshooting Guide

Problem	Possible Cause	Solution
Speaker does not power on.	No power connection or low battery.	Ensure the power adapter is securely connected and plugged into a working outlet. Charge the speaker if using battery power.
No sound from speaker.	Volume too low, incorrect mode, or device not connected.	Increase volume. Press Mode button to select correct input (Bluetooth, AUX, USB, MicroSD, FM). Ensure Bluetooth device is paired or AUX cable is connected.
Bluetooth pairing fails.	Speaker not in pairing mode, device too far, or interference.	Ensure speaker is in Bluetooth pairing mode. Move device closer to speaker. Turn off other Bluetooth devices to reduce interference. Try unpairing and re-pairing.
Microphone not working.	Microphone not connected properly or volume too low.	Ensure microphone is fully plugged into MIC IN port. Adjust microphone volume.

Problem	Possible Cause	Solution
USB/MicroSD playback issues.	Unsupported file format or corrupted media.	Ensure audio files are in a supported format (e.g., MP3). Try a different USB drive or MicroSD card.
FM radio static.	Weak signal.	Extend the FM antenna fully. Reposition the speaker for better reception.

Technical Specifications

Feature	Specification
Model Name	NDS-1253
Speaker Type	Subwoofer and tweeter
Woofer Diameter	12 Inches (Dual)
Connectivity Technology	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	33 Feet
Power Source	Battery Powered
Battery Life	Up to 3 Hours
Battery Capacity	4500 mAh
Speaker Maximum Output Power	3000 Watts
Product Dimensions (D x W x H)	11"D x 15.2"W x 39.5"H
Item Weight	37.71 Pounds
Included Components	Speaker, Remote control, Aux-in Cable, Wired Microphone & UL Power Adapter, User manual
Special Features	Hi Res Audio, LED Light, Portable, Stereo Pairing, USB Port
Color	BLACK
Material	Plastic

Warranty Information and Customer Support

This Naxa product comes with a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions, including the duration of coverage and what is covered.

For technical support, troubleshooting assistance, or warranty claims, please contact Naxa Customer Service:

- **Website:** Visit the official Naxa Electronics website for support resources and contact information.

- **Email:** Refer to your warranty card or the Naxa website for the appropriate support email address.
- **Phone:** Refer to your warranty card or the Naxa website for customer service phone numbers.

Please have your model number (NDS-1253) and proof of purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B2L7GJJP

More documents and user manuals: **https://manuals.plus/**