ChooChoo ET20001-E

ChooChoo Narrow End Table with Charging Station and Hidden Drawer

Model: ET20001-E

Introduction Safety Information Package Contents Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the ChooChoo Narrow End Table with Charging Station and Hidden Drawer. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before use and retain them for future reference.



Image: The ChooChoo Narrow End Table in a living room, showcasing its compact design and functionality.

2. Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and personal injury.

- Ensure all parts are securely fastened before use.
- Do not overload the charging station. Refer to the specifications for maximum electrical load.
- Keep liquids away from the charging station to prevent electric shock.
- Place the table on a flat, stable surface.
- Do not allow children to climb on or play with the table.
- Unplug the power cord from the wall outlet before cleaning or moving the table.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer

service.

- All necessary hardware for assembly.
- Numbered wood pieces and parts as per the assembly diagram.

4. Setup and Assembly

Assembly is required for this product. It is recommended that **1 person** perform the assembly. The estimated assembly time is approximately **30 minutes**.

Tools Required:

- Screwdriver (not included, unless specified in package)

Assembly Instructions:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each piece using the numbering provided in the assembly diagram.
3. Follow the step-by-step instructions in the included assembly guide.
4. Use the provided hardware and a screwdriver to securely fasten all connections.
5. Ensure all screws are tightened, but do not overtighten to avoid damaging the wood.
6. Once assembled, gently place the table in its desired location.

Your browser does not support the video tag.

Video: An official ChooChoo Furniture video demonstrating the assembly process and features of the end table with charging station.

5. Operating Instructions

Charging Station:

The end table is equipped with a convenient charging station to power your devices.

- The charging station includes **2 standard AC outlets (120V/12A)** and **2 USB ports (5V/2A)**.
- Plug the table's **6.5 ft power cord** into a wall outlet.
- Connect your devices (e.g., lamps, cell phones, tablets) to the appropriate outlets or USB ports.
- Ensure devices are compatible with the power output specifications.



Image: A close-up view of the integrated charging station on the tabletop, showing a smartphone connected for charging.

Hidden Drawer:

The table features a hidden drawer for discreet storage.

- Gently pull the drawer handle to open.
- Use the drawer to store small items such as remote controls, charging cables, or snacks.
- Push the drawer back in until it is flush with the table frame to close.



Image: The hidden drawer of the end table, shown partially open to illustrate its storage capacity.

Open Storage Shelves:

The two open shelves provide additional storage and display space.

- Utilize the shelves for books, decorative items, or other frequently accessed belongings.
- Ensure items placed on shelves do not exceed the table's weight capacity.

6. Maintenance

To maintain the appearance and longevity of your ChooChoo Narrow End Table, follow these care instructions:

- **Cleaning:** Wipe the surface with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood material.
- **Placement:** Avoid placing the table in direct sunlight or near heat sources, as this can cause fading or warping.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary.

7. Troubleshooting

If you encounter any issues with your end table, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Charging station not working	Power cord not plugged in; wall outlet not active; device not compatible; charging station malfunction.	Ensure power cord is fully plugged into a working wall outlet. Test the wall outlet with another device. Verify your device's charging requirements. If issues persist, contact customer service.
Table is wobbly	Loose fasteners; uneven floor.	Check and tighten all assembly screws. Move the table to a level surface or use furniture pads to stabilize.
Drawer does not slide smoothly	Obstruction in drawer slides; misaligned drawer.	Check for any objects blocking the drawer slides. Ensure the drawer was assembled correctly and is properly aligned on its tracks.

8. Product Specifications

Detailed specifications for the ChooChoo Narrow End Table (Model ET20001-E):

- **Brand:** ChooChoo
- **Model Name:** ET20001-E
- **Color:** Black
- **Material Type:** P2 MDF (Engineered Wood)
- **Product Dimensions (D x W x H):** 11.22" x 23.62" x 24.02" (28.5cm x 60cm x 61cm)
- **Charging Station:** 2 AC Outlets (120V/12A), 2 USB Ports (5V/2A)
- **Power Cord Length:** 6.5 ft
- **Number of Shelves:** 3 (including desktop)
- **Special Features:** Hidden Drawer, Charging Station
- **Indoor/Outdoor Usage:** Indoor
- **Assembly Required:** Yes



Image: A technical diagram illustrating the precise dimensions of the end table, including height, width, and depth.

9. Warranty & Customer Support

ChooChoo is committed to providing high-quality products and customer satisfaction. This product comes with a standard return policy allowing for refund or replacement within **30 days** of purchase.

Customer Service:

If you have any questions, concerns, or require assistance with assembly or product issues, please do not hesitate to contact our customer service team. We are dedicated to resolving any after-sales problems in a timely manner.
For support, please refer to the contact information provided at the point of purchase or visit the official ChooChoo website.

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question