Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anda Seat AD12YDC-XL-01-G-PVF

Anda Seat Kaiser 3 XL Gaming Chair User Manual

Model: AD12YDC-XL-01-G-PVF

Introduction

Welcome to the Anda Seat Kaiser 3 XL Gaming Chair user manual. This guide provides essential information for the assembly, operation, and maintenance of your new gaming chair. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

Safety Information

Always ensure all components are securely fastened before use. Do not stand on the chair. Do not use the chair for purposes other than its intended use. Keep small parts away from children. Maximum weight capacity: **395 lbs (180 kg)**. Recommended maximum height: **6'8" (210 cm)**.

Package Contents

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, please contact Anda Seat customer support.

- Backrest
- Seat Base
- 5-Point Aluminum Base
- Casters (65mm silent and smooth wheels)
- Gas Lift Cylinder
- Gas Lift Cover
- Magnetic Memory Foam Neck Pillow
- Assembly Hardware (screws, tools)

Setup and Assembly

The Anda Seat Kaiser 3 XL is designed for easy assembly. Follow these steps carefully:

1. **Attach Casters to Base:** Insert the 65mm silent and smooth casters firmly into the holes on the 5-point aluminum base until they click into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the 5-point aluminum base. Cover it with the gas lift cover.
3. **Connect Seat Base to Gas Lift:** Carefully place the seat base onto the gas lift cylinder. Apply gentle downward pressure to secure it.
4. **Attach Backrest to Seat Base:** Utilize the MagClap™ Easy Assemble system. Align the backrest with the seat base and slide it into position. Secure with the provided screws. *(Refer to image below for visual guidance on MagClap assembly)*



Figure 1: Attaching the backrest using the MagClap™ system.

5. **Install Magnetic Armrest Tops:** The 4D armrests are designed with magnetic snap-on tops for easy attachment and customization. Simply align the armrest tops with the armrest bases and they will magnetically snap into place. *(Refer to the assembly video below for visual guidance on magnetic armrests)*
6. **Attach Magnetic Neck Pillow:** The magnetic memory foam neck pillow can be easily attached and adjusted by simply placing it on the desired height of the backrest. It contains a cooling pad for enhanced comfort.

Assembly Video

For a detailed visual guide on assembly and key features, please watch the official product video:

Your browser does not support the video tag. This video demonstrates the assembly process and highlights key features of the Anda Seat Kaiser 3 XL Gaming Chair, including the MagClap™ easy assembly, magnetic armrests, and adjustable lumbar support.

Video 1: Anda Seat Kaiser 3 XL Assembly and Features Overview.

Operating Instructions

Your Anda Seat Kaiser 3 XL Gaming Chair offers multiple adjustment options for personalized comfort and ergonomic support.

Height Adjustment

To adjust the chair's height, locate the lever on the right side beneath the seat. Pull the lever upwards while seated to lower the chair, or pull it upwards while standing to raise the chair. Release the lever at your desired height.

Backrest Recline (90° to 160°)

To recline the backrest, pull the recline lever located on the left side of the seat. Lean back to your desired angle (between 90° and 160°) and release the lever to lock it in place. To return to an upright position, pull the lever again and lean forward.



Figure 2: Backrest recline mechanism.

4D Armrest Adjustments

- **Height Adjustment:** Press the button on the side of the armrest and move it up or down. Release the button to lock.
- **Forward/Backward:** Slide the armrest pad forward or backward.
- **Left/Right (Swivel):** Rotate the armrest pad left or right.
- **Inward/Outward:** Slide the armrest pad inward or outward.

Adaptive Lumbar Support

The built-in 4-way adaptive lumbar support system allows you to customize the support for your lower back:

- **Height Adjustment:** Use the knob on the right side of the backrest to move the lumbar support up or down to align with your spine's natural curve.
- **Depth Adjustment:** Use the knob on the left side of the backrest to adjust the protrusion of the lumbar support, increasing or decreasing the pressure against your lower back.



Figure 3: Adaptive lumbar support controls.

Maintenance and Care

Proper care will extend the life and appearance of your Anda Seat Kaiser 3 XL Gaming Chair.

Cleaning

For general cleaning, wipe the chair with a soft, damp cloth. For fabric models (like Grey Fabric), use a mild fabric cleaner if necessary, testing on an inconspicuous area first. For DuraXtra™ Leatherette models, use a non-abrasive cleaner specifically designed for synthetic leather. Avoid harsh chemicals or abrasive materials.

General Care

- Regularly check all screws and bolts to ensure they are tight. Retighten if necessary.
- Keep the chair away from direct sunlight and heat sources to prevent material degradation.
- Avoid placing sharp objects on the chair's surface to prevent punctures or tears.
- Clean the casters periodically to remove dust and debris, ensuring smooth movement.

Troubleshooting

If you encounter any issues with your Anda Seat Kaiser 3 XL Gaming Chair, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully pulled. If the issue persists, the gas lift may need replacement. Contact customer support.
Backrest does not recline or lock	Recline mechanism jammed or lever not fully engaged.	Check for obstructions around the recline mechanism. Ensure the lever is pulled completely.

Problem	Possible Cause	Solution
Armrests are loose or wobbly	Mounting screws are loose or magnetic tops are not fully seated.	Tighten the screws securing the armrests to the chair. Ensure magnetic armrest tops are properly aligned and snapped into place.
Chair makes squeaking noises	Loose connections or friction between parts.	Tighten all visible screws and bolts. Apply a small amount of silicone lubricant to moving parts if necessary.
Casters do not roll smoothly	Debris caught in casters or worn wheels.	Remove any hair or debris from the caster wheels. Clean the wheels regularly.

Specifications

- **Model Name:** Kaiser 3 XL
- **Model Number:** AD12YDC-XL-01-G-PVF
- **Color:** Grey Fabric
- **Product Dimensions (D x W x H):** 22.04" x 21.65" x 53.94" (56 cm x 55 cm x 137 cm)
- **Maximum Weight Recommendation:** 395 lbs (180 kg)
- **Recommended Maximum Height:** 6'8" (210 cm)
- **Back Style:** Solid Back
- **Special Features:** Rolling, Reclining (90°-160°), Adjustable Lumbar Support (4-way), Magnetic 4D Armrests, Magnetic Memory Foam Neck Pillow
- **Frame Material:** Precision Steel Framework
- **Base Material:** Aluminum 5-point Base
- **Casters:** 65mm Silent and Smooth Wheels
- **Fill Material:** Memory Foam
- **Product Care Instructions:** Wipe Clean
- **Item Weight:** 69 pounds (31.3 kg)



Figure 4: Detailed product dimensions.

Warranty and Support

Warranty Information

The Anda Seat Kaiser 3 XL Gaming Chair comes with a**lifetime cover** for the precision steel framework, ensuring long-term durability. All other parts are covered by a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Anda Seat customer support. You can find contact information on the official Anda Seat website or through your retailer.

Visit the official Anda Seat Store for more information:Anda Seat Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question