**ALLIMITY ERF3A69**

# ALLIMITY ERF3A69 Infrared Replacement Remote Control User Manual

For Hisense TV Models

## 1. Introduction

This manual provides instructions for the ALLIMITY ERF3A69 Infrared Replacement Remote Control. This remote is designed to function as a direct replacement for original Hisense TV remote controls, offering seamless operation without the need for complex programming. Please read this manual carefully to ensure proper use and to maximize your viewing experience.

## 2. Product Overview

The ALLIMITY ERF3A69 remote control features a standard layout with dedicated buttons for common functions and popular streaming services. Its ergonomic design ensures comfortable handling.






**Figure 1:** Front view of the ALLIMITY ERF3A69 Infrared Replacement Remote Control, showing power button, streaming service buttons (Netflix, Google Play, YouTube, Sling, Fandango Now, Tikilive), navigation pad, volume, and channel controls.




**Figure 2:** Angled view of the remote control, highlighting its ergonomic shape and button placement.






**Figure 3:** Back view of the remote control, showing the battery compartment with space for two AAA batteries and the model number ERF3A69.

## 3. Setup: Battery Installation

The ALLIMITY ERF3A69 remote control requires two AAA alkaline batteries (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.

4. Slide the battery cover back into place until it clicks securely.

***Note:*** *Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.*

## 4. Operating Instructions

### 4.1. Initial Use

No programming or setup is required for this replacement remote control. Once batteries are installed, it is ready for immediate use with compatible Hisense TV models.

### 4.2. Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Volume Up/Down (VOL +/-):** Adjusts the TV volume.
- **Channel Up/Down (CH ˆ/ˇ):** Changes TV channels.
- **Mute Button ( ):** Mutes or unmutes the TV audio.
- **Navigation Pad (▲◄▼►):** Navigates through menus and options.
- **OK Button (Center of Navigation Pad):** Confirms selections.
- **Back Button (←):** Returns to the previous screen or menu.
- **Home Button (◯):** Accesses the TV's home screen or smart TV interface.
- **Play/Pause Button ( ):** Controls media playback.

### 4.3. Dedicated Streaming Service Buttons

The remote includes dedicated buttons for quick access to popular streaming applications:

- **NETFLIX**
- **Google Play**
- **YouTube**
- **Sling**
- **FANDANGO NOW**
- **TIKILIVE**

### 4.4. Compatible Hisense TV Models

This remote control is compatible with a wide range of Hisense TV models, including but not limited to:

- 55H9020E Plus, 65H9040E Plus, 75EU8070, 55H9100E, 65H9808, 65H9100E Plus, 65Q8809, 65H9070E Plus, 58H6550E, 55H9050E Plus, 65H9100E, 65H9100EPLUS, 65H9020E Plus, 65H9030E Plus, 55Q8809, 55H9100EPLUS, 65H9050E Plus, 75H8080E, 65H9080E Plus, 55H9E1 Plus, 65H9E1 Plus, 65H9000E Plus, 55H9E2 Plus, 65H9E2 Plus, 55H9E3 Plus, 65H9E3 Plus, 55H9000E Plus, 55H9040E Plus, 55H9100E Plus, 55H9E Plus, 65H9E Plus, 55H9030E Plus, 55H9070E Plus, 55H9080E Plus.

## 5. Troubleshooting

### 5.1. Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA alkaline batteries if necessary.

- **Line of Sight:** Make sure there is a clear line of sight between the remote control and the TV's infrared sensor. Obstructions can block the signal.
- **Distance:** Ensure you are within the effective range of the TV's infrared receiver.
- **TV Sensor:** Verify that the TV's infrared sensor is not blocked or dirty.

### 5.2. Specific Buttons Not Working

- **Clean Remote:** Dust or debris under buttons can sometimes cause them to stick or malfunction. Gently clean the remote surface.
- **Battery Check:** Even if some buttons work, low battery power can affect the functionality of others. Replace batteries.

### 5.3. Remote Not Compatible

- Verify that your Hisense TV model is listed in the compatible models section (Section 4.4). While this remote is broadly compatible, some specific models may require a different remote.

## 6. Specifications

| | |
|---|---|
| **Model** | ERF3A69 |
| **Brand** | ALLIMITY |
| **Connectivity Technology** | Infrared |
| **Compatible Devices** | Television (Hisense) |
| **Power Supply** | 2 x AAA Alkaline Batteries (not included) |
| **Product Dimensions** | 5 x 2 x 0.5 inches |
| **Item Weight** | 2 ounces |
| **Special Feature** | No Programming Required |

## 7. Warranty and Support

For information regarding warranty, returns, or technical support, please refer to the seller's policies on the platform where the product was purchased. Keep your purchase receipt as proof of purchase.

© 2023 ALLIMITY. All rights reserved.