Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yomelo FD-EP-230201-1173

Yomelo 9-Speed Digital Hand Mixer User Manual

Model: FD-EP-230201-1173

1. Introduction

Thank you for purchasing the Yomelo 9-Speed Digital Hand Mixer. This powerful and versatile appliance is designed to simplify your baking and cooking tasks, offering precise control and efficient mixing for a variety of ingredients. Please read this manual thoroughly before first use to ensure safe and optimal operation.



Image 1.1: The Yomelo 9-Speed Digital Hand Mixer in Ice Blue, shown with its included beaters, dough hooks, whisk, and snap-on storage case.

2. Product Features

- **Powerful 400W DC Motor:** Provides strong torque for various mixing tasks while operating quietly (below 60 decibels).
- **Precise 9-Speed Control:** Digital display and touch buttons allow for accurate speed selection from 1 to 9, plus a Turbo Boost function for maximum power.
- **Soft Start Technology:** Gradually increases speed to prevent splattering and ensure smooth mixing.
- **Snap-On Storage Case:** Conveniently stores all accessories directly with the mixer, keeping them organized and easily accessible.
- **Ergonomic Design:** Lightweight housing with a soft-touch handle for comfortable and secure grip.
- **Durable Accessories:** Includes 2 Flat Beaters, 2 Dough Hooks, and 1 Net Whisk, all made from 304 Stainless Steel.



Image 2.1: A detailed view of the hand mixer's top panel, highlighting the digital speed display, 'Turbo Boost' button, 'Start/Stop' button, and 'Speed +' and 'Speed -' buttons.

3. Safety Instructions

To reduce the risk of fire, electric shock, or injury, basic safety precautions should always be followed:

1. Read all instructions before using the appliance.
2. Do not immerse the motor unit in water or other liquids. Clean with a damp cloth only.
3. Always unplug the mixer from the outlet before cleaning, attaching or removing parts, or when not in use.
4. Avoid contact with moving parts. Keep hands, hair, clothing, as well as spatulas and other utensils away from beaters during operation to prevent injury and/or damage to the mixer.
5. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
6. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
7. Do not use outdoors.

8. Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
9. Close supervision is necessary when any appliance is used by or near children.

4. Package Contents

Upon unpacking, please ensure all items listed below are present and in good condition:

- 1x Yomelo Electric Hand Mixer
- 2x Flat Beaters (304 Stainless Steel)
- 2x Dough Hooks (304 Stainless Steel)
- 1x Net Whisk (304 Stainless Steel)
- 1x Snap-On Storage Box



Image 4.1: The complete set of the Yomelo hand mixer, including the main unit, flat beaters, dough hooks, whisk, and the transparent storage case.

5. Setup

1. Before first use, wash all accessories (flat beaters, dough hooks, whisk) in warm, soapy water, then rinse and dry thoroughly. The main mixer unit should be wiped clean with a damp cloth.
2. Ensure the mixer is unplugged before attaching or removing any accessories.
3. Insert the desired beaters or hooks into the openings on the bottom of the mixer. Push firmly until they click into place. The flat beaters are interchangeable. For dough hooks, ensure the hook with the collar is inserted into the larger opening.
4. Plug the mixer into a standard electrical outlet.



Image 5.1: The Yomelo hand mixer securely attached to its snap-on storage case, demonstrating how the unit and accessories can be stored compactly.

6. Operating Instructions

6.1. Attaching and Detaching Accessories

To attach, align the accessory shafts with the openings and push until they click. To detach, ensure the mixer is

unplugged and the speed is set to '0'. Press the eject button located on the top of the mixer firmly to release the accessories.



Image 6.1: A hand demonstrating how to press the eject button on the top of the mixer to release the attachments. The digital display shows '0' indicating the mixer is off.

6.2. Using the Mixer

1. After attaching the desired accessories and plugging in the mixer, the digital display will show '0'.
2. Use the 'Speed +' and 'Speed -' buttons to select your desired speed from 1 to 9. The selected speed will be shown on the digital display.
3. Press the 'Start/Stop' button to begin mixing. The mixer will start at the selected speed with soft start technology.
4. For an immediate burst of maximum power, press and hold the 'Turbo' button. Release the button to return to the previously selected speed.
5. When finished mixing, press the 'Start/Stop' button to stop the mixer. The display will return to '0'.
6. Unplug the mixer from the outlet before removing accessories or cleaning.

6.3. Speed Guide

Refer to the table below for recommended speed settings based on ingredients:

Speed Range	Recommended Use
Speed 1-3 (Low Speed)	Mixing dry food (flour, butter, potato), wet food (salad, gravy, sauce, milkshakes). Ideal for chunky ingredients and preventing splattering.
Speed 4-6 (Medium Speed)	Mixing pasty food (cake batter, biscuits), stirring cream, butter, cheese, sugar.
Speed 6-9 (High Speed)	Mixing liquid food (egg, egg whites), whipping cream. For achieving light and fluffy textures.



Image 6.2: A visual representation of the recommended speed settings for different types of ingredients, from low speed for flour and butter to high speed for whipping cream.

7. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your hand mixer.

- Always unplug the mixer before cleaning.
- **Motor Unit:** Wipe the exterior of the motor unit with a damp cloth. Do not immerse the motor unit in water or any other liquid.
- **Accessories (Beaters, Dough Hooks, Whisk):** These stainless steel accessories are dishwasher safe for easy cleaning. Alternatively, they can be washed by hand in warm, soapy water, then rinsed and dried thoroughly.
- **Storage Case:** The snap-on storage case can be washed with warm, soapy water and air-dried.
- Store the mixer and its accessories in the snap-on storage case in a dry place when not in use.

8. Troubleshooting

If you encounter any issues with your Yomelo Hand Mixer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mixer does not turn on.	Not plugged in; power outlet not working; speed not selected.	Ensure the mixer is securely plugged into a working outlet. Select a speed (1-9) before pressing 'Start/Stop'.
Attachments do not stay in place or are difficult to insert/eject.	Attachments not fully inserted; eject button not pressed firmly; incorrect attachment for opening.	Push attachments firmly until they click. Ensure speed is '0' and press eject button completely. For dough hooks, ensure the collared hook goes into the larger opening.
Mixer slows down or struggles during operation.	Too much load; incorrect speed for ingredients.	Reduce the amount of ingredients. Increase the speed setting or use the 'Turbo' function for tougher mixtures.
Unusual noise or smell.	Overheating; internal malfunction.	Immediately stop operation and unplug the mixer. Allow it to cool down. If the issue persists, contact customer support. Do not attempt to repair.

9. Specifications

- **Brand:** Yomelo
- **Model Name:** Yomelo 9-Speed Digital Hand Mixer
- **Model Number:** FD-EP-230201-1173
- **Color:** Ice Blue
- **Motor Power:** 400W DC Motor
- **Speed Settings:** 9 Digital Speeds + Turbo Boost
- **Controls Type:** Push Button, Touch Buttons
- **Product Dimensions:** 3.1"D x 5.5"W x 7.2"H
- **Item Weight:** 2.8 Pounds (approx. 2.76 lbs)
- **Blade Material:** Stainless Steel (304)
- **Container Material:** Polycarbonate (PC), Acrylonitrile Butadiene Styrene (ABS)

- **Noise Level:** 50 dB
- **UPC:** 704415835669
- **Manufacture Year:** 2024

10. Warranty and Support

Yomelo provides a 12-month free replacement and money-back guarantee for this product. If you experience any issues or have questions regarding your Yomelo 9-Speed Digital Hand Mixer, please contact our customer support for assistance.

For support, please refer to the contact information provided with your purchase or visit the official Yomelo website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question