SOGO SS-5125

SOGO SS-5125 Cold Press Slow Juicer User Manual

Your guide to operating and maintaining your SOGO SS-5125 Cold Press Slow Juicer.

Introduction

Thank you for choosing the SOGO SS-5125 Cold Press Slow Juicer. This appliance is designed to efficiently extract juice from various fruits and vegetables, preserving nutrients and minimizing oxidation through its slow pressing technology. Please read this manual carefully before use to ensure safe and optimal operation.

Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the feeder chute during operation to prevent injury. Use the food pusher provided.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Do not allow the cord to hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure all parts are correctly assembled before operating the juicer.
- Do not process frozen fruits or vegetables in the juicer.

Product Overview

The SOGO SS-5125 Cold Press Slow Juicer is designed for efficient and quiet operation, extracting maximum juice while

preserving nutrients. Below is an image of the assembled product.



Figure 1: Front view of the SOGO SS-5125 Cold Press Slow Juicer, showing the main unit, feeder chute, and control panel.

The juicer comes with various components and accessories to enhance your juicing experience.

- Motor Base with Digital Touch Panel
- Juicing Bowl
- Auger (Squeezing Screw)
- Filters (Fine, Coarse, Sorbet)
- Hopper/Feeder Chute
- Pusher
- Juice Cup (1 Liter)
- Pulp Container (0.8 Liter)
- Cleaning Brush
- Recipe Book



Figure 2: The three interchangeable filters (fine, coarse, and sorbet) included with the juicer, allowing for different juice consistencies and sorbet making.

Setup

Unpacking

1. Carefully remove all components from the packaging.
2. Remove any protective films or packaging materials.
3. Wash all detachable parts (juicing bowl, auger, filters, hopper, juice cup, pulp container, pusher) with warm soapy water, rinse thoroughly, and dry. The motor base should only be wiped with a damp cloth.

Assembly

1. Place the motor base on a stable, flat surface.
2. Align the juicing bowl with the motor base and rotate it clockwise until it locks into place.
3. Insert the desired filter (fine for clear juice, coarse for pulpy juice, or sorbet filter) into the juicing bowl.
4. Insert the auger into the center of the filter, pressing down gently until it sits firmly.
5. Place the hopper/feeder chute onto the juicing bowl, aligning the marks, and rotate clockwise until it locks securely.
6. Position the juice cup under the juice spout and the pulp container under the pulp spout.
7. Ensure the anti-drip stopper on the juice spout is closed before starting.

Operating Instructions

Preparation of Ingredients

- Wash all fruits and vegetables thoroughly.
- Remove any hard seeds, pits, or thick peels (e.g., citrus, pineapple).
- Cut ingredients into pieces small enough to fit into the feeder chute. For fibrous vegetables like celery, cut into short pieces to prevent clogging.
- For leafy greens, roll them into a tight ball before inserting.

Juicing Process

1. Plug the appliance into a power outlet.
2. Press the Power button on the digital touch panel to turn on the juicer.
3. Select the desired program from the 9 pre-defined functions on the touch panel, or use the manual settings.
4. Slowly feed the prepared ingredients into the feeder chute. Use the pusher only when necessary to guide

ingredients down. Do not force ingredients.

5. The juicer will automatically separate juice and pulp into their respective containers.
6. Once juicing is complete, press the Power button to turn off the appliance and unplug it.
7. Open the anti-drip stopper to release any remaining juice into the cup.



Figure 3: A green apple being gently inserted into the feeder chute of the SOGO SS-5125 juicer, ready for the slow juicing process.

Control Panel Functions

The digital touch panel offers intuitive control over the juicing process.

Icon/Function	Description
Power On/Off	Turns the appliance on or off.
Reverse (REV)	Reverses the auger rotation to clear jams or clogs. Use for a few seconds at a time.
Pre-defined Programs	9 specific programs optimized for different types of ingredients (e.g., soft fruits, hard vegetables, leafy greens).
Smart Mode	Automatically adjusts juicing speed based on ingredient hardness.

Icon/Function	Description
Clean Mode	Initiates an automatic cleaning cycle by adding water to the chute.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your juicer.

Disassembly for Cleaning

1. Ensure the juicer is turned off and unplugged from the power outlet.
2. Remove the juice cup and pulp container.
3. Rotate the hopper/feeder chute counter-clockwise and lift it off.
4. Remove the auger and then the filter from the juicing bowl.
5. Rotate the juicing bowl counter-clockwise and lift it off the motor base.

Cleaning

- **Automatic Cleaning:** For quick cleaning between uses or before full disassembly, close the anti-drip stopper, pour a glass of water into the feeder chute, and run the juicer in "Clean Mode" for a few seconds. Then open the stopper to drain the water.
- **Manual Cleaning:** Rinse all detachable parts (juicing bowl, auger, filters, hopper, juice cup, pulp container, pusher) under running water immediately after use to prevent pulp from drying.
- Use the provided cleaning brush to thoroughly clean the filter mesh, as pulp can easily get stuck here.
- For stubborn residue, wash parts with warm soapy water. All detachable parts are dishwasher safe (top rack recommended).
- Wipe the motor base with a damp cloth. Never immerse the motor base in water.
- Dry all parts completely before reassembling or storing.

Storage

Store the disassembled or fully assembled juicer in a clean, dry place, away from direct sunlight and extreme temperatures. Ensure all parts are dry before storage to prevent mold or odors.

Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly; power outage.	Ensure the power cord is securely plugged in. Check if all parts are correctly locked into place. Verify power supply.
Juicer stops during operation or jams.	Too much ingredient fed at once; hard ingredients; fibrous ingredients clogging.	Press the "Reverse" button for a few seconds to clear the jam. If persistent, disassemble and clean. Feed ingredients slowly and cut hard/fibrous items into smaller pieces.

Problem	Possible Cause	Solution
Excessive pulp in juice.	Coarse filter used; filter clogged.	Ensure the fine filter is used for clearer juice. Clean the filter thoroughly.
Loud noise or vibration.	Parts not assembled correctly; foreign object inside.	Disassemble and reassemble all parts, ensuring they are securely locked. Check for any foreign objects.

Technical Specifications

Feature	Detail
Model Number	SS-5125
Brand	SOGO
Power	200W
Voltage	220-240V~ 50/60Hz
Dimensions (L x W x H)	10 x 48 x 50 cm
Weight	2 Kilograms
Juice Cup Capacity	1 Liter
Pulp Container Capacity	0.8 Liter
Noise Level	< 60 dB
Material	Stainless Steel, BPA-Free Plastic, Acrylic
Special Features	Digital Touch Panel, 9 Pre-defined Functions, Reverse Function, Automatic Cleaning, Low RPM (50-55)



Figure 4: Product label displaying model number, electrical specifications (200W), and compliance marks.

Warranty and Support

This SOGO SS-5125 Cold Press Slow Juicer comes with a standard manufacturer's warranty. Please refer to your purchase documentation for specific warranty terms and conditions. Spare parts availability is indicated for 2 years from the date of purchase.

For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact SOGO customer service through their official website or the retailer from whom you purchased the product. Keep your proof of purchase for warranty validation.

© 2024 SOGO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question