**Tefal CY7788**

# Tefal Turbo Cuisine & Fry Multicooker User Manual

**Model: CY7788**

## Introduction

Welcome to the world of versatile cooking with your new Tefal Turbo Cuisine & Fry Multicooker. This innovative appliance combines the speed of a pressure cooker with the crisping capabilities of a hot air fryer, offering 14 automatic cooking programs to simplify your meal preparation. From tender stews to crispy fries, enjoy delicious and healthy dishes with ease.

## Important Safety Information

Please read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance from the power outlet when not in use and before cleaning.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only genuine Tefal accessories and replacement parts.
- Exercise extreme caution when opening the pressure lid after cooking, as hot steam may escape. Always use the steam release button.
- Ensure adequate ventilation around the appliance during operation, especially when using the Extra Crisp lid.
- Do not place the appliance on or near a hot gas or electric burner, or in a heated oven.

## What's in the Box

Your Tefal Turbo Cuisine & Fry Multicooker package includes the following components:

- Main Multicooker Unit
- Pressure Cooking Lid
- Extra Crisp Air Fryer Lid
- Removable Spherical Cooking Bowl
- Steaming/Frying Insert
- Measuring Cup
- Rice Spoon
- Recipe Booklet




Figure 1: All components included with the Tefal Turbo Cuisine & Fry Multicooker.

## Setup

1. **Unpack and Clean:** Carefully remove all packaging materials. Wash the spherical cooking bowl, steaming/frying insert, measuring cup, and rice spoon with warm, soapy water. Wipe the main unit and lids with a damp cloth. Ensure all parts are completely dry before assembly.
2. **Place the Cooking Bowl:** Insert the spherical cooking bowl into the main multicooker unit. Ensure it is seated correctly and stable.
3. **Choose Your Lid:** Depending on your cooking method, select either the Pressure Cooking Lid or the Extra Crisp Air Fryer Lid.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet. The display will illuminate.




Figure 2: Exploded view illustrating the assembly of the multicooker components.

## Operating Instructions

The Tefal Turbo Cuisine & Fry Multicooker features an intuitive control panel with a single knob for program selection and adjustments.




Figure 3: Front view of the multicooker's control panel.

## General Operation

1. **Power On:** Press the power button to turn on the appliance.
2. **Select Program:** Rotate the central knob to browse through the 14 automatic cooking programs. The selected program will be highlighted on the digital display.
3. **Adjust Settings:** For some programs, you can adjust cooking time or temperature using the knob and

confirmation buttons.

4. **Start Cooking:** Press the Start/Stop button to begin the cooking cycle.




Figure 4: Adjusting settings using the control knob.

## Pressure Cooking

Use the Pressure Cooking Lid for fast and efficient cooking of stews, soups, and other pressure-cooked dishes.

1. Place ingredients into the spherical cooking bowl.
2. Securely attach the Pressure Cooking Lid, ensuring it is locked into place according to the markings on the unit.
3. Select a pressure cooking program (e.g., Stew, Soup) or manual pressure setting.
4. Press Start. The appliance will build pressure, indicated by the pressure indicator.
5. Once cooking is complete, allow pressure to release naturally or use the steam release button for a quick release. **Caution:** Always keep hands and face clear of the steam vent when releasing pressure.




Figure 5: Safely releasing steam using the dedicated button.

## Hot Air Frying (Extra Crisp Lid)

Transform your multicooker into an air fryer for crispy results with little to no oil using the Extra Crisp Lid.

1. Place the steaming/frying insert into the spherical cooking bowl if needed, then add your food.
2. Place the Extra Crisp Lid securely on top of the main unit.
3. Select an air frying program (e.g., Fry, Grill, Bake, Roast) or manual settings on the lid's control panel.
4. Press Start. The lid will begin circulating hot air.




Figure 6: Control panel of the Extra Crisp Air Fryer Lid.

## Other Automatic Programs

The multicooker offers a variety of other programs for diverse cooking needs:

- **Steam:** For vegetables, fish, and dumplings.
- **Sear:** To brown meats and vegetables before cooking.
- **Sous-Vide:** For precise temperature cooking.
- **Slow Cooking:** For tender, long-cooked dishes.
- **Rice:** Perfectly cooked rice every time.
- **Porridge:** Creamy breakfast oats.
- **Yogurt & Fermentation:** For homemade yogurt and fermented foods.
- **Soups:** Quick and easy soup preparation.
- **Baking:** For cakes and desserts.
- **Manual Control:** For custom cooking settings.

## Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your multicooker.

- **Unplug Before Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Spherical Cooking Bowl:** The non-stick cooking bowl is easy to clean. It is dishwasher safe. For best results, wash with warm, soapy water and a soft sponge.
- **Lids:** The Pressure Cooking Lid and its removable parts (gasket, valve) can be washed with warm, soapy water. The Extra Crisp Lid should be wiped clean with a damp cloth; do not immerse it in water.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
- **Accessories:** The steaming/frying insert, measuring cup, and rice spoon are dishwasher safe.
- **Storage:** Store the appliance in a dry place when not in use.

## Troubleshooting

If you encounter any issues with your Tefal Turbo Cuisine & Fry Multicooker, please refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not turn on. | Not plugged in; power outage; faulty outlet. | Ensure power cord is securely plugged in. Check circuit breaker. Try a different outlet. |
| Pressure not building (Pressure Cooking). | Lid not properly sealed; steam release valve open; insufficient liquid. | Ensure lid is correctly closed and locked. Close the steam release valve. Add required liquid as per recipe. |
| Food not crisping (Air Frying). | Overcrowding; incorrect temperature/time; food not dry enough. | Do not overcrowd the basket. Adjust temperature/time. Pat food dry before air frying. |
| Error code on display. | Specific internal issue. | Refer to the full instruction manual for specific error code meanings and solutions. If persistent, contact customer support. |

For more detailed troubleshooting or issues not listed here, please consult the comprehensive user manual or contact Tefal Customer Support.

## Specifications

| Feature | Detail |
|---|---|
| Brand | Tefal |

| Feature | Detail |
| --- | --- |
| Model Number | CY7788 |
| Capacity | 7.5 Liters |
| Material | Aluminium, Plastic |
| Color | Black |
| Wattage | 1090 watts |
| Item Weight | 12 Kilograms (26.4 pounds) |
| Control Method | Touch, Hand Control (Knob) |
| Voltage | 230 Volts |
| Product Dimensions (L x W x H) | 15.04 x 15.04 x 24.8 inches (approx. 34.5 x 37.5 x 39.5 cm) |
| Special Feature | Dishwasher Safe (removable parts, except Extra Crisp Lid) |




Figure 7: Product dimensions for the Tefal Turbo Cuisine & Fry Multicooker.

## Warranty and Support

Tefal products are manufactured to the highest quality standards. This product is covered by a limited warranty from the date of purchase. Please refer to the warranty card included in your packaging for specific terms and conditions, including warranty period and coverage details.

For technical assistance, troubleshooting, or to inquire about replacement parts, please contact Tefal Customer Support. Contact information can typically be found on the Tefal official website or in your product's original documentation.

Please retain your proof of purchase for warranty claims.

© 2024 Tefal. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question