FABULETTA FAF001

Fabuletta Air Fryer 4.2QT (Model FAF001) Instruction Manual

Model: FAF001 | Brand: FABULETTA

1. Introduction

Thank you for choosing the Fabuletta 4.2QT Air Fryer. This appliance uses 360° Rapid Air Circulation Technology to cook your favorite foods with up to 85% less oil, delivering crispy and tender results. With its intuitive controls and versatile presets, preparing healthy and delicious meals is simple and efficient. Please read this manual thoroughly before use to ensure safe and optimal operation.

2. Important Safeguards

- Always place the appliance on a stable, heat-resistant surface.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Keep hands and face away from hot steam vents during operation.
- Do not fill the basket with oil; this is an air fryer, not a deep fryer.
- Ensure the appliance is unplugged when not in use and before cleaning.
- Supervise children closely when the appliance is in use.
- Do not block any air vents.
- This appliance is for household use only.

3. Product Components



Main Unit: The primary body of the air fryer, housing the heating element and control panel.



Frying Basket: The removable, non-stick container where food is placed for air frying. It features a square design for increased cooking capacity.



Crisper Plate: Inserted into the frying basket, this perforated plate allows air to circulate around food for even cooking and crisping. It is removable for easy cleaning.



Package Contents: Includes the main unit, frying basket, crisper plate, and user manual. A recipe book is also included to inspire your cooking.

4. Setup

1. Unpack all components and remove any packaging materials.
2. Wipe the exterior of the main unit with a damp cloth.

3. Wash the frying basket and crisper plate thoroughly with hot water, dish soap, and a non-abrasive sponge. Rinse and dry completely.
4. Place the crisper plate into the frying basket.
5. Slide the assembled frying basket back into the main unit until it clicks securely into place.
6. Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances to ensure proper airflow.

5. Control Panel & Functions



The air fryer features a large digital touch screen with intuitive controls and 9 preset modes.

- **Power Button:** Turns the appliance on/off.

- **Temp/Time Button:** Press once to adjust temperature, press twice to adjust time.
- **Select/Increase Button (>):** Selects functions or increases temperature/time.
- **Select/Decrease Button (<):** Selects functions or decreases temperature/time.
- **Start/Pause Button:** Starts or pauses the cooking cycle.
- **Preset Modes:** Dedicated buttons for Fries, Chicken, Steak, Dessert, Seafood, Bacon, Veggies, Dehyd, and Preheat.
- **Shake Reminder:** An indicator that prompts you to shake the basket for even cooking.

6. Operating Instructions

Basic Operation

1. Plug the air fryer into a grounded electrical outlet.
2. Place ingredients in the frying basket, ensuring not to overfill.
3. Select a preset mode or manually set the desired temperature (150°F-450°F) and time (1-60 minutes) using the Temp/Time and +/- buttons.
4. Press the Start/Pause button to begin cooking.
5. The Shake Reminder will alert you when it's time to shake the basket (if applicable for the selected preset). Carefully remove the basket, shake, and reinsert.
6. The air fryer will automatically stop when the timer reaches zero.

Special Features

- **Memory Function:** You can remove the frying basket at any time during cooking. The appliance will pause and resume the original process once the basket is reinserted.
- **Thermo IQ Technology:** Automatically adjusts temperature to keep fluctuations under 5°F for evenly cooked meals, preventing burnt or undercooked food.
- **Even Crisp Technology:** Allows optimal airflow for a perfect golden finish, ensuring crispy and tender results.

7. Cooking Guide & Presets

The Fabuletta Air Fryer offers 9 convenient preset modes for various dishes. These are optimized for common foods, but you can always adjust time and temperature to suit your preferences.



The digital display shows 9 preset options for easy cooking.

Preset Modes:

- **Fries:** Ideal for crispy French fries.
- **Chicken:** Perfect for chicken wings, drumsticks, or thighs.
- **Steak:** For cooking various cuts of steak to your desired doneness.
- **Dessert:** Suitable for small baked goods or pastries.
- **Seafood:** Optimized for fish fillets, shrimp, or other seafood.
- **Bacon:** For perfectly crispy bacon.
- **Veggies:** Great for roasting or crisping vegetables.
- **Dehyd:** For dehydrating fruits or vegetables.
- **Preheat:** Warms the air fryer to the desired temperature before adding food.

Cooking Performance



The 360° Rapid Air Circulation Technology ensures food cooks efficiently and quickly.



Achieve Maxx Tender and Juicy results with Thermo IQ Technology.



Even Crisp Technology delivers Maxx Crispy Results with less oil.

Official Product Videos:

Video: Make Quick and Easy Meals with Fabuletta FAF001 Air Fryer. This video demonstrates how to prepare various dishes quickly and easily using the Fabuletta FAF001 Air Fryer, highlighting its efficiency and user-friendly features.

Video: Fabuletta Air Fryers - For Crisp, Tender and Juicy result. This video showcases the Fabuletta Air Fryer's ability to deliver crisp, tender, and juicy results for a variety of foods, emphasizing its cooking performance.

8. Cleaning & Maintenance

Proper cleaning ensures the longevity and optimal performance of your air fryer.



The removable non-stick basket and crisper plate are dishwasher safe for easy cleaning.

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The removable non-stick basket and crisper plate are food-grade, PFOA-free, BPA-free, and dishwasher safe.
- For stubborn food residue, soak the basket and plate in warm, soapy water before washing.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Ensure all parts are completely dry before storing or next use.

9. Troubleshooting

If you encounter any issues with your Fabuletta Air Fryer, please refer to the following common problems and solutions:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a grounded outlet. Check if the basket is

correctly inserted.

- **Food not cooking evenly:** Ensure the basket is not overcrowded. Use the Shake Reminder function to toss or turn food halfway through cooking.
- **White smoke coming from the appliance:** This may indicate excessive grease from fatty foods. Clean the basket and crisper plate thoroughly.
- **Unusual odors:** During initial uses, a slight odor may occur. This is normal and will dissipate. Ensure proper ventilation.
- For more detailed troubleshooting, please consult the full user manual.

10. Technical Specifications

Specification	Value
Model Number	FAF001
Capacity	4.2 Quarts (1.5 Pounds of French Fries)
Wattage	1550W (120V)
Control Method	Touch
Min Temperature Setting	150°F
Max Temperature Setting	450°F
Timer Range	1-60 minutes
Air Frying Technology	360° Rapid Air Circulation Technology
Nonstick Coating	Yes
Dishwasher Safe Parts	Basket, Crisper Plate
Certifications	ETL-Listed, FDA Compliant

11. Warranty & Support

Fabuletta provides a **24-month warranty** for this product. We also offer **lifetime customer service** to address any issues or concerns you may have. Please contact our customer support team for assistance.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question