ALLIMITY QYSY-DH-2110-QYSY

ALLIMITY Replacement Remote Control Instruction Manual

Model: QYSY-DH-2110-QYSY
For Polaroid SMART HD LED TVs

1. Introduction

This instruction manual provides essential information for the proper setup and operation of your ALLIMITY QYSY-DH-2110-QYSY replacement remote control. This remote is designed to function as a direct replacement for your original Polaroid SMART HD LED TV remote, requiring no programming. Simply insert batteries, and it is ready for use with compatible models.

2. Product Overview

The ALLIMITY QYSY-DH-2110-QYSY remote control is an ergonomic device designed for comfortable handling and intuitive operation of your compatible Polaroid television. It features a standard layout with dedicated buttons for common TV functions and popular streaming services.



Figure 1: Angled view of the ALLIMITY QYSY-DH-2110-QYSY Replacement Remote Control. This image displays the full button layout, including power, number keys, volume, channel, navigation, and dedicated buttons for services like Netflix and YouTube.



Figure 2: The ALLIMITY QYSY-DH-2110-QYSY remote control positioned next to a television, illustrating its typical use context.

3. Setup

3.1 Battery Installation

The remote control operates on two (2) AAA alkaline batteries (not included). Ensure correct polarity when inserting the batteries.

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two new AAA alkaline batteries, matching the (+) and (-) terminals as indicated inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: *Remove batteries if the remote control will not be used for an extended period to prevent leakage and damage.*

4. Operating Instructions

This remote control is designed for immediate use with compatible Polaroid SMART HD LED TVs once batteries are installed. Ensure a clear line of sight between the remote control and the TV's infrared sensor.

4.1 Basic TV Functions

- **ON/OFF (Power):** Press to turn the TV on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **VOL +/-:** Adjust the volume level.
- **CH +/-:** Change channels sequentially.
- **Mute:** Mute or unmute the TV sound.

- **SOURCE:** Select input sources (e.g., HDMI, AV).
- **MENU:** Access the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Navigate through menus and confirm selections.
- **EXIT:** Exit the current menu or function.
- **BACK:** Return to the previous screen or menu.

4.2 Smart TV and Special Functions

- **Freeview Play:** Access Freeview Play services (if supported by your TV model and region).
- **TV GUIDE:** Display the electronic program guide.
- **INFO:** Show information about the current program.
- **TEXT:** Access teletext services.
- **SUBTITLE:** Toggle subtitles on or off.
- **SMART:** Access the TV's smart hub or smart features.
- **NETFLIX:** Direct access to the Netflix application.
- **YouTube:** Direct access to the YouTube application.
- **Media Playback Controls (Play, Pause, Stop, Fast Forward, Rewind, Skip):** Control media playback.
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies by TV model and application; typically used for interactive services or specific menu options.

5. Compatibility

This ALLIMITY replacement remote control is compatible with the following Polaroid SMART HD LED TV models:

- P32RDP0119U
- P50UP1399U
- P24RP0080U
- P24RDP0100U
- 32/138Q-GB-11B4-EGPF-UK
- 32/138M-GB-11B4-EGPX-UK
- 32/138M-GB-11B4-EGQPX-UK
- 40/138M-GB-11B4-FEGPX-UK
- 40/138M-GB-11B4-FEGQPX-UK
- 40/138Q-GV B-11B4-FEGPF-UK

If your TV model is not listed, please verify compatibility with the manufacturer before use.

6. Troubleshooting

6.1 Remote Control Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new AAA alkaline batteries.
- **Line of Sight:** Make sure there is a clear path between the remote control's infrared emitter and the TV's infrared receiver. Obstructions can block the signal.
- **Distance:** Operate the remote within its effective range (up to 10 meters).

- **Interference:** Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with the infrared signal. Try operating the remote in a different lighting condition.

6.2 Specific Buttons Not Working

- **Compatibility:** Verify that your TV model is listed in the compatibility section. While this remote is a replacement, some specific advanced functions might vary slightly depending on the original remote's features for your exact TV model.
- **Clean Remote:** Ensure buttons are not stuck or dirty. Gently clean the remote surface if necessary.

7. Specifications

Brand	ALLIMITY
Model Number	QYSY-DH-2110-QYSY
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Alkaline Batteries (not included)
Maximum Range	10 Meters
Number of Buttons	16 (functional buttons)
Special Feature	Ergonomic Design

8. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades.

9. Warranty and Support

For warranty information or technical support regarding your ALLIMITY replacement remote control, please refer to the retailer's return policy or contact the manufacturer directly through their official support channels. Please have your product model number (QYSY-DH-2110-QYSY) and purchase details available when seeking assistance.

© 2023 ALLIMITY. All rights reserved.