ZdalaMit 100040212

ZdalaMit Replacement Remote Control Instruction Manual

Model: 100040212 | Brand: ZdalaMit

1. Introduction

This manual provides comprehensive instructions for the ZdalaMit Replacement Remote Control, specifically designed for use with various ONN Soundbar models. Please read this manual carefully before use to ensure proper operation and longevity of your remote control. This remote offers a direct replacement solution, requiring no complex programming.

2. Product Overview

The ZdalaMit Replacement Remote Control is a compact and ergonomic device designed for intuitive control of your ONN Soundbar. It features clearly labeled buttons for all essential functions.





Front view of the ZdalaMit Replacement Remote Control, showing all buttons clearly labeled. The remote is black with a brushed texture, and buttons are circular or oval, with a prominent red power button at the top left.

Remote Control Buttons:

- **Power (Red Button):** Turns the soundbar on or off.
- **Mute (Speaker with X icon):** Mutes or unmutes the sound.

- **AUX:** Selects the Auxiliary input source.
- **HDMI ARC:** Selects the HDMI Audio Return Channel input source.
- **HDMI IN:** Selects the standard HDMI input source.
- **Bluetooth (Asterisk icon):** Selects the Bluetooth input source.
- **Optical:** Selects the Optical audio input source.
- **VOL +** / **VOL -:** Increases or decreases the master volume.
- **Play/Pause (Center Button):** Controls media playback (play/pause).
- **Previous Track (Left Arrow):** Skips to the previous track.
- **Next Track (Right Arrow):** Skips to the next track.
- **RESET:** Resets sound settings to default.
- **BASS +** / **BASS -:** Adjusts the bass level.
- **TREB +** / **TREB -:** Adjusts the treble level.
- **EQ:** Cycles through equalizer presets.

3. Setup

Battery Installation:

The remote control requires two (2) AAA Alkaline batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: *No programming or pairing is required for this replacement remote control. It is ready for use immediately after battery installation.*

4. Operating Instructions

To operate your ONN Soundbar with this replacement remote control, ensure there is a clear line of sight between the remote and the soundbar's infrared (IR) receiver.

Basic Operation:

- **Power On/Off:** Press the **Power** button to turn the soundbar on or off.
- **Volume Control:** Use the **VOL +** and **VOL -** buttons to adjust the sound volume.
- **Input Selection:** Press the respective input buttons (**AUX**, **HDMI ARC**, **HDMI IN**, **Optical**, **Bluetooth**) to switch between audio sources.

- **Mute:** Press the **Mute** button to temporarily silence the sound. Press again to unmute.
- **Sound Adjustments:** Use **BASS +** / **-** and **TREB +** / **-** to fine-tune bass and treble levels. Press **EQ** to cycle through available equalizer modes (e.g., Movie, Music, News).
- **Playback Control:** For compatible sources, use the **Play/Pause**, **Previous Track**, and **Next Track** buttons to control media playback.
- **Reset Settings:** Press the **RESET** button to restore the soundbar's audio settings to their factory defaults.

5. Maintenance

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA Alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

Storage:

Store the remote control in a dry place, away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	Dead or incorrectly inserted batteries. Obstruction between remote and soundbar. Remote is out of range.	Replace batteries with new ones, ensuring correct polarity. Remove any obstructions. Move closer to the soundbar.
Some functions are not working.	Incorrect input selected on soundbar. Soundbar model incompatibility.	Ensure the correct input source is selected (e.g., HDMI, AUX). Verify your ONN Soundbar model is listed as compatible (100027812, 100015717, 100008866).
Soundbar does not respond consistently.	Low batteries. Infrared interference.	Replace batteries. Ensure no strong light sources (like direct sunlight or certain LED lights) are interfering with the soundbar's IR receiver.

If the issue persists after trying these solutions, please refer to the Warranty & Support section for further assistance.

7. Specifications

Brand	ZdalaMit
Model Number	100040212
Compatible ONN Soundbar Models	100027812, 100015717, 100008866
Power Supply	2 x 1.5V AAA Alkaline Battery (not included)
Product Dimensions	5 x 1 x 0.5 inches (approximately)
Item Weight	1.5 ounces (approximately)
Color	Black

8. Warranty & Support

This ZdalaMit Replacement Remote Control is designed for reliable performance. For any questions, concerns, or issues not covered in this manual, please contact the seller or manufacturer directly through your purchase platform.
Please retain your proof of purchase for any warranty claims or support inquiries.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question