USHA ST4272 G

Usha ST4272 G Sandwich Griller Instruction Manual

Model: ST4272 G

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating this appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended household use.
- This appliance features a cool-touch body and handle for safe operation.



The griller incorporates 2-stage thermal safety mechanisms and an anti-skid base for stability during use.

2. Product Components

Familiarize yourself with the parts of your Usha ST4272 G Sandwich Griller.



The Usha ST4272 G Sandwich Griller in its closed position.

- **Grilling Plates:** Fixed, non-stick, food-grade material for easy release and cleaning. Designed for thicker sandwiches up to 25mm.
- **Cool-Touch Handle:** Ensures safe handling during operation.
- **Power ON Indicator:** Illuminates when the appliance is connected to power.
- **Ready to Cook Indicator:** Illuminates when the grilling plates have reached the optimal temperature.
- **Locking Latch:** Secures the griller plates during cooking.
- **Anti-Skid Base:** Provides stability on countertops.



The griller features spacious heating plates suitable for thicker sandwiches and a food-grade non-stick coating.



The appliance includes a cool-touch handle for safety and indicator lights for power and readiness.

3. Before First Use

Before using your sandwich griller for the first time, follow these steps:

1. Unpack the appliance and remove all packaging materials.
2. Wipe the grilling plates with a damp cloth or sponge. Do not immerse the appliance in water.
3. Wipe the exterior of the appliance with a soft, damp cloth.
4. Ensure the appliance is completely dry before plugging it in.
5. For the first use, it is recommended to operate the griller empty for approximately 5-10 minutes to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal. Ensure good ventilation.
6. Unplug and allow to cool, then wipe the plates again.

4. Operating Instructions

Follow these steps to prepare your grilled sandwiches:

1. **Prepare Ingredients:** Prepare your bread and sandwich fillings. The griller can accommodate thicker sandwiches up to 25mm.
2. **Preheat:** Close the griller and plug the power cord into a 230V AC electrical outlet. The Power ON indicator will illuminate. The griller will begin to preheat.
3. **Ready Indicator:** Once the griller reaches the optimal cooking temperature, the Ready to Cook indicator light will illuminate. This typically takes a few minutes.
4. **Place Sandwiches:** Carefully open the griller using the cool-touch handle. Place your prepared sandwiches onto the lower grilling plate. Do not overfill.
5. **Close and Lock:** Gently close the top plate over the sandwiches and engage the locking latch.
6. **Grill:** Allow the sandwiches to grill for approximately 3-5 minutes, or until golden brown and heated through. The Ready to Cook indicator light may cycle on and off during cooking as the thermostat maintains the temperature.
7. **Remove Sandwiches:** Once cooked, carefully open the griller. Use a heat-resistant plastic or wooden spatula to remove the sandwiches. Do not use metal utensils, as they can damage the non-stick coating.
8. **Unplug:** After use, unplug the griller from the electrical outlet and allow it to cool completely before cleaning.

5. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your Usha ST4272 G Sandwich Griller.



The griller features non-stick Teflon coated plates for easy cleaning and a locking mechanism for secure closure.

- **Always Unplug:** Ensure the griller is unplugged from the power outlet and completely cool before cleaning.
- **Clean Grilling Plates:** The non-stick plates are easy to clean. Wipe them with a damp cloth or sponge. For stubborn food residue, dampen a cloth with a small amount of cooking oil and wipe the plates, then wipe clean with a damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the non-stick coating.
- **Clean Exterior:** Wipe the exterior plastic body with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
- **Do Not Immerse:** Never immerse the griller, its cord, or plug in water or any other liquid.
- **Storage:** Store the griller in a clean, dry place once it is cool and clean. The locking latch helps keep the plates closed for compact storage.

6. Troubleshooting

If you encounter issues with your sandwich griller, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Griller does not heat up.	Not plugged in; power outlet faulty; appliance faulty.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. If the issue persists, contact customer support.
Food sticks to the plates.	Plates not properly cleaned; non-stick coating damaged; insufficient oil/butter.	Ensure plates are clean before use. Lightly brush plates with cooking oil or butter. Avoid using metal utensils.
Sandwiches are not evenly cooked.	Uneven placement of food; griller not fully preheated.	Ensure the griller is fully preheated (Ready to Cook light is on). Distribute sandwich fillings evenly.
Smoke or odor during first use.	Manufacturing residues burning off.	This is normal for first use. Ensure good ventilation. It should dissipate after a few minutes.

7. Technical Specifications

Feature	Specification
Model Number	ST4272 G
Power	750 Watts
Voltage	230 Volts
Capacity	2 Slices (for sandwiches up to 25 mm thick)
Plate Type	Fixed, Non-Stick Food Grade Material
Body Material	Plastic (Cool Touch)
Color	Black
Item Weight	1250 Grams
Included Components	Main Unit, Instruction Manual, Warranty Card

8. Warranty Information

Your Usha ST4272 G Sandwich Griller comes with a**2-year limited warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

Please retain your purchase receipt and the warranty card for any warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or commercial use.

For detailed terms and conditions, refer to the warranty card included with your product.

9. Customer Support

For any queries, service requests, or assistance with your Usha ST4272 G Sandwich Griller, please contact Usha International Ltd. customer support:

- **Manufacturer:** USHA International LTD.

- **Contact Number:** +91-124-4583100
- **Address:** Plot No. 15, Institutional Area, Sector 32, Gurugram 122 001, Haryana, India

Please have your model number (ST4272 G) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question