Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ActiveJet Nikita 1P

ActiveJet Foco Nikita 1P E27 Wall Lamp User Manual

Model: Nikita 1P (OSWACJKIN0105)

1. Introduction

Thank you for purchasing the ActiveJet Foco Nikita 1P E27 Wall Lamp. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

2. Safety Instructions

- **Electrical Safety:** Installation must be performed by a qualified electrician or competent person in accordance with all local and national electrical codes. Always switch off the main power supply at the circuit breaker before commencing any installation, maintenance, or bulb replacement.
- **Voltage:** Ensure the supply voltage matches the fixture's requirements (220-240V, 50Hz).
- **Bulb Type:** Use only E27 base bulbs with a maximum wattage of 60W. Exceeding the maximum wattage can cause overheating and damage to the fixture or create a fire hazard.
- **Environment:** This fixture is designed for indoor use only (IP20 rating). Do not expose to moisture or direct water spray.
- **Handling:** Handle the glass shade and metal components with care to prevent breakage or damage.
- **Cleaning:** Disconnect power before cleaning. Use a soft, dry cloth. Do not use abrasive cleaners or solvents.

3. Package Contents

Please check that all components are present and undamaged before installation. If any parts are missing or damaged, do not proceed with installation and contact your retailer.

- ActiveJet Foco Nikita 1P Wall Lamp Fixture (Nickel finish)
- Glass Shade
- Mounting Hardware (screws, wall plugs)
- Instruction Manual



Image 1: The ActiveJet Foco Nikita 1P Wall Lamp packaging, showing the product box with branding and key features.

4. Setup and Installation

Tools Required: Screwdriver, drill, wire strippers, voltage tester, pencil, measuring tape.

1. **Prepare for Installation:**
    - **IMPORTANT:** Turn off the electricity at the main fuse box or circuit breaker before starting installation.
    - Carefully unpack the fixture and all components.
2. **Mark Mounting Position:**
    - Hold the mounting bracket (part of the fixture base) against the wall at the desired installation point.
    - Mark the drilling points with a pencil.
3. **Drill Holes and Install Wall Plugs:**
    - Drill holes at the marked positions suitable for the provided wall plugs.
    - Insert the wall plugs flush with the wall surface.

4. **Wire the Fixture:**
    - Connect the household electrical wires to the fixture's wires according to standard wiring practices (Live to Live, Neutral to Neutral, Earth to Earth). Ensure all connections are secure.
    - Use appropriate terminal blocks if necessary.
5. **Mount the Fixture:**
    - Align the fixture base with the drilled holes and secure it to the wall using the provided screws. Ensure the fixture is firmly attached.



Image 2: A close-up view of the ActiveJet Foco Nikita 1P Wall Lamp, showing the nickel-finished base and the frosted glass shade, ready for bulb insertion.

6. **Install the Bulb:**
    - Gently screw an E27 base bulb (max 60W) into the lamp holder. Do not overtighten.
7. **Attach the Glass Shade:**
    - Carefully place the glass shade onto the fixture and secure it according to the design (e.g., by screwing it onto a threaded ring or using retaining clips).



Image 3: Another perspective of the ActiveJet Foco Nikita 1P Wall Lamp, highlighting the curved arm and the secure attachment of the frosted glass shade to the nickel base.

8. **Restore Power:**
    - Once installation is complete and all connections are secure, turn the main power supply back on.

5. Operating Instructions

The ActiveJet Foco Nikita 1P Wall Lamp operates via your standard wall switch. Once installed and powered, simply use the wall switch connected to the fixture to turn the light on or off.

6. Maintenance

- **Cleaning:** To clean the fixture, first ensure the power is off. Use a soft, dry, lint-free cloth to wipe the metal and glass surfaces. Do not use liquid or abrasive cleaners, as they may damage the finish.
- **Bulb Replacement:**
    - **IMPORTANT:** Always turn off the power supply at the circuit breaker and allow the bulb to cool completely before attempting to replace it.
    - Carefully unscrew the old E27 bulb from the lamp holder.
    - Screw in a new E27 bulb, ensuring it does not exceed the maximum 60W rating.
    - Restore power.

7. Troubleshooting

- **Light does not turn on:**
    - Check if the power supply is on at the main circuit breaker.
    - Ensure the bulb is correctly screwed in and not faulty. Try a new bulb.
    - Verify all electrical connections are secure. If unsure, consult a qualified electrician.
- **Light flickers:**

- Ensure the bulb is fully tightened.
- Check for loose wiring connections.
- The bulb itself might be faulty or incompatible with the dimmer switch (if one is used).

8. Specifications

Brand	ActiveJet
Model Name	Foco Nikita 1P
Item Model Number	OSWACJKIN0105
Material	Nickel
Light Source Type	E27 (Incandescent, LED compatible)
Max Wattage	60 Watts
Voltage Frequency	220 to 240 Volts and 50 Hertz
Product Dimensions	1 x 1 x 1 cm; 273 g
Item Package Quantity	1
IP Rating	IP20 (Indoor use only)

9. Warranty and Support

This ActiveJet product is covered by a standard manufacturer's warranty. Please refer to your purchase documentation for specific warranty terms and duration. For technical support, replacement parts, or warranty claims, please contact your retailer or ActiveJet customer service through their official website.
Please note: Any unauthorized modification or incorrect installation of the product will void the warranty.

© 2023 ActiveJet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B3V6GM4Z

More documents and user manuals: **https://manuals.plus/**