Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Grunkel MWG-20INOX

Grunkel MWG-20INOX Microwave with Grill

User Instruction Manual

1. Introduction

Thank you for choosing the Grunkel MWG-20INOX Microwave with Grill. This appliance is designed for convenient and efficient cooking, reheating, and defrosting of various foods. Please read this manual carefully before operating the microwave oven to ensure proper use, safety, and optimal performance. Keep this manual for future reference.



Figure 1.1: Front view of the Grunkel MWG-20INOX Microwave with Grill, showcasing its stainless steel finish and control panel.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not operate the oven if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
- Do not heat liquids or other foods in sealed containers since they are liable to explode.
- Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- Use only utensils that are suitable for use in microwave ovens.
- When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.
- If smoke is observed, switch off or unplug the appliance and keep the door closed in order to stifle any flames.
- Cleaning and user maintenance shall not be made by children without supervision.
- The microwave oven is intended for heating food and beverages. Drying of clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.
- The appliance should not be cleaned with a steam cleaner.

3. Components and Features

The Grunkel MWG-20INOX microwave oven comes with the following main components:

- Microwave Oven Unit
- Glass Turntable (255 mm)
- Turntable Ring Assembly
- Grill Rack (for grill function)
- Control Panel with Power Level Selector and Timer Dial



Figure 3.1: Detailed view of the control panel, showing the power and timer dials, and the interior of the microwave.

Key Features:

- **20 Liter Capacity:** Sufficient internal volume for various food items.
- **5 Power Levels:** Offers flexibility for different cooking needs.
- **3 Combination Levels:** Combines microwave and grill functions for versatile cooking.
- **800 W Grill Power:** Dedicated grill function for browning and crisping.
- **255 mm Glass Turntable:** Ensures even cooking and accommodates standard dishes.
- **Adjustable Timer (up to 35 minutes):** Allows precise cooking times.
- **Defrost Function:** Quickly thaws frozen foods.

4. Setup and Installation

1. **Unpacking:** Carefully remove the microwave oven and all packing materials. Check for any damage. Do not operate if damaged.
2. **Placement:** Place the microwave on a flat, stable surface that can support its weight. Ensure there is adequate ventilation space around the unit: at least 20 cm (7.9 inches) above, 10 cm (3.9 inches) at the rear, and 5 cm (2 inches) on each side. Do not block air vents.
3. **Power Connection:** Ensure the power outlet matches the voltage specified on the microwave's rating label. Plug the microwave into a grounded electrical outlet.
4. **Turntable Assembly:** Place the turntable ring assembly in the center of the oven cavity. Then, place the glass turntable securely on top of the ring. Ensure it rotates freely.



Figure 4.1: Diagram illustrating the dimensions of the Grunkel MWG-20INOX microwave, including required clearance for proper ventilation.

5. Operating Instructions

The Grunkel MWG-20INOX features two main control dials: one for power/function selection and one for the timer.



Figure 5.1: View of the microwave with the door open, showing the interior cavity and the control panel on the right.

5.1. Basic Microwave Operation

1. Place food in a microwave-safe container on the glass turntable.
2. Close the oven door securely.
3. **Select Power Level:** Turn the upper dial (POTENCIA) to choose the desired power level:
    - **Baja (Low):** For softening butter, thawing.
    - **Med (Medium):** For simmering, more delicate cooking.
    - **M. Alta (Medium-High):** For general cooking and reheating.
    - **Alta (High):** For fast cooking and boiling.
4. **Set Cooking Time:** Turn the lower dial (TIEMPO) to set the desired cooking time, up to 35 minutes. The microwave will start automatically once the timer is set.

5. When the set time expires, the oven will automatically stop and a bell will sound.

5.2. Grill Function

The grill function is ideal for browning and crisping food. Use the included grill rack for best results.

1. Place food on the grill rack, then place the rack on the glass turntable.
2. Close the oven door.
3. **Select Grill Function:** Turn the upper dial (POTENCIA) to 'Grill'.
4. **Set Cooking Time:** Turn the lower dial (TIEMPO) to set the desired grilling time.
5. Monitor food closely to prevent over-browning.

5.3. Combination Cooking

The microwave offers three combination settings (Combi1, Combi2, Combi3) that combine microwave power with grill heat for faster and more versatile cooking.

- **Combi1:** 30% Microwave, 70% Grill - Ideal for fish, potatoes, or gratin.
- **Combi2:** 55% Microwave, 45% Grill - Suitable for poultry, meat, or casseroles.
- **Combi3:** 70% Microwave, 30% Grill - Best for quick cooking of vegetables or small meat portions.

1. Place food in a suitable container (microwave and grill safe).
2. Close the oven door.
3. **Select Combination Function:** Turn the upper dial (POTENCIA) to 'Combi1', 'Combi2', or 'Combi3'.
4. **Set Cooking Time:** Turn the lower dial (TIEMPO) to set the desired cooking time.

5.4. Defrost Function

The defrost function allows for quick and efficient thawing of frozen foods.

1. Place frozen food in a microwave-safe container on the turntable.
2. Close the oven door.
3. **Select Defrost:** Turn the upper dial (POTENCIA) to the defrost symbol (snowflake).
4. **Set Defrost Time:** Turn the lower dial (TIEMPO) to set the desired defrosting time. The time required will vary based on the food's weight and type.
5. During defrosting, it is recommended to turn the food over periodically to ensure even thawing.

6. Care and Cleaning

Regular cleaning of your microwave oven will help maintain its performance and extend its lifespan.

- **Interior Cleaning:** After each use, wipe the interior with a damp cloth and mild detergent. For stubborn stains, place a bowl of water with lemon slices inside and microwave for 2-3 minutes to loosen residue, then wipe clean.
- **Exterior Cleaning:** Clean the exterior surface with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals.
- **Turntable and Ring:** The glass turntable and turntable ring can be removed and washed in warm, soapy water or in

a dishwasher. Ensure they are completely dry before placing them back in the oven.

- **Door Seal:** Keep the door seal and adjacent parts clean. Use a soft cloth to wipe away any food spills.
- Always unplug the microwave from the power outlet before cleaning.

7. Troubleshooting

If you encounter issues with your microwave, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Fuse blown or circuit breaker tripped; Door not closed properly.	Plug into outlet; Replace fuse or reset circuit breaker; Close door securely.
Food not cooking evenly	Food not stirred or turned; Improper power level or cooking time.	Stir or turn food during cooking; Adjust power level and time.
Excessive steam inside oven	High moisture content in food.	This is normal for foods with high moisture. Wipe interior after use.
Turntable not rotating	Turntable not properly placed; Food too large or heavy.	Ensure turntable and ring are correctly positioned; Reduce food quantity or size.

If the problem persists after trying these solutions, please contact customer support.

8. Technical Specifications

Specification	Value
Brand	Grunkel
Model	MWG-20INOX (also listed as MW-20INOX)
Color	Stainless Steel
Product Dimensions (L x W x H)	45 x 35 x 26.2 cm (17.7 x 13.8 x 10.3 inches)
Capacity	20 Liters
Microwave Power	700 Watts
Grill Power	800 Watts
Voltage	230 Volts
Material	Stainless Steel

Specification	Value
Special Features	Defrost Function
Item Weight	10.5 Kilograms (23.1 lbs)
Glass Turntable Diameter	255 mm
Installation Type	Countertop

9. Warranty and Support

Grunkel products are manufactured to high-quality standards. For information regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official Grunkel website. For technical assistance, troubleshooting beyond this manual, or spare parts, please contact Grunkel customer support through the contact information provided on the product packaging or website.

© 2024 Grunkel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B46FJ3J3

More documents and user manuals: **https://manuals.plus/**