Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bitty Boomers BITTYRVADER

Bitty Boomers Star Wars: Darth Vader Mini Bluetooth Speaker User Manual

Model: BITTYRVADER

1. Introduction

Thank you for choosing the Bitty Boomers Star Wars: Darth Vader Mini Bluetooth Speaker. This ultra-portable speaker delivers powerful sound in a compact design, allowing you to enjoy your music anywhere. This manual provides essential information for the safe and efficient use of your device.

Image 1.1: Front view of the Darth Vader Mini Bluetooth Speaker. The speaker is shaped like Darth Vader's helmet, holding a red lightsaber.

2. What's in the Box

- Bitty Boomers Star Wars: Darth Vader Mini Bluetooth Speaker
- Micro USB Charging Cable
- Lanyard/Strap

3. Product Overview

The Bitty Boomers speaker features a single multi-function button for power and Bluetooth pairing, and a micro USB port for charging.



Image 3.1: Side view of the Darth Vader Mini Bluetooth Speaker, showing its compact, rounded profile.

4. Setup

4.1 Charging the Speaker

1. Locate the Micro USB port on the back of the speaker.
2. Connect the small end of the included Micro USB cable to the speaker's charging port.
3. Connect the larger USB end of the cable to a USB power source (e.g., computer USB port, USB wall adapter).
4. The LED indicator (if present, typically near the charging port) will illuminate during charging and turn off or change color when fully charged.

5. A full charge typically takes 1-2 hours and provides over 4 hours of music playback.



Image 4.1: Back view of the Darth Vader Mini Bluetooth Speaker, highlighting the Micro USB charging port at the bottom.

4.2 Powering On/Off

- **To Power On:** Press and hold the multi-function button (usually located on the base or back of the speaker) for approximately 2-3 seconds until you hear an audible tone or see the LED indicator light up.
- **To Power Off:** Press and hold the multi-function button again for approximately 3-4 seconds until you hear an audible tone or the LED indicator turns off.

4.3 Bluetooth Pairing

1. Ensure the speaker is fully charged and powered off.
2. Power on the speaker (as described in 4.2). The speaker will automatically enter pairing mode, indicated by a flashing LED light and/or an audible prompt.
3. On your Bluetooth-enabled device (smartphone, tablet, computer), go to the Bluetooth settings.
4. Search for available devices. You should see

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B47X44XK

More documents and user manuals: **https://manuals.plus/**