Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mattel HLW56

Mattel Disney Frozen Singing Anna Doll Instruction Manual

Introduction

Welcome to the world of Disney's Frozen with your new Mattel Singing Anna Doll! This doll is designed to bring joy and musical fun, singing a clip from Anna's signature song, "For the First Time in Forever." Please read this manual carefully to ensure proper setup, operation, and care of your doll.

What's Included

- 1 x Mattel Disney Frozen Singing Anna Doll (wearing removable fashion and accessories)

Setup

1. Unboxing the Doll

Carefully remove the doll from its packaging. Ensure all ties and fasteners are detached before attempting to remove the doll. Retain packaging for future reference.



Image: The Mattel Disney Frozen Singing Anna Doll as it appears in its retail packaging.

2. Battery Installation

The doll requires 3 LR44 batteries, which are included. The battery compartment is located on the back of the doll. Use a small Phillips head screwdriver to open the compartment, insert the batteries according to the polarity markings, and securely close the compartment. If the doll is in 'Try Me' mode, locate and remove the plastic pull-tab from the battery compartment area to enable full functionality.

Operating the Singing Feature

To activate the doll's singing feature, press the button located on the doll's bodice. Anna will sing a 30-second clip of "For the First Time in Forever" in English.



Image: A close-up of the Anna doll's bodice, showing the button to press for the singing feature.

Your browser does not support the video tag.

Video: Official product demonstration of the Mattel Disney Frozen Singing Anna Doll, showcasing its singing feature.

Maintenance

1. Cleaning the Doll

Wipe the doll's body with a damp cloth. Do not immerse the doll in water, as this may damage the electronic components. For the doll's hair, gently brush with a soft brush. Avoid harsh chemicals or abrasive cleaners.





Image: A detailed view of the Anna doll's face and hair, highlighting her authentic hairstyle.

2. Clothing Care

The doll's skirt is removable. Hand wash the fabric skirt with mild soap and cold water if necessary, then air dry. Do not machine wash or tumble dry.



Image: A close-up of the Anna doll's upper body, showing the details of her bodice and the top of her removable skirt.

Troubleshooting

Doll Not Singing or Singing Short Clips

- **Check Batteries:** Ensure batteries are correctly installed and not depleted. Replace with fresh LR44 batteries if needed.

- **Remove Demo Tab:** If the doll is new, verify that the plastic 'Try Me' tab has been completely removed from the battery compartment area.
- **Button Activation:** Make sure the button on the bodice is pressed firmly.

If issues persist after following these steps, please contact Mattel customer support.

Specifications

Feature	Detail
Product Dimensions	1.97 x 3.15 x 11.81 inches
Item Weight	4.8 ounces
Model Number	HLW56
Manufacturer Recommended Age	3 years and up
Batteries	3 LR44 batteries required (included)
Language	English
Manufacturer	Mattel

Important Safety Information

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

- Always supervise young children during play.
- Do not attempt to modify the doll or its components.
- Dispose of used batteries responsibly.

Warranty and Support

For warranty information, product support, or to contact customer service, please visit the official Mattel website or refer to the contact details provided on the product packaging. Keep your proof of purchase for any warranty claims.
You can visit the Mattel Store for more products and information:Mattel Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B47XH93M

More documents and user manuals: **https://manuals.plus/**