Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Maxxima MEL-6150DW

Maxxima Luvoni WiFi LED Outdoor Wall Light

USER MANUAL

Introduction

This manual provides essential information for the safe installation, operation, and maintenance of your Maxxima Luvoni WiFi LED Outdoor Wall Light. Please read this manual thoroughly before installation and retain it for future reference.



The Maxxima Luvoni WiFi LED Outdoor Wall Light, a smart outdoor fixture with app and voice control capabilities.

Safety Information

WARNING: Risk of electric shock. Installation should be performed by a qualified electrician or a person familiar with the construction and operation of the product and the hazards involved. Disconnect power at the fuse or circuit breaker before installing or servicing.

- Ensure the supply voltage is correct (120 VAC).
- Do not attempt to modify the fixture.
- Do not connect to a dimmer switch; dimming is controlled via the app.
- This fixture is suitable for wet locations.

Package Contents

Verify that all components are present before beginning installation:

- 1x Maxxima Luvoni WiFi LED Outdoor Wall Light Fixture

- Mounting Hardware
- Instruction Manual (this document)

Setup

1. Installation

This fixture is designed for wall-mount installation. For detailed electrical wiring instructions, refer to the included installation guide or consult a qualified electrician. Ensure power is OFF at the circuit breaker before proceeding.

1. Turn off power at the main circuit breaker.
2. Attach the mounting bracket to the junction box using the provided screws.
3. Connect the fixture wires to the house wires: black to black (live), white to white (neutral), and ground to ground. Secure connections with wire nuts.
4. Carefully tuck all wires into the junction box.
5. Align the fixture with the mounting bracket and secure it with the provided screws.
6. Restore power at the circuit breaker.



The Maxxima Luvoni light fixture installed on an exterior wall.



Dimensions of the fixture: approximately 11.5 inches high and 7.75 inches deep from the wall.

2. App Connection

The Maxxima Luvoni light is controlled via the TuyaSmart app. No separate hub is required.

1. **Download the App:** Scan the QR code below or search for "TuyaSmart" in your mobile device's app store. You can also visit smartapp.tuya.com/tuyasmart or maxximastyle.com/wifi-app-download.
2. **Register/Log In:** Open the TuyaSmart app and create an account or log in if you already have one.
3. **Add Device:** Ensure your phone is connected to a 2.4GHz Wi-Fi network. Power on the light fixture. In the app, tap "+" to add a device. Select "Lighting" then "Light Source (Wi-Fi)".
4. **Pairing Mode:** The light should blink rapidly to indicate pairing mode. If not, turn the light switch OFF-ON-OFF-ON-OFF-ON (3 times) to reset it into pairing mode.
5. **Connect:** Follow the in-app instructions to connect the light to your Wi-Fi network.



The light supports 16 million colors, is WiFi enabled, and works with Google Assistant and Amazon Alexa. Scan the QR code to download the app.

Operating Instructions

1. App Control

Once connected, you can control your light fixture using the TuyaSmart app:

- **On/Off:** Toggle the light on or off.
- **Brightness:** Adjust dimming from 20% to 100%. (*Note: This fixture is not compatible with external dimmer switches.*)
- **Color Temperature (CCT):** Change the white light from warm (2700K) to cool (6500K).
- **Color Selection:** Choose from a full spectrum of 16 million colors.
- **Scheduling:** Set schedules for the light to turn on/off, dim, or change color at specific times.
- **Grouping:** Control multiple Maxxima smart lights individually or as a group within the app.



The app interface allows adjustment of brightness and color temperature.



The light can be controlled via the Smart Life or TuyaSmart app, works with Google Assistant and Alexa, and offers 16 million colors.

2. Voice Control

The Maxxima Luvoni light is compatible with Amazon Alexa and Google Assistant. To enable voice control:

1. **Link Account:** In your Alexa or Google Home app, enable the "TuyaSmart" skill/service and link your TuyaSmart account.
2. **Discover Devices:** Ask your voice assistant to "Discover devices" or manually add the light.
3. **Voice Commands:** You can now use commands such as:
    - "Alexa, turn on [Light Name]"
    - "Hey Google, set [Light Name] to 50%"
    - "Alexa, change [Light Name] to blue"

Your browser does not support the video tag.

Official product video demonstrating the smart features of the Maxxima WiFi LED Outdoor Wall Light, including brightness and color changes via app control.

Maintenance

To ensure optimal performance and appearance of your outdoor wall light:

- **Cleaning:** Periodically clean the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish or glass.
- **Inspection:** Annually inspect the fixture for any signs of damage, loose connections, or wear.
- **LEDs:** The LED light source is integrated and not user-replaceable.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power; loose wiring; fixture not properly installed.	Check circuit breaker; ensure all wire connections are secure; verify installation steps.
Light is not connecting to Wi-Fi.	Incorrect Wi-Fi band (5GHz); incorrect password; light not in pairing mode.	Ensure phone is on 2.4GHz Wi-Fi; re-enter password; reset light to pairing mode (OFF-ON 3 times).
App control is unresponsive.	Poor Wi-Fi signal; app issue; device offline.	Check Wi-Fi signal strength; restart app; power cycle the light fixture.
Voice control not working.	Account not linked; device not discovered; incorrect commands.	Verify TuyaSmart skill is enabled and linked in Alexa/Google Home app; rediscover devices; use correct device name.

Specifications

Model Number	MEL-6150DW
Brand	Maxxima
Power Source	Corded Electric
Voltage	120 VAC
Wattage	11 Watts
Brightness	850 Lumens
Color Temperature (CCT)	2700K - 6500K
Color Options	16 Million Colors
Dimming Range	20% - 100% (App Controlled)
Connectivity	Wi-Fi (2.4GHz)
Control Method	App, Voice (Alexa, Google Assistant)
Material	Aluminum
Dimensions (H x D)	Approximately 11.5" H x 7.75" D
Item Weight	2 pounds
Indoor/Outdoor Usage	Outdoor (Wet Location Rated)

Certifications	ETL, FCC

Warranty

This Maxxima product comes with a**3-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For warranty claims or further details, please contact Maxxima customer support.

Support

For technical assistance, troubleshooting, or warranty inquiries, please visit the official Maxxima website or contact their customer service department.
Maxxima Official Store: Visit Maxxima Store on Amazon
For additional support, refer to the contact information provided on the Maxxima packaging or their official website.

© 2023 Maxxima. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4KL7N4F

More documents and user manuals: **https://manuals.plus/**