TOKIT C2

TOKIT Omni Cook C2 Smart Cooking Robot User Manual

Model: C2

1. Introduction

The TOKIT Omni Cook C2 is an advanced smart cooking robot designed to simplify and enhance your culinary experience. This all-in-one kitchen appliance integrates 21 functions, including blending, stirring, frying, steaming, chopping, and cutting, to automate various cooking processes. Featuring a user-friendly touchscreen and Wi-Fi connectivity for access to a vast recipe library, the Omni Cook C2 aims to bring efficiency and precision to your kitchen.



Image: The TOKIT Omni Cook C2, a smart cooking robot, shown with its main unit and a smartphone interface displaying various recipes.

2. Safety Information

Please read all safety instructions carefully before using the TOKIT Omni Cook C2 to prevent injury or damage to the appliance. Keep this manual for future reference.

- Always ensure the appliance is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the main unit in water or any other liquid.
- Keep hands and utensils away from moving blades during operation.
- Ensure the lid is properly secured before starting any function. The built-in lid detection system locks the machine for safety.
- Use only TOKIT-approved accessories and parts.
- Unplug the appliance from the power outlet when not in use, before cleaning, or during assembly/disassembly.
- Exercise caution when handling hot liquids or steam.

- The appliance is made of temperature-resistant and food-grade materials.

3. Product Overview

3.1 Key Features

- **All-in-One Functionality:** Combines 21 cooking functions including blending, stirring, frying, steaming, chopping, and cutting.
- **Smart Touchscreen:** Intuitive 7-inch touchscreen for step-by-step guidance, ingredient lists, and precise control.
- **AI-Powered Cooking:** Equipped with a COOKINGIOT heating control chip for integrated heating, stirring, weighing, and automatic control.
- **Extensive Recipe Library:** Access to over 3000 free online recipes with weekly updates via Wi-Fi.
- **Custom Recipe Creation:** Ability to design, save, and share your own unique recipes.
- **Powerful Motor:** Features a 40–12000 RPM motor and durable stainless steel blade for versatile processing.
- **Self-Cleaning Mode:** Pre-clean function for easy residue removal.



Image: The TOKIT Omni Cook C2 highlighting its 21 integrated cooking functions, such as blending, steaming, and chopping.

3.2 Components and Accessories

The TOKIT Omni Cook C2 comes with several essential components and accessories to facilitate its various functions. Familiarize yourself with each part before use.



Image: A detailed view of the TOKIT Omni Cook C2's accessories, including the simmering basket, whisk, scraper, tea spoon set, and measuring cup.

- **Main Unit:** The base of the appliance housing the motor, heating element, and touchscreen.
- **Mixing Bowl:** The primary container for processing ingredients.
- **Blade Set:** Durable stainless steel blades for chopping, blending, and mixing.
- **Lid:** Secures the mixing bowl during operation, with a built-in safety lock.
- **Measuring Cup:** Used for measuring ingredients and sealing the lid opening.
- **Whisk:** Attachment for whipping cream or beating eggs.
- **Scraper:** Tool for cleaning food from the inner wall of the mixing bowl.
- **Simmering Basket:** For steaming food, processing fragile ingredients, or filtering juices.
- **Tea Spoon Set:** For precise measurement of liquid or powder ingredients.
- **Blade Cover:** Used to cover the blades for gentle stirring or slow cooking.
- **Slow-cook Plug:** An accessory for specific slow-cooking functions.

4. Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wash all removable parts (mixing bowl, lid, blades, accessories) with warm soapy water. Rinse thoroughly and dry completely. The main unit can be wiped with a damp cloth.
3. **Placement:** Place the main unit on a clean, dry, stable, and heat-resistant surface, ensuring adequate ventilation around the appliance.
4. **Assembly:** Insert the blade set into the mixing bowl. Place the mixing bowl securely onto the main unit. Attach the lid firmly.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet. The appliance will power on and display the initial setup screen.
6. **Initial Setup:** Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your user profile.

5. Operating Instructions

5.1 Using the Smart Touchscreen

The 7-inch touchscreen is your primary interface for controlling the Omni Cook C2. It provides clear, step-by-step instructions for all cooking processes.



Image: The TOKIT Omni Cook C2's ergonomic touchscreen, showing an example of a recipe with clear instructions and controls.

- **Navigation:** Swipe left/right or tap icons to navigate through menus and recipe categories.
- **Selection:** Tap on a recipe or function to select it.
- **Controls:** Adjust settings like time, temperature, and speed using the on-screen controls or the physical dial.

5.2 Accessing and Using Recipes

The Omni Cook C2 offers access to a vast library of recipes, updated weekly via Wi-Fi.



Image: The TOKIT Omni Cook C2 demonstrating its connectivity to a large library of recipes, offering endless cooking possibilities.

1. **Browse Recipes:** From the home screen, select the "Recipes" option to browse categories or search for specific dishes.
2. **Select Recipe:** Tap on a desired recipe. The screen will display ingredients, preparation steps, and estimated cooking time.
3. **Start Cooking:** Follow the on-screen instructions, adding ingredients as prompted. The machine will automatically adjust temperature, speed, and time according to the recipe.

5.3 Creating Custom Recipes

You can create and save your own unique recipes directly on the Omni Cook C2.



Image: The TOKIT Omni Cook C2 illustrating the feature to create, import, and modify personalized recipes.

1. **Access Creation Mode:** Navigate to the "My Creations" section on the touchscreen.
2. **Input Details:** Enter recipe name, ingredients, and step-by-step instructions. You can manually set cooking parameters like temperature, time, and speed for each step.
3. **Save and Share:** Save your recipe. It will be available for future use and can be shared with family members or other users.

6. Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your TOKIT Omni Cook C2.

6.1 Self-Cleaning Mode

The Omni Cook C2 features a convenient pre-clean mode to easily remove stubborn food residues.



Image: The TOKIT Omni Cook C2 demonstrating its self-cleaning mode, where water swirls to remove food residues.

1. After cooking, add water and a few drops of concentrated lemonade or mild dish soap to the mixing bowl.
2. Select the "Pre-clean" or "Self-cleaning" mode from the touchscreen.
3. Allow the cycle to complete.
4. Empty the bowl, rinse thoroughly, and wipe clean.

6.2 Manual Cleaning

- All accessories are made without PFOA and are dishwasher-safe.
- For manual cleaning, disassemble the mixing bowl, blades, and other removable accessories.
- Wash with warm, soapy water using a non-abrasive sponge or brush.
- Rinse all parts thoroughly under running water.
- Dry all components completely before reassembly or storage to prevent water spots or mineral buildup.
- Wipe the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.

7. Troubleshooting

If you encounter issues with your TOKIT Omni Cook C2, refer to the following common troubleshooting tips. For persistent problems, contact customer support.

Problem	Possible Cause	Solution
Appliance does not power on.	Not plugged in; power outlet issue; main unit not properly assembled.	Ensure power cord is securely plugged into a working outlet. Check if the mixing bowl and lid are correctly assembled and locked.
Motor not running or weak.	Overload; improper assembly; safety lock engaged.	Reduce ingredient quantity. Ensure all parts are correctly assembled. Check if the lid is fully closed and locked.
Touchscreen unresponsive.	Temporary software glitch; power cycle needed.	Unplug the appliance for 30 seconds, then plug it back in. If the issue persists, contact customer support.
Wi-Fi connection issues.	Incorrect password; weak signal; router issues.	Verify Wi-Fi password. Move the appliance closer to the router. Restart your router.

8. Specifications

Brand: TOKIT

Model Name: C2

Product Dimensions: 14"D x 9"W x 13.99"H

Item Weight: 15 pounds

Color: Black

Bowl Capacity: 2.2 Liters

Number of Speeds: 10

Blade Material: Stainless Steel

Special Features: Auto Shut Off, Built-In Grinder, Ice Crushing, Safety Lock

Care Instructions: Dishwasher Safe (accessories)

Manufacturer: TOKIT

First Available Date: June 23, 2022

9. Warranty and Support

For warranty information, product support, or to download the full user manual, please refer to the official TOKIT website or the provided PDF document.

Official User Manual (PDF): Download PDF

For further assistance, please contact TOKIT customer service.

© 2024 TOKIT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question