Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOLDEN HOUR GH-1313P

GOLDEN HOUR Ultra-Thin Minimalist Sports Waterproof Digital Watch GH-1313P Instruction Manual

Model: GH-1313P

Setup **Operation** **Maintenance** **Troubleshooting** **Specifications** **Warranty & Support**

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your GOLDEN HOUR Ultra-Thin Minimalist Sports Waterproof Digital Watch (Model GH-1313P). Please read this manual thoroughly to ensure proper use and longevity of your watch.



Image: The GOLDEN HOUR Ultra-Thin Minimalist Sports Waterproof Digital Watch, black resin model.

Setup

Button Functions

Your watch features four buttons for various functions:

- **LIGHT:** Activates the EL backlight for improved visibility in low light conditions.
- **MODE:** Cycles through different watch modes (Time, Stopwatch, Alarm, Date Setting).
- **ST/STOP:** Used to start/stop functions in Stopwatch mode and adjust values in setting modes.
- **RESET:** Used to reset values in Stopwatch mode and confirm selections in setting modes.

Setting Time and Date

To set the correct time and date on your watch:

1. Press the **MODE** button three times to enter the time setting mode. The seconds display will begin to flash.
2. Press the **ST/STOP** button to cycle through the adjustable settings: seconds, minutes, hours (12/24H format), month, date, and day of the week.
3. While a setting is flashing, use the **RESET** button to adjust the value. Hold the **RESET** button to quickly advance the numbers.
4. Once all settings are correct, press the **MODE** button again to exit the setting mode and return to the normal time display.



Image: Close-up of the watch display showing the time and date, highlighting its easy readability.

Operation

Time Display (12/24H)

The watch displays time in either 12-hour or 24-hour format. This setting can be adjusted within the time setting mode (refer to "Setting Time and Date").

EL Backlight

Press the **LIGHT** button to illuminate the display. The EL backlight provides clear visibility in dark environments.



Image: The watch display illuminated by its EL backlight, showing clear visibility in dim conditions.

Stopwatch Function

1. From the normal time display, press the**MODE** button once to enter Stopwatch mode. The display will show "00:00:00".
2. Press the **ST/STOP** button to start the stopwatch.
3. Press the **ST/STOP** button again to pause the stopwatch.
4. Press the **RESET** button to reset the stopwatch to zero.
5. Press the **MODE** button to exit Stopwatch mode.

Alarm Function

1. From the normal time display, press the**MODE** button twice to enter Alarm mode.
2. Use the **ST/STOP** button to select the hour or minute to set.

3. Use the **RESET** button to adjust the flashing value.
4. Press the **MODE** button to exit Alarm setting mode.
5. To activate/deactivate the alarm, press the **ST/STOP** and **RESET** buttons simultaneously in Alarm mode. An alarm icon will appear/disappear.

Water Resistance (5ATM / 50M)

The watch is rated 5ATM (50 meters) water resistant. This means it is suitable for swimming in shallow water and cold showering. It is *not* suitable for diving, snorkeling, or prolonged underwater activities. Avoid exposure to hot water or steam, as this can compromise the water resistance seals.



Image: The GOLDEN HOUR watch partially submerged in water, illustrating its 5ATM water resistance.

Maintenance

General Care

- Clean the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by

drying.

- Avoid exposing the watch to extreme temperatures, direct sunlight for extended periods, or strong magnetic fields.
- Do not press buttons underwater to maintain water resistance.
- Avoid contact with chemicals such as solvents, detergents, perfumes, and cosmetics, as they may damage the watch case or strap.

Battery Replacement

The watch uses 1 Nonstandard Battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance seal is properly maintained.



Image: The stainless steel back case of the GOLDEN HOUR watch, indicating its construction.

Troubleshooting

Problem	Possible Cause	Solution
Display is dim or blank.	Low battery.	Replace the battery.
Time is incorrect.	Time not set properly or accidental button press.	Refer to "Setting Time and Date" section to reset the time.
Watch beeps with every button press, and sound cannot be turned off.	This model does not feature a silent mode for button presses.	This is a characteristic of the watch. No user adjustment is available for button press sounds.
Watch is in an unexpected mode (e.g., Stopwatch) and difficult to return to time display.	Requires cycling through modes.	Press the **MODE** button repeatedly until the desired mode (e.g., Time) is displayed. There is no quick return function.
Water appears inside the watch or display fogs up.	Water resistance compromised (e.g., exposure to hot water, buttons pressed underwater).	Immediately take the watch to a professional watch repair service. Do not attempt to open the watch yourself.

Specifications

Feature	Detail

Feature	Detail
Model Number	GH-1313P
Brand	GOLDEN HOUR
Display Type	Digital
Watch Movement Type	Japanese Quartz
Case Material	Plastic
Case Diameter	43 Millimeters
Case Thickness	0.31 Inches (approx. 8mm)
Band Material Type	Rubber
Band Width	0.86 Inches
Band Length	9.84 Inches (Adjustable, fits 160mm-240mm wrist circumference)
Clasp Type	Pin buckle
Water Resistance Depth	50 Meters (5ATM)
Power Source	Battery Powered (1 Nonstandard Battery required)
Additional Features	Alarm, Glow In The Dark (EL Backlight), Stopwatch, Date, Day
Item Weight	2.4 ounces (approx. 68g)



Image: Technical diagram illustrating the dimensions and weight of the GOLDEN HOUR watch.



Image: Diagram showing the adjustable wearing size range of the watch strap (160mm-240mm).

Warranty & Support

Warranty Information

Your GOLDEN HOUR watch comes with a Lifetime Warranty. This warranty covers manufacturing defects under normal use. Please retain your purchase receipt as proof of purchase.
Additionally, GOLDEN HOUR offers a 12-month after-service period for any questions or issues you may encounter with your watch.

Customer Support

For any inquiries, technical assistance, or warranty claims, please contact GOLDEN HOUR customer support through the retailer where the product was purchased or visit the official GOLDEN HOUR website for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4V76LFG

More documents and user manuals: **https://manuals.plus/**