Dyson SV30

Dyson V12 Detect Slim Cordless Vacuum Instruction Manual

Model: SV30

Product Overview

The Dyson V12 Detect Slim is Dyson's lightest intelligent cordless vacuum. It combines powerful suction with advanced features for a thorough clean, designed to reveal microscopic dust and debris.



The image displays the Dyson V12 Detect Slim main unit, long wand, Fluffy Optic cleaner head with green laser illumination, and several accessory tools including the Anti-tangle hair screw tool, Combination tool, and Crevice tool.

Included Components

Your Dyson V12 Detect Slim comes with the following components:

- Dyson V12 Detect Slim Cordless Vacuum Cleaner (Main Body)
- Fluffy Optic cleaner head
- De-tangling Motorbar cleaner head
- Wand
- Docking station
- Charger
- Anti-tangle hair screw tool

- Combination tool
- Crevice Tool
- Wand clip

These components allow for versatile cleaning across different surfaces and hard-to-reach areas.

Setup

Initial Charging

Before first use, fully charge your Dyson V12 Detect Slim. The vacuum comes with a wall-mounted charging dock for convenient storage and charging.

Your browser does not support the video tag.

This video demonstrates how to store the Dyson V12 Detect Slim on its wall-mounted charging dock, highlighting its compact storage and continuous charging capability.

Assembly

Attach the desired cleaning head or accessory to the wand, then connect the wand to the main vacuum body. Ensure all connections click securely into place.

Your browser does not support the video tag.

This video shows the unboxing and initial assembly of the Dyson V12 Detect Slim, demonstrating how to connect the wand and various cleaning heads to the main unit.

Operating Instructions

Power On/Off and Mode Selection

The Dyson V12 Detect Slim features a push-button power control. Press the red button on the main body to turn the vacuum on or off. Use the button on the LCD screen to cycle through power modes: Eco, Auto, and Boost.

Your browser does not support the video tag.

This video illustrates the power button and mode selection on the Dyson V12 Detect Slim, showing how to switch between Eco, Auto, and Boost modes for different cleaning needs.

Laser Illumination

The Fluffy Optic cleaner head features a green laser that illuminates microscopic dust on hard floors, making invisible dust visible for a more thorough clean.

Your browser does not support the video tag.

This video showcases the laser illumination feature of the Fluffy Optic cleaner head, demonstrating its effectiveness in revealing hidden dust on hard floor surfaces.

LCD Screen Display

The integrated LCD screen provides real-time performance updates, including remaining run time, current power mode,

and a visual representation of the size and quantity of dust particles picked up.

Your browser does not support the video tag.

This video highlights the interactive LCD screen, showing how it displays real-time data on battery life, power mode, and the types of particles being collected.

Using Attachments

The vacuum comes with various attachments for different cleaning tasks. Simply click the desired tool directly onto the main body for handheld cleaning or onto the wand for extended reach.

Your browser does not support the video tag.

This video demonstrates the versatility of the Dyson V12 Detect Slim with various attachments, including the Anti-tangle hair screw tool for effective pet hair removal on upholstery.

Maintenance

Emptying the Dustbin

To empty the dustbin, hold the vacuum over a bin and push the red lever forward. Ensure the wand is detached first to prevent accidental spills. The dustbin capacity is 0.1 Gallons.

Your browser does not support the video tag.

This video demonstrates the simple process of emptying the dustbin on the Dyson V12 Detect Slim, ensuring hygienic disposal of collected debris.

Filter Maintenance

The vacuum features a lifetime washable filter. For optimal performance, regularly check and clean the filter according to the instructions provided in the full user manual. Ensure the filter is completely dry before reinserting.

Troubleshooting

Issue	Possible Cause	Solution
No power/Not turning on	Battery not charged; Power button not pressed correctly	Ensure battery is fully charged. Press the red power button firmly.
Low suction power	Dustbin full; Filter clogged; Blockage in cleaner head/wand	Empty dustbin. Wash and dry filter. Check for and clear any blockages.
Brush bar not spinning	Blockage in brush bar; Incorrect mode selected	Clear any hair or debris from the brush bar. Ensure vacuum is not in Eco mode on carpets.
Short run time	Using Boost mode; Battery degradation	Use Eco or Auto mode for longer run time. Consider purchasing an additional battery.

For more complex issues, please refer to the full user manual or contact Dyson customer support.

Specifications

Feature	Detail
Brand	Dyson
Model Name	V12 Detect Slim
Model Number	SV30
Special Feature	Laser illumination, Cordless, LCD screen display
Filter Type	Lifetime washable
Capacity	0.1 Gallons
Wattage	150 watts
Runtime	1 hour (Eco mode)
Charging Time	3 Hours
Item Weight	5.2 pounds
Product Dimensions	49.6"L x 9.8"W x 10.5"H
Noise Level	82 dB
Recommended Uses	Carpet, Hard Floor, Tile Floor, Hardwood, Rug, Bare Floor

Warranty and Support

This Dyson product comes with a manufacturer's warranty. For detailed warranty information, product registration, and customer support, please visit the official Dyson store or contact their customer service.

Official Dyson Store: https://www.amazon.com/stores/Dyson/page/6E6D08F3-8F26-4243-B63A-6E50F0E65725

For any technical assistance or spare parts, please refer to the contact information available on the Dyson website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question