Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY AMT-MR21GC-NPDW-bl-netf

User Manual for ALLIMITY Replacement Magic Voice Remote Control

Model: AMT-MR21GC-NPDW-bl-netf

Introduction

This manual provides instructions for the ALLIMITY Replacement Magic Voice Remote Control, model AN-MR21GC. This remote is designed to be compatible with various LG 4K Smart TV series, offering features such as point, click, scroll, and voice control, along with dedicated shortcut buttons for popular streaming services.





Image: Front view of the ALLIMITY Replacement Magic Voice Remote Control, showing the full button layout including number pad, navigation, volume, channel, and dedicated streaming service buttons.

Setup

Battery Installation

The remote control requires two AA batteries (not included). Ensure correct polarity when inserting the batteries.



Image: Back view of the remote control with the battery cover removed, revealing the compartment for two AA batteries.

Pairing Your Remote

To ensure full functionality, the remote control must be paired with your LG Smart TV. Follow these steps:

1. Turn on your LG Smart TV.
2. After approximately 20 seconds, point the remote control towards the TV screen.
3. Press the **Wheel (OK)** button located in the center of the navigation pad.

The remote control should register automatically, and a pairing completion message will appear on your TV screen. If the Magic Remote failed to register, turn the TV off and then back on, and attempt the registration process again.



Image: A visual guide illustrating the pairing process, highlighting the central Wheel (OK) button on the remote control.

Operating Instructions

Basic Navigation

- **Power Button:** Located at the top, used to turn the TV on or off.
- **Number Pad:** For direct channel input.
- **Volume Up/Down:** Adjusts the TV volume.
- **Channel Up/Down:** Changes TV channels.
- **Navigation Wheel (OK):** Used for selecting items and scrolling through menus.
- **Home Button:** Accesses the TV's main smart hub.
- **Back Button:** Returns to the previous screen or menu.

Voice Control Function

This remote features voice control for convenient operation. To use voice commands:

1. Press and hold the **Microphone Button** (located below the volume controls).
2. Speak your command clearly into the remote.
3. Release the button when finished speaking.

Examples of voice commands include changing channels, searching for content, or adjusting settings.



Image: A visual guide highlighting the microphone button on the remote control, indicating its use for voice control.

Shortcut Buttons

Dedicated buttons provide quick access to popular streaming services:

- **Netflix**
- **Prime Video**
- **Disney+**
- **Watcha**

Maintenance

Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Always use new AA alkaline batteries for optimal performance. Refer to the "Battery Installation" section under Setup for instructions.

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as these may damage the remote's surface or internal components.

Troubleshooting

Problem	Possible Cause / Solution
Remote not responding	◦ Check battery orientation and charge. Replace batteries if necessary. ◦ Ensure the remote is pointed directly at the TV. ◦ Re-pair the remote with the TV (refer to "Pairing Your Remote" section).
Voice control not working	◦ Ensure the Microphone button is pressed and held while speaking. ◦ Check TV's internet connection for voice recognition services. ◦ Verify TV settings for voice control are enabled.
Pointer not appearing on screen	◦ Shake the remote gently to activate the pointer. ◦ Re-pair the remote with the TV.

If issues persist after attempting these solutions, please contact customer support.

Specifications

Model Number: AMT-MR21GC-NPDW-bl-netf

Product Dimensions: 7.48 x 1.57 x 0.39 inches

Item Weight: 3.52 ounces

Batteries Required: 2 AA batteries

Connectivity Technology: Bluetooth

Compatible Devices: Television

Special Feature: Ergonomic design, Voice Control, Point, Click, Scroll function

Compatible LG TV Models

This replacement remote control is compatible with a wide range of LG 4K Smart TV models, including but not limited to the following series and specific models:

- A1 Series, C1 Series, G1 Series
- UP8770 Series, UP8000 Series, UP8070 Series
- NanoCell 75 Series, NanoCell 80 Series, NanoCell 90 Series, NanoCell 99 Series
- Specific models: 43UP8000PUA, 50UP8000PUA, 55UP8000PUA, 70UP8070PUA, 65QNED95UPA, 75QNED95UPA, 43UP7560AUD, 50UP7100ZUF, 50UP7560AUD, 55UP7100ZUF, 55UP7560AUD, 65UP7100ZUF, 65UP7560AUD, 70UP7070PUE, 70UP7170ZUC, 70UP7570AUD, 75UP7070PUD,

75UP7170ZUC, 75UP7570AUE, 43UP7670PUC, 43UP7700PUB, 50UP7670PUC, 50UP7700PUB, 55UP7670PUC, 55UP7700PUB, 60UP7670PUB, 60UP7700PUB, 65UP7670PUC, 65UP7700PUA, 65UP7700PUB, 70UP7670PUB, 70UP7770PUB, 75UP7670PUB, 75UP7770PUB, 43UP8000PUR, 50UP8000PUR, 55UP8000PUR, 60UP8000PUA, 60UP8000PUR, 65UP8000PUA, 65UP8000PUR, 70UP8070PUR, 75UP8070PUA, 75UP8070PUR, 82UP8770PUA, OLED48A1AUA, OLED48C1AUB, OLED55A1AUA, OLED55B1PUA, OLED55C1AUB, OLED55C1PUA, OLED65A1AUA, OLED65B1PUA, OLED65C1AUA, OLED65C1AUB, OLED77A1AUA, OLED77B1PUA, OLED77C1AUA, OLED77C1AUB, OLED83C1AUA, 43NANO75UPA, 50NANO77ZPA, 50NANO80UPA, 50NANO85APA, 55NANO75UPA, 55NANO77ZPA, 55NANO85APA, 65NANO77ZPA, 65NANO80UPA, 65NANO85APA, 75NANO75UPA, 75NANO80UPA, 75NANO85APA, 75NANO90UPA, 86NANO85APA, 65NANO95UPA, 75NANO95UPA, 86NANO99UPA, 43UP7100ZUF, 75UP7570AUD.

For a comprehensive list or if your model is not listed, please consult the product description or contact the manufacturer.

Warranty and Support

This product is sold as a replacement voice remote control. For any issues or inquiries, please refer to the user manual included with the product or contact the seller directly. The seller provides professional suggestions for troubleshooting.
Contact information for support is typically available through your purchase platform or the manufacturer's website.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B57DHSKK

More documents and user manuals: **https://manuals.plus/**