Yavor RM-L1125

Yavor RM-L1125 TV Remote Control User Manual

Model: RM-L1125

1. Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Yavor RM-L1125 TV Remote Control. This remote is designed to be compatible with various Philips TV models, offering a convenient replacement or secondary control unit.

2. Product Overview

Familiarize yourself with the layout and features of your RM-L1125 remote control.



Figure 2.1: Front View of RM-L1125 Remote Control. This image displays the front of the Yavor RM-L1125 remote control, showing all primary buttons including power, channel, volume, navigation, source, and numerical keys. The remote has a black finish with clearly labeled buttons.



Figure 2.2: Back View of RM-L1125 Remote Control. This image shows the back of the Yavor RM-L1125 remote control, highlighting the battery compartment and providing initial setup instructions printed on the casing.

3. Setup

3.1. Battery Installation

1. Locate the battery compartment on the back of the remote control (refer to Figure 2.2).

2. Slide open the battery cover.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover securely.

3.2. Initial Use and Pairing

After installing batteries, the remote control may function directly with your Philips TV. If it does not, follow these steps for pairing:

1. Ensure your Philips TV is powered on.
2. Press and hold the **POWER** button on the remote control.
3. While holding the **POWER** button, simultaneously press and hold the corresponding digital button (e.g., "1", "2", "3", "4") that matches your TV type (e.g., "LCD/LED", "TV/LCD/LED"). The specific digital button may vary based on the TV model or the remote's pre-programmed codes.
4. Release both buttons simultaneously.
5. Test the remote control's functions. If it still does not work, repeat the process with a different digital button.

The back of the remote indicates potential codes such as "POWER" + "1" (Default), "POWER" + "4" (LCD/LED), "POWER" + "..." (TV/LCD/LED).

4. Operating Instructions

This section describes the primary functions of the buttons on your RM-L1125 remote control.

- **POWER**: Turns the TV on or off.
- **SOURCE**: Selects input sources (e.g., HDMI 1, AV, Component).
- **TV**: Switches to TV mode.
- **FORMAT**: Adjusts screen aspect ratio or picture format.
- **LIST**: Displays a list of channels or recorded programs.
- **INFO**: Shows program information.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates menus and confirms selections.
- **ADJUST**: Accesses picture or sound adjustment settings.
- **OPTIONS**: Opens a context-sensitive options menu.
- **CH+ / CH-**: Changes channels up or down.
- **VOL+ / VOL-**: Adjusts volume up or down.
- **MUTE**: Mutes or unmutes the TV sound.
- **Numerical Buttons (0-9)**: Directly enters channel numbers.
- **3D**: Activates or deactivates 3D mode (if supported by TV).
- **TEXT**: Opens or closes Teletext.
- **SUBTITLE**: Toggles subtitles on or off.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the TV menu or application.
- **Playback Controls (Rewind, Play/Pause, Fast Forward, Stop, Previous, Next)**: Controls media playback.

5. Maintenance

5.1. Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the remote's surface or internal components.

5.2. Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA batteries. Dispose of old batteries according to local regulations.

5.3. Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly inserted and not depleted. Replace if necessary.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Try the initial pairing steps again (Section 3.2).
- **Specific buttons not working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.
  - If only certain functions are affected, it might indicate a compatibility issue with your specific TV model.
- **Short operating range:**
  - Replace the batteries with new ones.
  - Ensure the remote is pointed directly at the TV's IR sensor.

7. Specifications

Model	RM-L1125
Brand	Yavor
Compatibility	Philips TV models
Power Source	2 x AAA Batteries (not included)
Item Weight	200 g
Number of Items	1

8. Warranty and Support

For information regarding warranty coverage and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase. For further assistance, please visit the Yavor official website or contact their customer service department.

© 2023 Yavor. All rights reserved.