JVC Si32rf

JVC 32-inch Smart HD Frameless Roku TV User Manual

Model: Si32rf

Introduction

This user manual provides comprehensive instructions for the setup, operation, and maintenance of your JVC 32-inch Smart HD Frameless Roku TV, Model Si32rf. Please read this manual thoroughly before using your television to ensure proper and safe operation. Keep this manual for future reference.

Safety Information

Always follow basic safety precautions when using this television to reduce the risk of fire, electric shock, and injury to persons.

- Do not block ventilation openings.
- Do not install near any heat sources.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

Package Contents

Verify that all items are included in the package:

- JVC 32-inch Smart HD Frameless Roku TV (Model Si32rf)
- Remote Control with Batteries

- TV Stand (2 pieces)
- Screws for TV Stand
- Power Cord
- Quick Start Guide
- User Manual (this document)

Setup

Attaching the TV Stand

To attach the TV stand, place the TV face down on a soft, clean surface to prevent scratches. Align each stand piece with the corresponding slots on the bottom of the TV and secure them with the provided screws.



Image: Front view of the JVC 32-inch Roku TV with its stand properly installed, showing the main screen interface.

Connecting Power and Devices

Connect the power cord to the TV and then to a wall outlet. For external devices, use the available HDMI and USB ports. The TV features 1 USB port and multiple HDMI inputs for various devices like gaming consoles, sound systems, and

media players.



Image: Diagram illustrating the dimensions of the JVC 32-inch Roku TV and the location of its ports, including HDMI and USB.

Initial Setup and Network Connection

Upon first power-on, the TV will guide you through the initial setup process. This includes selecting your language, connecting to your Wi-Fi network, and activating your Roku account. A stable internet connection is required for Smart TV features and updates.



Image: The JVC 32-inch Roku TV displaying its home screen with various streaming application icons, highlighting its Smart TV capabilities.

Operating Instructions

Using the Roku Remote

The included remote control allows you to navigate the Roku TV interface. Use the directional pad to move between options, the OK button to select, and the Home button to return to the main screen. Dedicated buttons for popular streaming services are also available.

Accessing Smart TV Features

Your JVC Roku TV provides access to a wide range of streaming channels and apps. From the home screen, you can browse featured content, access your subscribed services like Netflix, Hulu, and YouTube, or search for new channels in the Roku Channel Store.



Image: The JVC 32-inch Roku TV screen showing examples of diverse streaming content, including news, movies, and sports, available through the Roku platform.

Picture and Sound Settings

To optimize your viewing experience, you can adjust picture and sound settings. Navigate to the 'Settings' menu on the home screen to find options for picture mode (e.g., Movie, Standard, Vivid), brightness, contrast, and sound mode (e.g., Standard, Music, Movie). The TV features a vibrant LED HD display.



Image: A close-up of the JVC 32-inch Roku TV screen showcasing a high-definition image of a beach, demonstrating its capability for vivid and realistic color reproduction.

Using the Roku Mobile App

For added convenience, you can download the Roku mobile app on your smartphone. This app allows you to control your TV, use voice search, and even enjoy private listening through your headphones connected to your phone.



Image: A smartphone screen showing the Roku mobile application interface, illustrating how users can control their JVC Roku TV from their mobile device.

Maintenance

Cleaning Your TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, dampen the cloth with a small amount of water or a screen cleaner specifically designed for electronics. Do not spray cleaner directly onto the screen. For the TV casing, use a soft, dry cloth.

Software Updates

Your JVC Roku TV receives automatic software updates to ensure optimal performance and access to the latest features. Ensure your TV is connected to the internet for these updates to download and install seamlessly.



Image: Graphic illustrating key Smart TV features: automatic updates, easy setup, and the option for private audio via a mobile device.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Power cord not connected; outlet not working.	Ensure power cord is securely plugged into TV and a working outlet. Try a different outlet.

Problem	Possible Cause	Solution
No Picture, But Sound	Incorrect input selected; external device issue.	Press the Input button on the remote to cycle through inputs. Check connections of external devices.
No Sound, But Picture	Volume muted or too low; audio settings incorrect.	Unmute volume or increase level. Check audio output settings on TV and connected devices.
Cannot Connect to Wi-Fi	Incorrect password; router issues; TV too far from router.	Double-check Wi-Fi password. Restart router. Move TV closer to router or use a Wi-Fi extender.
Remote Not Working	Dead batteries; obstruction; remote not paired.	Replace batteries. Remove any obstructions between remote and TV. Re-pair remote if it's a Roku Voice Remote.

Specifications

Feature	Detail
Brand	JVC
Model Name	Si32rf
Screen Size	32 Inches (82 cm diagonal)
Display Technology	LED-LCD
Resolution	720p HD
Operating System	Roku TV
Aspect Ratio	16:9
Connectivity	HDMI, USB (1 port)
Mounting Type	Table Mount (Stand included)
Product Dimensions (W x D x H)	78 x 11 x 49 cm
Weight	4.98 kg

Warranty and Support

For warranty information and technical support, please refer to the warranty card included in your product packaging or

visit the official JVC support website. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may contact JVC customer service through their official channels. Please have your model number (Si32rf) and serial number ready when contacting support.

© 2023 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question