Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ECONTROLLY 100027812

User Manual for ECONTROLLY Replacement Remote Control

Model: 100027812
Compatible with ONN Sound BAR Blast 5.1 400W 36" Soundbar

Introduction

This manual provides comprehensive instructions for the ECONTROLLY 100027812 replacement remote control. Designed to seamlessly operate your ONN Sound BAR Blast 5.1 400W 36" Soundbar, this remote offers a direct replacement solution without the need for complex programming.

Package Contents

- 1 x ECONTROLLY Replacement Remote Control (Model: 100027812)
- User Manual (this document)

Product Overview

Front View



This image displays the front of the ECONTROLLY replacement remote control, highlighting the layout of its various function buttons, including power, input selection, volume, bass, treble, and mute controls.

Back View



The back view of the remote control is shown, featuring the battery compartment cover at the bottom and the model number '100027812' clearly printed on the main body.

Button Functions

Button	Function
Power	Turns the soundbar On or Off.
Mute	Mutes or unmutes the soundbar audio.
AUX	Selects the Auxiliary input source.
HDMI ARC	Selects the HDMI Audio Return Channel input.
HDMI IN	Selects the standard HDMI input.
Optical	Selects the Optical audio input.
Bluetooth (represented by asterisk/star icon)	Selects the Bluetooth input source.
VOL + / -	Increases or decreases the main volume level.
Play/Pause	Plays or pauses media playback.
Previous Track	Skips to the previous track.
Next Track	Skips to the next track.
RESET	Resets sound settings or the remote itself.
BASS + / -	Adjusts the bass level up or down.
TREB + / -	Adjusts the treble level up or down.
EQ	Cycles through available equalizer presets.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Initial Use

This ECONTROLLY replacement remote control is pre-programmed and does not require any additional setup or programming. Once batteries are installed, it is ready for immediate use with your compatible ONN Sound BAR Blast 5.1 400W 36" Soundbar.

Operating Instructions

To operate your soundbar using this remote control, simply point the remote directly at the soundbar's infrared (IR) receiver and press the desired function button.

- **Power On/Off:** Press the **Power** button to turn the soundbar on or off.

- **Volume Control:** Use the **VOL +** button to increase volume and **VOL -** to decrease volume.
- **Mute:** Press the **Mute** button to temporarily silence the audio. Press again to restore sound.
- **Input Selection:** Press **AUX**, **HDMI ARC**, **HDMI IN**, **Optical**, or the **Bluetooth** button to switch between different audio input sources.
- **Bass Adjustment:** Use **BASS +** to increase bass and **BASS -** to decrease bass.
- **Treble Adjustment:** Use **TREB +** to increase treble and **TREB -** to decrease treble.
- **Equalizer Presets:** Press the **EQ** button to cycle through available sound equalizer modes (e.g., Movie, Music, News).
- **Media Playback Controls:** Use the **Play/Pause**, **Previous Track**, and **Next Track** buttons for controlling media playback when applicable (e.g., via Bluetooth).
- **Reset:** The **RESET** button can be used to restore certain sound settings to their default values or to reset the remote's internal state if it becomes unresponsive.

Maintenance

Cleaning

Wipe the remote control periodically with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

Troubleshooting

Problem	Possible Cause	Solution
Remote not working.	Batteries are dead or incorrectly inserted.	Replace batteries with new AAA alkaline batteries, ensuring correct polarity.
Remote not working.	Obstruction between remote and soundbar.	Ensure there is a clear line of sight between the remote's IR emitter and the soundbar's IR receiver.
Remote not working.	Soundbar is not powered on.	Ensure the soundbar is plugged in and powered on.
Some buttons not responding.	Specific button malfunction or soundbar not supporting the function.	Check if other buttons work. Ensure your soundbar model supports the specific function. Try resetting the remote (if applicable).
Remote range is poor.	Low batteries or interference.	Replace batteries. Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

Specifications

Feature	Detail
Model Number	100027812
Compatible Devices	ONN Sound BAR Blast 5.1 400W 36" Soundbar
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Alkaline Batteries (not included)
Dimensions (L x W x H)	7 x 2 x 0.65 inches (approximate)
Weight	1.55 ounces (without batteries)
Manufacturer	ECONTROLLY Factory

Warranty Information

This ECONTROLLY product is covered by the manufacturer's standard warranty. Please refer to the original product packaging or contact ECONTROLLY customer support for specific warranty terms and conditions.

Customer Support

For further assistance, technical support, or inquiries regarding your ECONTROLLY replacement remote control, please contact the manufacturer directly. Contact information can typically be found on the product packaging or the ECONTROLLY official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B5WND7QS

More documents and user manuals: **https://manuals.plus/**