ALLIMITY N2QAYB001059

ALLIMITY N2QAYB001059 Remote Control Instruction Manual

For Panasonic DVD Recorder Models: DMR-EX97EB, DMR-EX97EB-K, DMREX97EB, DMREX97EBK

1. Introduction

This instruction manual provides essential information for the proper setup, operation, and maintenance of your ALLIMITY N2QAYB001059 replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of various Panasonic DVD Recorder models, including N2QAYB001059, DMR-EX97EB, DMR-EX97EB-K, DMREX97EB, and DMREX97EBK.
The ALLIMITY N2QAYB001059 remote control offers full functionality, replicating all features of your original remote without the need for complex programming.

2. Setup: Battery Installation

The remote control requires two AAA alkaline batteries (not included) for operation. No programming or pairing is necessary; simply insert the batteries, and the remote will be ready for use.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Note: *Always use new alkaline batteries for optimal performance. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period to prevent leakage.*




DRIVE SELECT
INPUT
AV
VOL
CH
PAGE
1
2abc
3def
4ghi
5jkl
6mno
7pqrs
8tuv
9wxyz
0
RADIO/TV
LAST VIEW
SKIP
SLOW/SEARCH
REWIND LIVE TV
STOP
PAUSE
PLAY/x1.3
PAUSE LIVE TV
STATUS
EXIT
GUIDE
VIDEO MENU
FUNCTION MENU
OK
BACK/RETURN
OPTION
REC
REC MODE
TEXT
STTL
PROG/CHECK
CHAPTER
DELETE
DISPLAY
AD
TIME SLIP
MANUAL SKIP
-10s
+60s



Image 2.1: Angled view of the ALLIMITY N2QAYB001059 remote control, showing its ergonomic design and button layout. This view provides a perspective of the remote's form factor.

3. Button Functions and Operation

The ALLIMITY N2QAYB001059 remote control is designed to replicate the full functionality of your original Panasonic DVD Recorder remote. Below is a general overview of the buttons and their common functions. Refer to your Panasonic DVD Recorder's manual for specific operational details related to your device.





Image 3.1: Front view of the ALLIMITY N2QAYB001059 remote control, displaying all buttons and their labels. This image serves as a visual guide for identifying each control.

3.1. Power and Input Controls

- **POWER (Red Button):** Turns the DVD Recorder and/or connected TV (if configured) on or off.
- **DRIVE SELECT:** Selects the drive (e.g., HDD, DVD).
- **TV / INPUT AV:** Switches the TV input source or toggles between TV and AV modes.

3.2. Channel and Volume Controls

- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the television channel up or down.
- **PAGE CH +/-:** Navigates through pages of channels or program guides.

3.3. Numeric Keypad and Navigation

- **0-9:** Enters channel numbers, menu selections, or time codes.
- **LAST VIEW:** Returns to the previously viewed channel or input.
- **RADIO/TV:** Toggles between radio and TV modes.
- **GUIDE (Green Button):** Displays the electronic program guide (EPG).
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **OK:** Confirms a selection or enters a menu item.
- **VIDEO MENU:** Accesses the video menu.
- **FUNCTION MENU:** Accesses additional function menus.
- **OPTION:** Displays context-sensitive options.
- **BACK/RETURN:** Returns to the previous screen or menu.

3.4. Playback and Recording Controls

- **PLAY/x1.3:** Starts playback or plays at 1.3x speed.

- **PAUSE / PAUSE LIVE TV:** Pauses playback or live TV.
- **STOP:** Stops playback or recording.
- **SKIP (Forward/Backward):** Skips forward or backward in content.
- **SLOW/SEARCH:** Activates slow motion playback or search function.
- **REWIND LIVE TV:** Rewinds live television.
- **REC (Red Button):** Initiates recording.
- **REC MODE (Green Button):** Selects recording quality or mode.
- **PROG/CHECK:** Checks program information.
- **CHAPTER:** Navigates between chapters.
- **DELETE:** Deletes selected items.
- **DISPLAY:** Shows on-screen display information.
- **AD:** Activates audio description.
- **TIME SLIP:** Allows time-shifting functions.
- **MANUAL SKIP -10s / +60s:** Skips content by specific time intervals.

3.5. Other Functions

- **STATUS (i):** Displays status information.
- **TEXT (Yellow Button):** Accesses teletext services.
- **STTL (Blue Button):** Toggles subtitles.
- **EXIT (X):** Exits current menu or function.

4. Maintenance

Proper maintenance ensures the longevity and reliable performance of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new alkaline batteries.
- **Storage:** If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent potential leakage and damage. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops and Impacts:** Protect the remote from physical shock, as internal components can be damaged.

5. Troubleshooting

If you encounter issues with your ALLIMITY N2QAYB001059 remote control, refer to the following common troubleshooting steps:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-) and are not depleted. Replace with fresh alkaline batteries if necessary.
  - Ensure there is a clear line of sight between the remote control and the infrared sensor on your Panasonic DVD Recorder. Obstructions can block the signal.
  - Verify that the remote is pointed directly at the DVD Recorder's sensor.

- **Specific Buttons Not Working:**
  - This could indicate a dirty contact under the button. While not recommended for user disassembly, ensure the remote is clean externally.
  - If only a few buttons are unresponsive, and battery replacement does not help, the remote may be faulty.
- **Interference:**
  - Strong light sources, especially fluorescent lights or direct sunlight, can interfere with infrared signals. Try operating the remote in different lighting conditions.
  - Other electronic devices emitting infrared signals might cause interference.
- **Incorrect Device Response:**
  - Ensure your Panasonic DVD Recorder model is listed as compatible with the ALLIMITY N2QAYB001059 remote control.

If these steps do not resolve the issue, please contact the seller for further assistance.

6. Specifications

Brand	ALLIMITY
Item Model Number	QYSY-N2QAYB001059-QYSY
Connectivity Technology	Infrared
Special Feature	Universal (Replacement)
Compatible Devices	N2QAYB001059, DMR-EX97EB, DMR-EX97EB-K, DMREX97EB, DMREX97EBK
Controller Type	Remote Control
Maximum Range	10 Meters
Battery Description	Alkaline (AAA x 2, not included)
Country of Origin	China

7. Warranty and Support

For information regarding product warranty, please refer to the documentation provided at the time of purchase or contact the seller directly. Warranty terms and conditions may vary depending on the retailer and region.
If you require technical support or have questions not covered in this manual, please contact the seller or manufacturer through the platform where the product was purchased. Provide your order details and a clear description of the issue for prompt assistance.