Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uetmulik HC-6601-FR2

Uetmulik Raffel Systems HC-6601-FR2 Remote Control User Manual

Introduction

This manual provides instructions for the proper installation, operation, and maintenance of your Uetmulik Raffel Systems HC-6601-FR2 Remote Control. This hand control is designed for use with Franklin and Tranquil Ease recliner lift chairs. Please read this manual thoroughly before use to ensure safe and efficient operation.

Safety Information

- Always ensure the lift chair's power is disconnected before performing any installation or maintenance.
- Keep the remote control dry and away from liquids.
- Do not attempt to open or repair the remote control yourself. Contact qualified personnel for service.
- Ensure all connections are secure to prevent electrical hazards or malfunction.

Setup Instructions

Follow these steps to connect your new remote control to your lift chair:

1. **Identify Components:** Unpack the remote control and the included extension cable. The remote features a 4-pin connector, and the extension cable provides a 5-pin connection for your lift chair.
2. **Locate Chair Connection:** Identify the existing remote control connection port on your lift chair. This is typically a 5-pin circular port.
3. **Connect Remote:**
    - Connect the 4-pin plug from the remote control to the 4-pin receptacle on the extension cable. Ensure the pins align correctly and push firmly until secure.
    - Connect the 5-pin plug from the extension cable to the 5-pin port on your lift chair. Ensure the pins align and the connection is snug.
4. **Secure Cables:** Route the cables safely to prevent tripping hazards or damage.



Image: The HC-6601-FR2 remote control with its attached cable and the separate extension cable, ready for connection.



Image: A detailed view showing the 4-pin connector from the remote and the 5-pin connector on the extension cable, highlighting the dual connector design.

Setup Video Guide

Your browser does not support the video tag.

Video: This official product video demonstrates the connection process for the HC-6601-FR2 remote control, showing how to attach the extension cable and connect it to a lift chair.

Operating Instructions

The HC-6601-FR2 remote control features a simple paddle button for intuitive operation:

- **To Recline/Lift Up:** Press and hold the **UP** (top) section of the paddle button. The chair will recline backward or lift upwards, depending on its current position.
- **To Sit Up/Lift Down:** Press and hold the **DOWN** (bottom) section of the paddle button. The chair will move to an upright position or lower downwards.

Release the paddle button at any time to stop the chair's movement.



Image: A close-up view of the remote control's paddle button, showing the distinct 'Up' and 'Down' sections for easy control.

Maintenance

To ensure the longevity and proper function of your remote control:

- **Cleaning:** Spot clean the surface of the remote control with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the cable excessively. Do not roll over the cable with chair wheels or other heavy objects.

Troubleshooting

If you experience issues with your remote control, refer to the following common solutions:

- **Remote Not Responding:**
  - Ensure all cable connections (remote to extension, extension to chair) are fully inserted and secure.
  - Verify that the lift chair itself is properly plugged into a working power outlet.
  - Check for any visible damage to the remote control cable or connectors.
- **Intermittent Operation:**
  - Inspect connections for looseness. Re-seat all plugs.
  - Ensure the cable is not pinched or under stress.

If the problem persists after attempting these steps, contact customer support.

Specifications

Attribute	Detail
Brand	Uetmulik
Model Number	HC-6601-FR2
Manufacturer	Raffel Systems
Material	Plastic
Color	Black
Item Weight	0.48 kg
Size (approx.)	17.78 x 3.048 x 22.86 inches
Connection Type	5-Pin (with 4-pin remote to 5-pin extension)
Included Components	Remote Control, Extension Cable
Recommended Uses	Relaxing (Lift Chair Operation)
Product Care	Spot Clean





Image: The reverse side of the remote control, displaying the manufacturer's label with model number HC-6601-FR2 and other compliance information.

Warranty Information

This product is covered by the standard manufacturer's warranty. For specific details regarding warranty coverage, duration, and claims process, please refer to your purchase documentation or contact the seller directly. Keep your proof of purchase for warranty purposes.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or any other customer service inquiries, please contact the seller or the manufacturer, Uetmulik. Provide your product model number (HC-6601-FR2) and purchase date when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B61SP49Z

More documents and user manuals: **https://manuals.plus/**