Chriari 60inchXG60

Chriari 60-inch Ceiling Fan User Manual

Model: 60inchXG60

1. Introduction

Thank you for choosing the Chriari 60-inch Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read all instructions carefully before beginning installation and retain this manual for future reference.

Safety Information

- Always disconnect power at the circuit breaker before installation or servicing.
- Ensure all electrical connections comply with local codes and ordinances.
- The fan must be mounted to a ceiling joist or a suitable support structure capable of supporting the fan's weight.
- Do not bend the blade holders during installation or cleaning.
- Keep children away from the fan during operation.

2. Product Overview

The Chriari 60-inch Ceiling Fan is designed for both indoor and outdoor (covered) use, featuring a durable construction and advanced functionalities for enhanced comfort.



Image: The Chriari 60-inch Ceiling Fan with its included remote and wall control units.

Key Features

- **Indoor/Outdoor Compatibility:** IP4 Moisture Resistance suitable for covered patios, porches, and indoor spaces.
- **Quiet DC Motor:** Silicon steel DC motor provides powerful airflow with a low noise level of 35 decibels.
- **Reversible Function:** Allows for seasonal air direction changes to optimize cooling in summer and heat distribution in winter.
- **Multiple Control Options:** Includes both a remote control and a wall control for convenient operation.
- **6 Wind Speeds:** Adjustable fan speeds to suit various comfort levels.
- **Smart Timing:** Programmable timer settings (2, 4, or 6 hours) for automatic fan shut-off.
- **Durable Blades:** Features 3 balanced solid wood blades.
- **Flexible Installation:** Includes three downrods (5", 10", 20") for various ceiling heights and supports sloped ceiling installations.



Image: Visual representation of the fan's key features: wall control, remote control, timer settings, low noise operation, reversible function, and 6 wind speeds.



Image: Close-up views highlighting the fan's components, including the downrods, silent bearing DC motor, walnut wood blades, enhanced sturdy structure, and premium copper core.

3. Specifications

Feature	Detail
Brand	Chriari
Model Name	60inchXG60
Electric Fan Design	Ceiling Fan
Size	60-Inch
Color	Aged Pewter Gray

Style	Farmhouse
Power Source	Corded Electric
Voltage	120 Volts
Wattage	35 watts
Number of Blades	3
Blade Length	30 Inches
Air Flow Capacity	6387 Cubic Feet Per Minute
Noise Level	35 Decibels
Control Method	Remote, Wall Control
Number of Power Levels	6
Special Features	2H-4H-6H Timing, 6 Wind Speed, Remote Control, Reversible Function, Wall Control
Indoor/Outdoor Usage	Indoor, Outdoor (Covered)
Mounting Type	Downrod Mount
Included Components	3 Downrods (5"/ 10" / 20"), 3 Wood Blades, 35W DC Motor, Remote + Wall Control, User Manual
Certification	ETL

4. Setup and Installation

This section provides general guidance for installing your Chriari ceiling fan. For detailed, step-by-step instructions, please refer to the separate installation guide included in your product packaging. Professional installation is recommended.

Pre-Installation Checklist

- Ensure all components listed in the 'Included Components' section are present.
- Verify that the installation location can support the fan's weight and is suitable for electrical connections.
- Turn off power at the main circuit breaker before starting any electrical work.

Mounting Options

The fan supports both normal and angled mounting, accommodating various ceiling types. Three downrod lengths are provided for flexible installation based on your ceiling height.



Image: The Chriari 60-inch Ceiling Fan installed in a modern living room, demonstrating its aesthetic integration and the presence of both remote and wall control options.



Image: A detailed view of how the fan blades attach to the motor housing, showcasing the secure fastening mechanism.

5. Operating Instructions

Your Chriari ceiling fan can be operated using either the included remote control or the wall control unit.

Remote Control Functions

- **Power On/Off:** Press the power button to turn the fan on or off.
- **Speed Adjustment:** Buttons 1-6 control the fan speed, from lowest (1) to highest (6).
- **Timing Function:** Set the fan to operate for 2, 4, or 6 hours before automatically turning off.
- **Reversible Function:** A dedicated button allows you to switch the direction of blade rotation.

Wall Control Functions

The wall control provides similar functionalities to the remote, allowing for convenient operation from a fixed location.

Reversible Function

The reversible function allows you to change the fan's direction of rotation to suit the season:

- **Summer Mode:** Blades rotate counter-clockwise, pushing air downwards to create a cooling breeze.
- **Winter Mode:** Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling, helping to distribute heat more evenly.



Image: Illustration of the fan's reversible function, showing downward airflow for cooling in summer and upward airflow for heat distribution in winter.



Image: A visual representation of the fan's intelligent timing feature, offering 2, 4, and 6-hour automatic shut-off options.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

Cleaning

- Always turn off the power at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the fan blades and motor housing. Avoid harsh chemicals or abrasive cleaners.
- Do not immerse the fan in water.

Blade Balancing

If the fan wobbles, ensure all blade screws are tightened. A balancing kit may be used if wobbling persists after checking all connections.

7. Troubleshooting

This section addresses common issues you might encounter with your ceiling fan.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote/wall control battery low or not paired.	Check circuit breaker; Verify all wiring connections are secure; Replace batteries or re-pair control.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a blade balancing kit; Ensure mounting bracket is securely fastened.

Noisy operation	Loose screws; Motor housing rubbing; Incorrect installation.	Check and tighten all screws; Ensure no parts are rubbing; Re-check installation steps.
Remote/Wall control not working	Dead batteries; Not paired with fan; Obstruction between control and receiver.	Replace batteries; Follow pairing instructions in the installation guide; Remove any obstructions.

8. Warranty and Support

Chriari is committed to providing quality products and excellent customer service.

Warranty Information

Your Chriari 60-inch Ceiling Fan comes with an**18-month worry-free warranty** and free replacement services for manufacturing defects.

Technical Support

For any issues during installation or use, Chriari provides**24-hour online technical support**.
Contact Email: ChriariCeilingFan@gmail.com

© 2023 Chriari. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question