Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wilfa CM6S-100

Wilfa Classic Filter Coffee Machine

Model: CM6S-100

1. Important Safety Instructions

Please read all instructions carefully before using the appliance and save them for future reference. Incorrect operation may cause personal injury and property damage.

- Always ensure the appliance is unplugged from the power outlet before cleaning or when not in use.
- Do not immerse the power cord, plug, or the appliance itself in water or any other liquid.
- This appliance is intended for household use only. Do not use outdoors.
- Keep the appliance and its cord out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Place the coffee maker on a stable, level surface, away from hot surfaces or open flames.
- Do not open the lid during the brewing cycle as scalding may occur.
- Use only cold, fresh water in the water tank.
- Regularly descale the coffee maker to ensure optimal performance and longevity.

2. Product Overview

The Wilfa Classic Filter Coffee Machine CM6S-100 is designed for optimal coffee brewing, combining timeless design with advanced features for a perfect cup every time.



Figure 2.1: Front view of the Wilfa Classic Filter Coffee Machine, showcasing its sleek silver and black design with the water tank, filter holder, and glass carafe.



Figure 2.2: The coffee machine in a modern kitchen setting, highlighting its ability to brew coffee precisely to your preference.



Figure 2.3: Key features of the coffee machine, including the detachable filter element, manual drip tray, flow control with adjustable extraction time, and 1-liter water tank.



Figure 2.4: The coffee machine emphasizing its timeless Norwegian design and coffee expertise.



Figure 2.5: An overview of brewing parameters and features, including power (1550W), brewing temperature (92-96°C), automatic cleaning reminder, auto shut-off, hot plate, and 10-cup capacity.



Figure 2.6: The coffee machine ready to deliver delicious coffee with the simple touch of a button.

3. Setup

1. **Unpacking:** Carefully remove all packaging materials and ensure all parts are present: main unit, water tank, filter holder, glass carafe, and measuring spoon.
2. **Initial Cleaning:** Before first use, wash the glass carafe, filter holder, and water tank lid in warm, soapy water. Rinse thoroughly and dry.
3. **Positioning:** Place the coffee maker on a flat, stable, heat-resistant surface near a power outlet. Ensure there is enough space around the unit for proper ventilation.
4. **First Use (Cleaning Cycle):** Fill the water tank with fresh, cold water up to the MAX level. Place the empty glass carafe on the heating plate. Press the power button to run a full brewing cycle without coffee. Discard the water. Repeat this process 2-3 times to clean the internal components.

4. Operating Instructions

Follow these steps to brew a perfect cup of coffee:

1. **Fill Water Tank:** Open the lid of the water tank and fill it with fresh, cold water. The tank has clear markings for desired cups (e.g., 1L capacity). Do not exceed the MAX fill line.
2. **Insert Filter:** Place a paper filter (size 4 recommended) into the filter holder.
3. **Add Coffee Grounds:** Add your desired amount of ground coffee into the paper filter. A general guideline is 60 grams of coffee per liter of water, but adjust to your taste.
4. **Position Carafe:** Place the glass carafe with its lid securely on the heating plate, ensuring it is correctly aligned to activate the drip-stop mechanism.
5. **Adjust Flow Control (if applicable):** The Wilfa Classic features an adjustable flow control on the filter holder. Rotate the dial to adjust the extraction time based on your coffee grind and desired strength. For finer grinds, a slower flow might be preferred.
6. **Start Brewing:** Plug the coffee maker into a power outlet. Press the power button. The indicator light will illuminate, and the brewing process will begin.
7. **Serving:** Once the brewing cycle is complete, the coffee maker will automatically switch to keep-warm mode. The heating plate will keep the coffee warm for approximately 40 minutes before automatically shutting off.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your coffee machine.

- **Daily Cleaning:** After each use, unplug the appliance. Remove the filter holder and glass carafe. Wash them in warm, soapy water or place them in the dishwasher (if dishwasher-safe, refer to product manual for specific parts). Wipe the exterior of the coffee maker with a damp cloth.
- **Descaling:** Mineral deposits from water can build up over time, affecting performance and taste. Descale your coffee maker every 1-3 months, depending on water hardness and frequency of use.
- **Descaling Procedure:**
    a. Mix a descaling solution according to the manufacturer's instructions (e.g., white vinegar and water, or a commercial descaler).
    b. Pour the solution into the water tank.
    c. Place the empty carafe on the heating plate.
    d. Run a brewing cycle. If using vinegar, you may want to pause the cycle halfway through and let it sit for 15-30 minutes before resuming.
    e. After the cycle, discard the solution.
    f. Rinse the coffee maker by running 2-3 full cycles with fresh, cold water to remove any residual descaling solution.
- Do not use abrasive cleaners or scouring pads on any part of the coffee maker.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Coffee does not brew.	No water in tank; appliance not plugged in; power button not pressed.	Fill water tank; plug in appliance; press power button.
Coffee tastes weak.	Not enough coffee grounds; coffee too coarsely ground; flow control set too fast.	Add more coffee; use finer grind; adjust flow control to a slower setting.
Coffee overflows from filter.	Too much coffee grounds; filter clogged; carafe not positioned correctly.	Reduce coffee amount; clean filter holder; ensure carafe is correctly placed.
Appliance leaks.	Water tank overfilled; carafe not correctly placed; component not assembled properly.	Do not overfill; ensure carafe is aligned; check all removable parts are securely in place.
Coffee is not hot enough.	Appliance needs descaling.	Perform a descaling cycle.

If the problem persists after trying these solutions, please contact Wilfa customer support.

7. Specifications

- **Model:** CM6S-100
- **Manufacturer:** WILFA
- **Power:** 1550 Watts
- **Voltage:** 230V
- **Capacity:** 1 Liter (approx. 10 cups)
- **Brewing Temperature:** 92°C - 96°C (197.6°F - 204.8°F)
- **Product Dimensions:** 7.48 x 15.28 x 16.3 inches
- **Item Weight:** 4.4 pounds
- **Filter Type:** Reusable (or standard paper filter size 4)
- **Special Features:** Jug, Adjustable Flow Control, Automatic Cleaning Reminder, Automatic Shut-off (40 minutes), Hot Plate with Self-Resistor
- **Operation Mode:** Manual
- **Coffee Input Type:** Pre-ground

8. Warranty and Support

Wilfa products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty, details of which can be found on the official Wilfa website or by contacting customer support.

For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Wilfa customer support through their official website or the contact information provided with your purchase.

Please retain your proof of purchase for warranty purposes.

© 2024 Wilfa. All rights reserved.
For more information, visit www.wilfa.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B68TDHXH

More documents and user manuals: **https://manuals.plus/**