TRAVELARIM VC-TA-L

TRAVELARIM 20-Inch Carry-On Luggage Instruction Manual

Model: VC-TA-L

1. Product Overview

The TRAVELARIM 20-Inch Carry-On Luggage is designed for efficient and secure travel. This hard-shell suitcase meets airline-approved carry-on dimensions and features smooth-gliding spinner wheels, a telescoping handle, and an integrated TSA lock. It includes a tech-friendly front compartment with a USB charging port and a dedicated cosmetic case for organized packing.



Image 1: Overview of the TRAVELARIM 20-Inch Carry-On Luggage and Cosmetic Case with key dimensions.

2. Key Features

- **Airline Approved Dimensions:** Exterior dimensions of 22" x 13.5" x 9" (including wheels) meet most airline carry-on requirements. Interior packing space is 19.5" x 13" x 9".
- **Durable Hard-Shell Design:** Impact-resistant construction with beveled sides and a brushed finish to reduce scratches.
- **360° Spinner Wheels:** Four multi-directional spinner wheels provide smooth, effortless mobility.
- **Telescoping Handle:** Adjustable handle for comfortable maneuvering.
- **Integrated TSA Lock:** Secure your belongings with a built-in TSA-approved combination lock.
- **Tech-Friendly Front Compartment:** Features a padded laptop pocket, padded iPad pocket, power bank pocket, and an

exterior USB port for charging devices (power bank not included). Includes an insulated pocket for food.

- **Matching Cosmetic Case:** A separate cosmetic case (6" W x 12" L x 10" H) with zippered compartments and a mesh pocket, designed to securely attach to the suitcase handle.
- **Organized Interior:** Large, zippered compartments with elastic straps to secure contents.



Image 2: Detailed view of the tech-friendly front compartment and interior organization.



Image 3: Key features of the luggage including the TSA lock, spinner wheels, and durable exterior.

3. Setup

3.1 Setting the TSA Combination Lock

1. The default combination is usually 0-0-0.
2. With the lock set to the default combination, push the reset button (a small button or lever, often recessed) with a pen or pointed object until you hear a click.
3. Set your desired 3-digit combination by turning the dials.
4. Push the release button (usually the larger button or lever) in the direction of the arrows. The reset button should pop back out.
5. Your new combination is now set. Test it to ensure it works correctly before securing your luggage.

3.2 Attaching the Cosmetic Case

The cosmetic case is designed to securely attach to the telescoping handle of the main carry-on luggage.

1. Extend the telescoping handle of the main luggage to its full height.
2. Locate the elastic strap on the back of the cosmetic case.
3. Slide the cosmetic case over the extended handle, ensuring the strap fits snugly around both handle bars.
4. Adjust the position of the cosmetic case for stability.

Your browser does not support the video tag.

Video 1: Demonstration of attaching the cosmetic case to the main luggage handle. This video highlights the convenience of the two-piece set for travel.

4. Operating Instructions

4.1 Using the Telescoping Handle

- To extend the handle, press the button located on the top of the handle and pull upwards.
- To retract the handle, press the button again and push downwards until it is fully collapsed.

4.2 Utilizing the Spinner Wheels

The 360° spinner wheels allow for effortless movement in any direction. Simply push or pull the luggage from the handle, and the wheels will glide smoothly, reducing strain on your arm.



Image 4: The 360-degree spinner wheels provide smooth and easy movement.

4.3 USB Charging Port

The carry-on luggage features an integrated USB port for convenient charging of your electronic devices.

1. Open the tech-friendly front compartment.
2. Place your power bank (not included) into the designated power bank pocket inside the compartment.
3. Connect the internal USB cable from the luggage to your power bank.
4. To charge your device, plug your device's charging cable into the external USB port located near the TSA lock.

Your browser does not support the video tag.

Video 2: A demonstration of the USB charging port and front compartment features.

Your browser does not support the video tag.

Video 3: Another view of the USB charging port and internal organization for electronics.

5. Maintenance

5.1 Cleaning the Exterior

- Wipe the hard-shell exterior with a soft, damp cloth and mild soap.
- Avoid abrasive cleaners or solvents that could damage the finish.
- For stubborn marks, a gentle plastic cleaner may be used.

5.2 Interior Care

- Vacuum the interior lining to remove dust and debris.
- Spot clean any stains with a damp cloth and mild detergent. Allow to air dry completely before closing.

5.3 Wheel and Handle Maintenance

- Periodically check the spinner wheels for any debris or hair that might impede smooth rolling. Clean as necessary.
- Ensure the telescoping handle extends and retracts smoothly. If it becomes stiff, a silicone-based lubricant can be applied sparingly to the shafts.

6. Troubleshooting

6.1 Zipper Issues

- If a zipper gets stuck, avoid forcing it. Gently pull the fabric around the zipper to relieve tension.
- Lubricate the zipper teeth with a pencil lead or a zipper lubricant to help it glide smoothly.
- If the zipper is misaligned or skips teeth, try to carefully realign it by moving the slider back and forth.

6.2 Handle Stiffness

- If the telescoping handle becomes stiff, ensure no debris is lodged in the mechanism.
- Apply a small amount of silicone spray to the handle shafts and extend/retract it several times to distribute the lubricant.

6.3 USB Port Not Charging

- Ensure your power bank is fully charged and correctly connected to the internal USB cable.
- Verify that your device's charging cable is securely plugged into the external USB port.
- Test with a different power bank or charging cable to rule out issues with those accessories.

7. Specifications

Feature	Detail
Product Dimensions	8.5 x 13 x 22 inches

Item Weight	5 pounds
Capacity	33 Liters
Model Number	VC-TA-L
Manufacturer	TravelArim
Material	Hard-shell (details not specified, typically ABS or Polycarbonate)

8. Warranty & Support

For warranty information, product support, or to purchase replacement parts, please visit the official TRAVELARIM store or contact their customer service directly.
Official TRAVELARIM Store: Visit Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question