OLOV Budhha

OLOV Electric Body Hair Trimmer User Manual

Model: Budhha

1. Safety Information

Important: Keep out of reach of children.
This device is designed for personal grooming. Do not use it for purposes other than those described in this manual. Ensure the device is clean and dry before and after each use, especially when using it in wet conditions.

2. Product Overview

The OLOV Electric Body Hair Trimmer is a versatile grooming tool designed for both men and women. It features ceramic blades that provide a smooth and comfortable trim without cutting, tugging, or irritating the skin. This trimmer is suitable for various body areas, including the groin, bikini area, armpits, legs, and chest.
Key features include:

- **Ceramic Blades:** Designed for gentle and effective trimming, minimizing nicks and irritation.
- **Wet/Dry Use:** Fully waterproof (IPX7 rated) for convenient use in the shower and easy cleaning under running water.
- **USB Recharge Dock:** Provides convenient charging and storage.
- **Adjustable Trimming Guards:** Includes 2 adjustable guards for different hair lengths.



Image: The OLOV Electric Body Hair Trimmer in its charging dock, showcasing its sleek white and rose gold design.



Image: The OLOV Trimmer alongside its packaging, charging dock, USB cable, and two adjustable trimming guards.

3. Setup and Charging

3.1 Initial Charge

Before first use, fully charge your OLOV Electric Body Hair Trimmer. Connect the USB cable to the charging dock and plug it into a compatible USB power adapter (not included). Place the trimmer securely in the charging dock. The indicator light on the trimmer will show charging status.



Image: The OLOV Trimmer shown both in its charging dock and connected directly via USB cable, illustrating charging options.

3.2 Attaching/Detaching Trimmer Heads

The OLOV trimmer features replaceable ceramic blade heads for optimal hygiene and performance. To attach a head, align it with the trimmer body and gently push until it clicks into place. To detach, firmly pull the head away from the body.



Image: A hand demonstrating how to attach or detach the replaceable trimmer head from the main body of the OLOV trimmer.



Image: A detailed view of the ceramic blade heads, highlighting the ceramic blade and protective guard for a close shave.

3.3 Attaching Trimming Guards

For different hair lengths, attach one of the two adjustable trimming guards (3/6mm or 9/12mm) over the blade head. Ensure it is securely fastened before use.

4. Operating Instructions

To operate the OLOV Electric Body Hair Trimmer, follow these steps:

1. Ensure the trimmer is fully charged and clean.
2. Select the appropriate trimming guard for your desired hair length, or use without a guard for a closer trim.
3. Press the power button to turn on the trimmer.
4. Gently glide the trimmer against the direction of hair growth. For sensitive areas, pull the skin taut to ensure a smooth pass.
5. The trimmer can be used wet or dry. Using it in the shower can help wash away trimmings and make the process easier.
6. After use, press the power button to turn off the trimmer.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your trimmer.

- **After Each Use:** Turn off the trimmer. Remove the blade head and use the included cleaning brush to remove any trapped hairs.
- **Rinsing:** Since the trimmer is waterproof, you can rinse the blade head and the entire device under running water. Ensure all hair and debris are washed away.
- **Drying:** Allow the trimmer and blade head to air dry completely before reattaching the head or storing the device.
- **Storage:** Store the trimmer in a cool, dry place, preferably in its charging dock or a protective pouch.



Image: The OLOV Trimmer with water droplets, illustrating its waterproof design (IPX7 rating) for easy cleaning and wet use.

6. Troubleshooting

If you encounter issues with your OLOV Electric Body Hair Trimmer, please refer to the following common solutions:

- **Trimmer not turning on:** Ensure the device is fully charged. If the battery is low, place it on the charging dock for at least 30 minutes.
- **Trimmer pulling hair or not cutting effectively:**

- Check if the blade head is clogged with hair. Turn off the device, remove the head, and clean it thoroughly with the brush and water.
- Ensure the blade head is properly attached and secured.
- The blades may be dull. Consider replacing the ceramic blade head if performance does not improve after cleaning.

- **Charging issues:**
  - Verify that the USB cable and power adapter are working correctly.
  - Ensure the trimmer is correctly seated in the charging dock.

If the problem persists, please contact OLOV customer support for further assistance.

7. Specifications

Product Dimensions	3.15 x 1.18 x 1.18 inches; 12.31 ounces
Item Model Number	Budhha
Batteries	2 AAA batteries required. (included)
Date First Available	July 12, 2022
Manufacturer	OLOV
ASIN	B0B6B9BW1Q
Recommended Uses	Body, Pubic, Groin, Bikini
Color	Rose Gold & White
Hair Type	All
Item Weight	0.35 Kilograms
Brand	OLOV

8. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact OLOV customer service directly. Contact details can typically be found on the manufacturer's official website or through the retailer where the product was purchased.
You can visit the OLOV Store for more information and products: OLOV Store

© 2024 OLOV. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question