Escape P6

Escape P6 Air Outdoor/Garden Speaker User Manual

Model: P6

Introduction

Thank you for choosing the Escape P6 Air Outdoor/Garden Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The Escape P6 Air is a high-quality portable HiFi music system designed for superior sound quality and versatile connectivity, perfect for both indoor and outdoor environments.

What's in the Box

- Escape P6 Air Speaker (with built-in battery)
- Touchpad
- Power Cable

Please inspect all components for any signs of damage. If anything is missing or damaged, contact your retailer or Escape customer support.

Setup

Initial Charging

Before first use, fully charge the Escape P6 Air speaker. Connect the power cable to the speaker's power input and plug it into a suitable power outlet. The charging indicator will show the charging status. A full charge provides up to 16 hours of listening at background volume or 8 hours at typical listening volume.



Figure 1: Charging and Powering On. The speaker features a powerful battery for extended use.

Placement

The Escape P6 Air is designed for versatile placement, both indoors and outdoors. Its robust construction and IPX4 weather resistance make it suitable for terraces, poolsides, and gardens. Ensure the speaker is placed on a stable, flat surface.



Figure 2: Optimal placement for 360-degree sound in an outdoor setting.

Operating Instructions

Connectivity Options

The Escape P6 Air offers multiple wireless connectivity options:

- **Bluetooth:** For direct connection from your smartphone, tablet, or other Bluetooth-enabled devices.
- **Wi-Fi Streaming (AirPlay 2, Google Cast, Roon):**For high-quality, multi-room audio streaming over your home network. This provides a more stable connection than Bluetooth, especially when Wi-Fi is available.



Figure 3: Weather-resistant controls for easy operation in any environment.

Pairing via Bluetooth

1. Ensure the speaker is powered on.
2. Activate Bluetooth on your device.
3. Select "Escape P6 Air" from the list of available devices.
4. Once paired, the speaker will confirm the connection.

Wi-Fi Setup (AirPlay 2, Google Cast, Roon)

For Wi-Fi connectivity, download the official Escape Control App (available for iOS and Android). The app will guide you through connecting your speaker to your home Wi-Fi network and configuring AirPlay 2, Google Cast, or Roon.
The app also allows for comfortable control of the speaker and access to equalizer settings.

Twin Mode (Stereo Configuration)

You can combine two Escape P6 Air speakers in a stereo configuration via Bluetooth for an enhanced audio experience.

Refer to the Escape Control App or the full online manual for detailed instructions on setting up Twin Mode.

Maintenance

Cleaning

The Escape P6 Air is designed for easy cleaning. Use a soft, damp cloth to wipe down the exterior. Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish. Ensure the speaker is dry before connecting it to power.

Weather Resistance (IPX4)

The speaker is IPX4 weather-resistant, meaning it is protected against splashing water from any direction. While it can withstand rain and splashes, it is not designed to be submerged in water. Always ensure the charging port cover is securely closed when used outdoors.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. If storing the speaker for an extended period, charge it to approximately 50% and store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
No power/Speaker not turning on	Battery is discharged; Power cable not connected properly.	Charge the speaker fully. Ensure the power cable is securely connected.
No sound/Low volume	Volume too low on speaker or source device; Incorrect input selected; Device not paired.	Increase volume on both speaker and source. Check Bluetooth/Wi-Fi connection. Re-pair if necessary.
Bluetooth pairing issues	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in pairing mode. Move device closer. Reduce interference from other wireless devices.
Wi-Fi connection unstable/slow	Weak Wi-Fi signal; Router issues; Speaker too far from router/repeater.	Ensure strong Wi-Fi signal. Restart router. Move speaker closer to router or use a Wi-Fi extender.
Sound quality not as expected	Poor audio source quality; EQ settings; Speaker placement.	Try a different audio source. Adjust EQ settings via the Escape Control App. Experiment with speaker placement.

If the problem persists after trying these solutions, please contact Escape customer support.

Specifications

Feature	Detail

Feature	Detail
Model Number	P6
Product Dimensions	20 x 20 x 55 cm
Weight	7.5 Kilograms
Maximum Output Power	60 Watt RMS
Frequency Response	20Hz-20KHz
Connectivity Technology	Bluetooth, WLAN (AirPlay 2, Google Cast, Roon)
Audio Output Mode	Stereo
Special Features	Portable, IPX4 Weather-resistant, Multiroom capable (Twin-Mode)
Battery Life	Up to 16 hours (background volume), 8 hours (typical volume)
Manufacturer	Escape BV
Country of Origin	China

Warranty and Support

The Escape P6 Air speaker comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Escape website. In case of any issues or for technical support, please contact the seller, **sonoro audio GmbH**, or Escape customer service directly.
For returns, the product has a return policy of 14 days for refund/replacement, as per the seller's terms.

© 2025 Escape. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question