Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BLACK+DECKER BCRC115-XJ

BLACK+DECKER 3.6V Cordless Electric Rotary Cutter

Model: BCRC115-XJ

Introduction

The BLACK+DECKER BCRC115-XJ 3.6V Cordless Electric Rotary Cutter is a versatile tool designed for effortless cutting of various materials. Its compact and ergonomic design, combined with a self-sharpening blade, makes it ideal for crafting projects, opening packages, and general household cutting tasks. This manual provides essential information for safe operation, setup, maintenance, and troubleshooting to ensure optimal performance and longevity of your rotary cutter.

Image: The BLACK+DECKER 3.6V Cordless Electric Rotary Cutter, showcasing its white and black body with blue accents and the rotary blade.

Safety Information

Always observe the following safety precautions when using your electric rotary cutter:

- **Read all instructions:** Before operating the tool, thoroughly read and understand all safety warnings and instructions.
- **Keep hands clear:** Always keep hands and fingers away from the rotating blade during operation.
- **Use safety trigger:** The tool is equipped with a safety trigger. Ensure it is engaged when the tool is not in use to prevent accidental activation.
- **Wear eye protection:** Always wear appropriate eye protection when operating the rotary cutter.
- **Secure workpiece:** Ensure the material being cut is stable and secure to prevent slipping.
- **Do not force the tool:** Allow the tool to cut at its own pace. Forcing it can lead to injury or damage to the tool.
- **Store safely:** Store the tool in a dry, secure place out of reach of children when not in use.
- **Use only specified charger:** Only use the provided USB charger for charging the device.

Product Overview and Components

Familiarize yourself with the key components of your BLACK+DECKER rotary cutter:

Image: A diagram highlighting the main parts of the rotary cutter, including the comfortable grip, safety lock, extra-long handle and trigger, and the 40mm blade with its guard.

- **Comfortable Grip:** Ergonomically designed for secure and comfortable handling.
- **Safety Lock:** A mechanism to prevent accidental activation of the blade.
- **Extra-Long Handle and Trigger:** Provides enhanced control and ease of use.
- **40mm Blade and Guard:** The self-sharpening rotary blade for cutting, protected by a guard.

Setup

Charging the Battery

Your rotary cutter is powered by a 3.6V Lithium-Ion battery. Before first use, or when the battery is low, charge the device using the provided USB charger.

1. Locate the USB charging port on the device.

2. Connect the provided USB charging cable to the rotary cutter.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., wall adapter, computer USB port).
4. The charging indicator lights will illuminate, showing the charging status. A full charge takes approximately 3 hours.
5. Once fully charged, disconnect the USB cable. The device provides up to 35 minutes of continuous use on a full charge.

Image: The USB charging cable included with the rotary cutter.

Image: The rotary cutter connected to a charging cable, with green indicator lights visible, signifying charging status.

Operating Instructions

General Operation

Image: A hand demonstrating the comfortable grip and handling of the rotary cutter.

1. **Prepare your material:** Lay the material you wish to cut on a flat, stable surface. Ensure there are no obstructions.
2. **Grip the tool:** Hold the rotary cutter firmly by the comfortable grip.
3. **Activate the blade:** Press the safety lock button (if applicable) and then squeeze the main trigger to start the rotary blade.
4. **Begin cutting:** Gently guide the rotary cutter along the desired cutting line. The self-sharpening blade is designed for smooth and effortless cuts.
5. **Release trigger:** Release the trigger to stop the blade. Ensure the safety lock is engaged when not actively cutting.

Compatible Materials

This rotary cutter is suitable for a wide range of materials, including but not limited to:

- Cardstock
- Fabric
- Carpet
- Vinyl
- Denim
- Corrugated cardboard
- Leather
- Plastic (thin sheets)

It is suitable for straight, bias, or curved cuts.

Image: A user demonstrating fast and smooth cuts on fabric using the rotary cutter.

Image: A collage showing various materials like felt, leather, cardboard, vinyl, and denim, illustrating the wide range of materials the cutter can handle.

Image: A user cutting a large piece of corrugated cardboard with the rotary cutter.

Image: A user demonstrating how to open tough plastic product packaging using the rotary cutter.

Image: A user cutting a roll of burlap fabric on a table using the rotary cutter.

Image: A user cutting a large cardboard box on a table, demonstrating the ease of use for breaking down packaging.

Maintenance

Blade Care

The BLACK+DECKER rotary cutter features a self-sharpening blade, which reduces the need for manual sharpening. However, proper care is still important:

- **Keep clean:** After each use, especially when cutting fibrous or sticky materials, ensure the blade and surrounding area are free of debris. Use a dry cloth or soft brush to gently clean.
- **Inspect for damage:** Periodically inspect the blade for any signs of damage or excessive wear. If the blade becomes dull or damaged despite its self-sharpening feature, replacement blades may be available from BLACK+DECKER.

General Cleaning and Storage

- **Wipe down:** Use a slightly damp cloth to wipe the exterior of the tool. Do not immerse the tool in water or any other liquid.
- **Dry thoroughly:** Ensure the tool is completely dry before storing.
- **Store in a safe place:** Store the rotary cutter in a cool, dry place, away from direct sunlight and out of reach of children.

Troubleshooting

Problem	Possible Cause	Solution
Tool does not turn on.	Battery is depleted. Safety lock is engaged.	Charge the battery fully. Ensure the safety lock is disengaged before pressing the trigger.
Cutter is not cutting effectively.	Blade is dirty or obstructed. Material is too thick or hard.	Clean the blade and surrounding area. This tool is designed for specific materials; do not attempt to cut materials beyond its capacity.
Battery life is shorter than expected.	Battery not fully charged. Cutting very dense materials frequently.	Ensure the battery is charged for the full 3 hours. Continuous cutting of thick materials can reduce battery life. Allow the tool to rest if it feels strained.

Specifications

Feature	Detail
Model Number	BCRC115-XJ
Battery Voltage	3.6V
Battery Type	Lithium-Ion (included)
Battery Life (approx.)	35 minutes
Charger Type	USB charger

Feature	Detail
Charging Time (approx.)	3 hours
Blade Type	Self-sharpening rotary blade
Included Accessories	1 x Electric Rotary Cutter, 1 x Self-Sharpening Blade, 1 x USB Charging Cable
Dimensions (L x W x H)	9.29 x 2.17 x 2.17 inches
Weight	0.02 ounces (approx. 0.58 grams)

Warranty and Support

For warranty information, technical support, or to purchase replacement parts and accessories, please visit the official BLACK+DECKER website or contact their customer service. Keep your proof of purchase for warranty claims.

Online Support: www.blackanddecker.com

Refer to the product packaging or the BLACK+DECKER website for specific warranty terms and conditions applicable to your region.

© 2025 BLACK+DECKER. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6FLFMQP

More documents and user manuals: **https://manuals.plus/**