Disney TRHA22129

Disney Minnie Projector Watch

Instruction Manual

1. Introduction

This manual provides essential information for the safe and effective use of your Disney Minnie Projector Watch. Please read this manual thoroughly before using the product and retain it for future reference.



Figure 1.1: Front view of the Disney Minnie Projector Watch. The watch is pink with a digital time display and a graphic of Minnie Mouse at the bottom of the watch face. The strap is also pink with white polka dots and Minnie Mouse silhouettes.

The Disney Minnie Projector Watch is designed to display time and project various images. It is a fun and interactive accessory for children.

2. Safety Information

- This product is made from non-toxic and safe materials.
- Not suitable for children under 3 years due to small parts that could be a choking hazard.
- Do not aim the projector light directly into eyes.
- Keep away from extreme temperatures and direct sunlight.
- Do not immerse the watch in water. It is not waterproof.

3. Product Components

Familiarize yourself with the main components of your projector watch:

1. **Watch Face:** Displays the digital time.
2. **Projector Lens:** Located on the right side of the watch, used to project images.
3. **Time Setting Buttons:** Small buttons on the left side for adjusting time.
4. **Image Selector Dial:** A rotating dial near the projector lens to change projected images.
5. **Battery Compartment:** Located on the back of the watch.



Figure 3.1: Side view of the watch, showing the projector lens on the right side and the time setting buttons on the left.



Figure 3.2: Back view of the watch, indicating the battery compartment cover.

4. Setup

4.1 Setting the Time

1. Locate the two small buttons on the left side of the watch case.
2. Press the top button (usually labeled 'A' or 'Mode') repeatedly until the hour digit flashes.
3. Use the bottom button (usually labeled 'B' or 'Set') to adjust the hour.
4. Press the top button again to move to the minute digit, then use the bottom button to adjust the minutes.
5. Continue this process for setting the month, day, and year if applicable.
6. Press the top button one last time to confirm and exit time setting mode.

4.2 Battery Installation/Replacement

The watch comes with pre-installed batteries. If the display dims or the projector light weakens, it's time to replace the batteries.

1. Using a small Phillips head screwdriver, carefully remove the screws from the battery compartment cover on the back of the watch (refer to Figure 3.2).
2. Remove the cover.
3. Note the orientation of the existing batteries.
4. Replace with new batteries of the same type (e.g., LR41 or AG3, typically 3-4 cells).
5. Replace the cover and secure with screws. Do not overtighten.

Note: *Battery replacement should be performed by an adult. Dispose of old batteries responsibly.*

5. Operating Instructions

5.1 Using the Watch Function

- To view the time, simply look at the digital display on the watch face.
- The watch typically displays hours and minutes. Some models may also show date.

5.2 Using the Projector Function

1. Point the projector lens (on the right side of the watch) towards a flat, light-colored surface, such as a wall or ceiling.
2. Rotate the image selector dial, located around the projector lens, to cycle through the available images.
3. Press the button next to the projector lens (often the same button used to activate the light) to illuminate and project the image.
4. Adjust the distance from the surface to focus the image. Closer distances result in smaller, sharper images; further distances result in larger, less sharp images.



Figure 5.1: Illustration of the projector function, showing images being projected from the watch and a collection of interchangeable image discs.



Figure 5.2: Demonstrating the projection feature. The watch is held by a hand, and a projected image is visible on a surface.

6. Maintenance

- **Cleaning:** Wipe the watch with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** If the watch will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.
- **Water Exposure:** Avoid exposing the watch to water or high humidity, as it is not waterproof.

7. Troubleshooting

Problem	Possible Cause	Solution
Watch display is dim or blank.	Low or dead batteries.	Replace batteries (refer to Section 4.2).
Projector light is weak or not working.	Low or dead batteries.	Replace batteries (refer to Section 4.2).
Projected image is blurry.	Incorrect focus distance.	Adjust the distance between the watch and the projection surface.
Cannot change projected images.	Image selector dial stuck or not rotated fully.	Gently rotate the image selector dial to the next position. Ensure no debris is blocking it.

8. Specifications

Feature	Detail
Brand	Disney
Model Number	TRHA22129
Generic Name	Watch
Product Dimensions (LxWxH)	30 x 25 x 8 cm
Item Weight	200 g

Feature	Detail
Net Quantity	1 count
Manufacturer	Trucarekidz Pvt Ltd
Date First Available	26 September 2022

9. Warranty and Support

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the retailer where the product was acquired.

Manufacturer Contact Information:

Trucare Kidz India Pvt Ltd
309, Kamla Space, Santacruz W,
Mumbai - 400054, India

For further assistance, please visit the official Disney website or contact their customer service.

© 2024 Disney. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question