Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM TV Stand

T4TREAM Farmhouse TV Stand User Manual

Model: TV Stand

Introduction

Thank you for choosing the T4TREAM Farmhouse TV Stand. This media console is designed to accommodate TVs up to 75 inches, offering a blend of modern farmhouse aesthetics and practical storage solutions for your living space. Its robust construction and thoughtful design ensure both durability and functionality.



Image: The T4TREAM Farmhouse TV Stand, showcasing its antique white finish, barn-style sliding doors, and central open shelving, supporting a large television in a living room setting.

Safety Information

Please read and understand all safety precautions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Carefully check that all parts are intact and accounted for before beginning assembly.
- Read all instruction manual tips and complete each step thoroughly before proceeding to the next.
- Do not fully tighten screws until assembly is complete to ensure proper alignment of holes.
- Keep the TV stand away from sharp objects to prevent damage to the finish.
- It is recommended to use hand tools for assembly; power tools may cause overtightening and damage.
- For any quality problems or concerns, please contact customer support for a satisfactory solution.

Product Features

- **Generous Dimensions:** Measuring 66" L × 15.75" W × 25" H, this stand is designed to accommodate flat-screen TVs up to 75 inches.
- **Barn-Inspired Style:** Features double barn door cabinets and an open cubby, providing ample storage while adding a modern farmhouse aesthetic to your living room. Crafted from FSC-Certified wood with a weathered finish and rustic metal accents.
- **Customizable Storage:** All interior shelves are adjustable, allowing you to customize the space for media players, board games, or decorative items.
- **Integrated Cable Management:** Three pre-punched holes on the back panel help organize messy wires, maintaining a neat and tidy appearance.
- **Enhanced Stability:** Includes two additional support legs underneath the sturdy table to prevent sagging and ensure long-term durability.



Image: Detailed views highlighting key features such as the decorative metal accents, adjustable shelving, robust leg design, and convenient cable management openings.

Assembly Instructions

The T4TREAM TV Stand is designed for easy assembly. Please follow the step-by-step instructions provided in the package. Each screw and pin is coded, and boards are clearly labeled to simplify the process.

1. Unpack all components and verify against the parts list in your included manual.
2. Lay out all pieces on a soft, clean surface to prevent scratches.
3. Follow the numerical sequence of steps in the assembly guide.
4. Insert dowels and secure with cam locks as indicated.
5. Attach the back panels, ensuring wires can pass through the pre-drilled holes.
6. Install the sliding barn doors onto their tracks.
7. Adjust shelves to your desired height using the pre-drilled holes.
8. Once all components are in place, carefully tighten all screws for a secure and stable structure.



Image: A detailed diagram illustrating the overall dimensions (66" W x 25" H x 15.7" D) and individual shelf weight capacities (top 150 lbs, middle 30 lbs, bottom 50 lbs).

For a visual guide to the product's features and design, please watch the official video:

Your browser does not support the video tag.

Video: An official overview of the T4TREAM Farmhouse Barn Door TV Stand, highlighting its design, features, and suitability for TVs up to 75 inches.

Operating Instructions

The T4TREAM TV Stand is designed for straightforward use in your living room or bedroom.

- **Placing Your TV:** Position your television centrally on the top surface. The stand is built to safely support TVs up to 75 inches and a weight of 150 pounds.
- **Utilizing Storage:**
  - Use the central open cubbies for media devices like DVD players, gaming consoles, or soundbars.
  - Slide the barn doors to reveal or conceal the side storage cabinets, perfect for organizing entertainment accessories, books, or decorative items.
  - Adjust the height of the interior shelves by repositioning the shelf pins in the pre-drilled holes to accommodate items of various sizes.
- **Cable Management:** Route all power cords and signal cables through the pre-punched holes in the back panel to keep them tidy and out of sight.

Maintenance

To ensure the longevity and appearance of your T4TREAM TV Stand, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as they may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining or water damage to the engineered wood.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.
- **Weight Distribution:** Distribute weight evenly across the top surface and shelves to maintain stability and prevent warping. Do not exceed the specified weight limits.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.

Troubleshooting

If you encounter any issues with your T4TREAM TV Stand, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Damaged or Missing Parts upon Arrival	Shipping damage or packaging error.	Do not proceed with assembly. Contact T4TREAM customer support immediately with your order details for replacement parts.
Difficulty Aligning Holes During Assembly	Screws tightened prematurely; incorrect part orientation.	Loosen all screws slightly, realign parts, then retighten once everything is correctly positioned. Double-check part labels and orientation in the manual.
Stand Feels Unstable or Wobbly	Screws are not fully tightened; uneven floor surface.	Ensure all screws are securely tightened. If the floor is uneven, use furniture pads or shims under the legs to level the stand.

Problem	Possible Cause	Solution
Sliding Doors Do Not Move Smoothly	Track obstruction; misaligned doors.	Check the sliding tracks for any debris and clear them. Ensure the doors are correctly seated on the tracks and are not obstructed by items inside the cabinet.

Specifications

Attribute	Detail
Brand	T4TREAM
Model	TV Stand
Color	Antique White
Product Dimensions (L x W x H)	66" x 15.75" x 25" (approx. 15.92"D x 67.04"W x 25.4"H)
Weight Limit (Top Surface)	150 Pounds
Item Weight	92.4 Pounds
Number of Shelves	6 (including adjustable shelves)
Assembly Required	Yes
Top Material Type	Engineered Wood
Handle Material	Metal
Accommodates TV Size	Up to 75 inches

Warranty & Support

T4TREAM is committed to providing quality products and customer satisfaction. For any quality problems or concerns, please contact the seller directly for assistance. They are dedicated to providing a satisfactory solution.
Additional protection plans may be available for purchase through the retailer. Please refer to your purchase receipt or the product listing for details on extended warranty options.
For general inquiries or support, you may visit the official T4TREAM Store:T4TREAM Furniture Store

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6H7WVSM

More documents and user manuals: **https://manuals.plus/**