Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

eufy LR30 Hybrid

eufy RoboVac LR30 Hybrid User Manual

Model: LR30 Hybrid (T2193)

1. Introduction

The eufy RoboVac LR30 Hybrid is an advanced robotic vacuum cleaner and mop designed to provide efficient and thorough cleaning for your home. Featuring iPath™ Laser Navigation, powerful 3000Pa suction, and intelligent mapping capabilities, this device simplifies floor maintenance. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance of your RoboVac.



Image 1.1: The eufy RoboVac LR30 Hybrid robot vacuum.

2. What's in the Box

Carefully unpack all components and check against the list below. If any items are missing or damaged, please contact eufy support.

- RoboVac LR30 Hybrid+

- Charging Base
- Power Adapter
- Waterproof Base
- Mopping Module (with washable cloth)
- Side Brushes (spare set included)
- Extra Filter
- Cleaning Tool
- User Manual
- Quick Start Guide



Image 2.1: All components included with the RoboVac LR30 Hybrid. This includes the robot, charging dock, power adapter, side brushes, cleaning tool, mop pad, and filter.

3. Setup

3.1 Charging Base Placement

1. Place the charging base against a wall in an open, uncluttered area.
2. Ensure there is at least 0.5 meters (1.6 feet) of clear space on both sides of the charging base and 1.5 meters (4.9

feet) in front of it.

3. Connect the power adapter to the charging base and plug the other end into a wall outlet.
4. Attach the waterproof base to the charging base if you plan to use the mopping function frequently.

3.2 Initial Charging

Before first use, fully charge the RoboVac. Place the RoboVac onto the charging base, ensuring the charging pins make contact. The indicator lights on the RoboVac will show charging status. A full charge takes approximately 5-6 hours.

3.3 App Download and Connection

1. Download the **eufy Clean** app from the App Store (iOS) or Google Play (Android).
2. Create an account or log in.
3. Tap the '+' icon to add a new device and select 'RoboVac LR30 Hybrid'.
4. Follow the on-screen instructions to connect your RoboVac to your home Wi-Fi network. Ensure your phone is connected to a 2.4GHz Wi-Fi network during setup.

4. Operating Instructions

4.1 Starting and Stopping Cleaning

- **Start Cleaning:** Press the power button on the RoboVac or tap 'Start' in the eufy Clean app. The RoboVac will begin cleaning in Auto mode.
- **Pause Cleaning:** Press the power button on the RoboVac or tap 'Pause' in the app.
- **Return to Charging Base:** Press the Home button on the RoboVac or tap 'Recharge' in the app.

4.2 Suction Power Adjustment

You can adjust the suction power via the eufy Clean app to suit different cleaning needs. Available modes include:

- **Quiet:** 600 Pa
- **Standard:** 1200 Pa
- **Turbo:** 1800 Pa
- **Max:** 3000 Pa



Image 4.1: Visual representation of the four suction power levels: Quiet (600 Pa), Standard (1200 Pa), Turbo (1800 Pa), and Max (3000 Pa).

4.3 Using the Mopping Function

1. Fill the water tank with clean water. Do not use cleaning solutions that are not approved by eufy.
2. Attach the washable mop cloth to the mopping module.
3. Slide the filled mopping module into the back of the RoboVac until it clicks into place.
4. Select the desired water flow level (3 levels available) in the eufy Clean app.
5. Start a cleaning cycle. The RoboVac will vacuum and mop simultaneously.



Image 4.2: The RoboVac LR30 Hybrid with its 200ml capacity water tank inserted, illustrating the controllable water flow with 3 levels.

4.4 App Features (Mapping and Customization)

The eufy Clean app provides extensive control and customization options:

- **iPath™ Laser Navigation:** Creates an accurate map of your home for efficient cleaning paths.
- **Multi-Floor Mapping:** The RoboVac can store up to 3 different floor maps, ideal for multi-story homes.
- **No-Go Zones & Virtual Walls:** Define areas where the RoboVac should not enter or clean.
- **Zone Cleaning:** Select specific rooms or areas to clean.

- **Scheduled Cleaning:** Set cleaning schedules for automatic operation.



Image 4.3: The RoboVac LR30 Hybrid demonstrating its ability to map and store layouts for multiple floors (1F, 2F, 3F).



Image 4.4: The RoboVac LR30 Hybrid illustrating the No-Go Zones feature, preventing it from entering designated areas.

4.5 Voice Control

The RoboVac LR30 Hybrid is compatible with Amazon Alexa and Google Assistant. To enable voice control:

1. Open the Alexa or Google Home app.
2. Search for the 'eufy Clean' skill/action and enable it.
3. Link your eufy Clean account.
4. Use commands such as:

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6NZ5Y7V

More documents and user manuals: **https://manuals.plus/**