FABULETTA FVS001

FABULETTA FSV001/FSV101 Cordless Stick Vacuum Cleaner Rechargeable Battery User Manual

1. Product Overview

This document provides instructions for the FABULETTA rechargeable battery, designed for use with FSV001 and FSV101 cordless stick vacuum cleaners. This battery is rechargeable and detachable, featuring a capacity of 7*2200 mAH. It includes built-in circuit protection to ensure safe and stable operation.



Image 1.1: The FABULETTA rechargeable battery unit.

2. Safety Instructions

- Do not disassemble, open, or shred the battery pack.
- Do not expose the battery pack to heat or fire. Avoid storage in direct sunlight.
- Do not short-circuit a battery pack.
- Do not expose battery packs to mechanical shock.
- In case of battery leakage, avoid contact with skin and eyes. If contact occurs, wash the affected area with plenty of water and seek medical advice.
- Keep battery packs out of reach of children.
- Dispose of used battery packs promptly and properly according to local regulations.

3. Setup and Installation

3.1 Battery Installation/Replacement

To install or replace the battery in your FABULETTA cordless stick vacuum cleaner (models FSV001 or FSV101), align the battery pack with the designated slot on the vacuum's main body. Push firmly until you hear a click, indicating it is securely in place. To remove the battery, press the red 'Release' button located on the battery unit and slide it out.



Image 3.1: Close-up view of the red 'Release' button on the battery unit.

Ensure the battery is correctly oriented before attempting to insert it. Do not force the battery into place.

4. Operating Instructions

4.1 Charging the Battery

The battery is rechargeable and detachable. To charge, connect the appropriate charger (not included with the battery, typically supplied with the vacuum cleaner) to the charging port on the battery unit. Plug the charger into a standard wall outlet.



Image 4.1: Side view of the battery unit, showing the charging port.

4.2 Indicator Lights

The indicator lights on the battery unit will illuminate when charging. They will stop flashing once the battery is fully charged. Monitor these lights to ensure your battery is adequately charged for optimal performance.

Important: Low power will affect the vacuum's suction performance. Please charge the battery promptly when it indicates low power (e.g., only 1 indicator light on).

5. Maintenance

To ensure the longevity and optimal performance of your battery, keep it clean and dry. Avoid exposing it to extreme temperatures. Store the battery in a cool, dry place when not in use for extended periods.

6. Troubleshooting

6.1 Low Suction Performance

- **Issue:** Vacuum has reduced suction power.
- **Solution:** Check the battery indicator lights. If only one light is on, the battery is low. Charge the battery fully.

6.2 Battery Not Charging

- **Issue:** Indicator lights do not illuminate when connected to the charger.
- **Solution:** Ensure the charger is properly connected to both the battery and a working power outlet. Verify the charger itself is functional. If the issue persists, contact customer support.

7. Specifications

Feature	Detail
Compatible Models	Fabuletta FSV001, FSV101 Cordless Stick Vacuum Cleaner
Battery Capacity	7*2200 mAH
Battery Type	Rechargeable & Detachable Lithium Ion
Safety Features	Built-in circuit protection
Item Weight	15.8 ounces
Package Dimensions	4.69 x 3.58 x 3.31 inches

8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your FABULETTA cordless stick vacuum cleaner or visit the official FABULETTA website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find a replacement battery for the Fabuletta FSV101 cordless vacuum cleaner, as my current one only lasts a few minutes?

If your Fabuletta FSV101 battery is only lasting a few minutes, it likely needs to be replaced. You can find the

official replacement battery (Model: FVS001) through the following channels:Amazon: The battery is listed...

Read full answer