Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OLEVS L6631

OLEVS Women's Automatic Mechanical Watch L6631 Instruction Manual

Model: L6631 | Brand: OLEVS

1. Product Overview

The OLEVS L6631 is an automatic mechanical wristwatch designed for women, featuring a blend of rose gold and ceramic elements. It includes a date display and is built with a durable movement and water-resistant casing for daily use.



Figure 1: OLEVS L6631 Watch and Bracelet

Key Features:

- **Movement:** Original automatic mechanical movement with manual winding capability.
- **Power Reserve:** Approximately 45 hours.
- **Water Resistance:** 30 meters (3 ATM) for daily use.
- **Material:** Rose gold-plated stainless steel and ceramic band.
- **Dial:** Mother-of-pearl dial with crystal accents and a heart-shaped date calendar.
- **Case Back:** Transparent (see-through) case back to view the movement.

2. Setup and Initial Operation

2.1 Unpacking

Carefully remove the watch from its packaging. Inspect for any visible damage.

2.2 Initial Winding

This watch features an automatic mechanical movement. For initial use or after the watch has stopped, it requires manual winding to build up power reserve.

1. Locate the crown on the side of the watch case.
2. Ensure the crown is in its normal, pushed-in position (Position 0).
3. Rotate the crown clockwise 30 to 40 times. This will manually wind the mainspring.
4. The watch will start ticking.

Once the watch is running, normal arm movements will automatically wind the watch. If worn daily for at least 8-10 hours, manual winding should not be necessary.



Figure 2: Watch Features - Water Resistance, Glass, Buckle, Movement

3. Operating Instructions

3.1 Setting the Time

1. Pull the crown out to Position 2 (the outermost position). The second hand will stop.
2. Rotate the crown to set the hour and minute hands to the desired time.
3. Push the crown back into Position 0 to restart the second hand and begin timekeeping.

3.2 Setting the Date

The watch features a heart-shaped date calendar.

1. Pull the crown out to Position 1 (the middle position).
2. Rotate the crown clockwise or counter-clockwise to adjust the date.
3. Once the correct date is displayed, push the crown back into Position 0.

Important: Avoid setting the date between 9 PM and 3 AM, as this is when the date change mechanism is engaged and could cause damage.



Figure 3: Watch Face with Date Display

4. Maintenance and Care

4.1 Water Resistance

The watch is rated for 30 meters (3 ATM) water resistance. This means it is suitable for daily use, such as accidental splashes, rain, and hand washing. It is **not** suitable for:

- Showering or bathing
- Swimming or diving
- Water sports
- Exposure to drastic changes in water pressure

Always ensure the crown is fully pushed in before any contact with water.

4.2 Cleaning

Wipe the watch case and band with a soft, dry cloth. For ceramic and stainless steel parts, a slightly damp cloth can be used, followed by a dry cloth. Avoid using harsh chemicals or abrasive materials.

4.3 Storage

When not wearing the watch for extended periods, store it in a cool, dry place away from direct sunlight and strong magnetic fields. A watch box is recommended to protect it from dust and scratches.

4.4 Bracelet Adjustment

The watch bracelet may require adjustment to fit your wrist. This typically involves removing or adding links. It is recommended to have this done by a professional jeweler or watchmaker to prevent damage to the ceramic links.

5. Troubleshooting

- **Watch has stopped or is running inaccurately:**

  As an automatic mechanical watch, it relies on movement to stay wound. If not worn for an extended period, it will stop. Manually wind the watch by rotating the crown 30-40 times clockwise. Ensure you wear the watch regularly (8-10 hours daily) for consistent operation.

- **Date is not changing correctly:**

  Avoid setting the date between 9 PM and 3 AM. If the date is stuck, try advancing the time past 3 AM, then set the date, and finally set the correct time.

- **Condensation inside the watch:**

  This indicates a potential breach in water resistance. Stop using the watch immediately and contact customer support or a professional watch repair service.

6. Specifications

Brand	OLEVS
Model Number	L6631
Movement Type	Automatic Mechanical (Self-winding and Manual winding)
Power Reserve	Approx. 45 hours
Water Resistance	30 Meters (3 ATM)

Case Material	Rose Gold-plated Stainless Steel
Band Material	Ceramic and Rose Gold-plated Stainless Steel
Dial Window Material	High Hardness Glass
Product Dimensions	18 x 3.25 x 1.2 cm
Product Weight	370 g

7. Warranty and Support

Your OLEVS L6631 watch comes with the following guarantees:

- **30-Day Exchange Guarantee:** For products purchased on Amazon.
- **2-Year Quality Guarantee:** Covers manufacturing defects.

If you encounter any product defects or require assistance, please contact customer support via email. We aim to respond to inquiries within 24 hours.
For further support or inquiries, please refer to the seller's contact information provided at the time of purchase or on the product listing page.

© 2023 OLEVS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6SK82TT

More documents and user manuals: **https://manuals.plus/**