Armitron 40/8438BDG

Armitron Sport Digital Chronograph Watch

Model: 40/8438BDG

Introduction

This manual provides comprehensive instructions for the Armitron Sport Digital Chronograph Watch, Model 40/8438BDG. Please read this manual carefully to understand the features, operation, and maintenance of your new watch. Proper use and care will ensure long-lasting performance.

Key Features

- Metallic green resin case with a black metallic top ring.
- LCD display showing time, seconds, day, and date.
- Functions include: Chronograph, alarm, dual time, military time, and backlight.
- Green resin strap with a secure buckle closure.
- Water resistant up to 330 feet (100 meters).
- Equipped with a reliable quartz movement.

Product Overview





Figure 1: Front view of the Armitron Sport Digital Chronograph Watch. This image displays the watch face, including the digital time display, day, and date, along with the various function buttons labeled "SET", "ADJ", "MODE", and "EL".




ADJ

Figure 2: Side view of the Armitron Sport Digital Chronograph Watch. This image shows the profile of the watch, emphasizing the design of the resin case and the two control buttons located on the right side.





Figure 3: Back view of the Armitron Sport Digital Chronograph Watch. This image provides a clear view of the stainless steel case back, which often includes water resistance ratings, and the green resin strap with its buckle closure.

Setup

Initial Time Setting

1. Press the **MODE** button repeatedly until the time setting mode is displayed (usually indicated by flashing digits).
2. Use the **SET** or **ADJ** button to select the digit you wish to change (e.g., hours, minutes, seconds).
3. Press the **EL** or **ADJ** button to increase the selected digit. Hold to fast-forward.
4. Once the time is set, press the **MODE** button to confirm and exit the setting mode.

Date Setting

Follow a similar procedure as time setting. Navigate to the date setting mode using the**MODE** button and adjust the year, month, and day using the **SET** and **ADJ** buttons.

Operating Instructions

Chronograph Function

- Press **MODE** until "CHRONO" or "STOPWATCH" appears.
- Press **ADJ** to start the chronograph.
- Press **ADJ** again to pause.
- Press **SET** to reset the chronograph to zero.

Alarm Function

- Press **MODE** until "ALARM" mode is displayed.
- Use **SET** and **ADJ** to set the desired alarm time.
- Press **MODE** to activate/deactivate the alarm. An alarm icon will appear when active.

Backlight (EL)

Press the **EL** button to illuminate the display for a few seconds, allowing for visibility in low-light conditions.

Maintenance

- **Cleaning:** Wipe the watch with a soft, damp cloth. Avoid harsh chemicals or abrasive materials.

- **Water Resistance:** This watch is water resistant up to 100 meters (330 feet). It is suitable for showering, swimming, and snorkeling, but not for diving. Do not operate buttons underwater.
- **Battery Replacement:** When the display dims or functions become erratic, it may be time to replace the battery. It is recommended to have this done by a qualified watch technician to ensure water resistance is maintained.
- **Storage:** Store your watch in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace battery.
Time is incorrect.	Time not set correctly or accidental button press.	Reset the time according to the "Initial Time Setting" section.
Buttons are unresponsive.	Watch may be in a locked mode or internal issue.	Try pressing all buttons to see if it unlocks. If not, a reset or professional service may be needed.
Water inside the watch.	Water resistance compromised (e.g., buttons pressed underwater, seal failure).	Immediately take the watch to a qualified technician for inspection and repair. Do not attempt to dry it yourself.

Specifications

Brand: Armitron Sport

Model Number: 40/8438BDG

Movement: Quartz

Case Material: Resin

Strap Material: Resin

Water Resistance: 100 meters (330 feet)

Display Type: Digital LCD

Functions: Chronograph, Alarm, Dual Time, Military Time, Backlight

Batteries: 1 specific product requires batteries (Included)

Package Dimensions: 10.7 x 10.1 x 7.6 cm

Item Weight: 200 grams

First Available Date: August 24, 2022

Department: Men

ASIN: B0B6WQQMJT

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Armitron Sport website. Keep your proof of purchase for any warranty claims.
For further assistance or technical inquiries, please contact Armitron Sport customer service.

© 2024 Armitron Sport. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question