CIRCLE JOY HJ-VBGS-KB1-601807A-SS-FBA

CIRCLE JOY 5-in-1 Electric Wine Opener User Manual

Model: HJ-VBGS-KB1-601807A-SS-FBA

Introduction

Thank you for choosing the CIRCLE JOY 5-in-1 Electric Wine Opener Gift Set. This comprehensive set is designed to simplify your wine enjoyment experience, from opening to preserving. It includes an electric wine opener, a foil cutter, a wine pourer, a wine stopper, and a storage base.



Image: The complete CIRCLE JOY 5-in-1 Electric Wine Opener Gift Set, including the electric opener, foil cutter, pourer, stopper, and storage base.

Safety Information

- Keep the electric wine opener and its accessories out of reach of children.
- Do not immerse the electric wine opener in water or any other liquid.
- Avoid touching the corkscrew spiral when the device is in operation.
- Use only 4 AA batteries (not included) of the specified type. Do not mix old and new batteries or different types of batteries.
- Remove batteries if the device will not be used for an extended period.

- Do not attempt to open bottles with synthetic corks that are not designed for corkscrews.
- This product is intended for household use only.

Package Contents

- 1 x Electric Wine Opener
- 1 x Foil Cutter
- 1 x Wine Pourer
- 1 x Wine Stopper
- 1 x Storage Base



Image: All components of the wine opener set, including the electric opener, foil cutter, pourer, stopper, and storage base, displayed separately.

Setup

Battery Installation

The CIRCLE JOY Electric Wine Opener requires 4 AA batteries (not included) for operation.

1. Grip the upper part of the electric wine opener and twist the bottom clear casing counter-clockwise to detach it.
2. Insert 4 AA batteries into the battery compartment, ensuring correct polarity (+/-) as indicated inside the compartment.
3. Reattach the clear casing by aligning it and twisting clockwise until it locks securely.



Image: The electric wine opener with an illustration indicating the need for 4 AA batteries, which are not included.

Operating Instructions

Using the Foil Cutter

1. Place the foil cutter on top of the wine bottle.
2. Grip the bottle firmly and twist the foil cutter around the bottle neck to remove the foil seal.



Image: A hand demonstrating the use of the foil cutter to remove the foil from a wine bottle.

Operating the Electric Wine Opener

1. After removing the foil, place the electric wine opener vertically over the wine bottle, ensuring the corkscrew is centered over the cork.
2. Press and hold the **DOWN** button. The corkscrew will rotate clockwise, penetrate the cork, and automatically pull it out of the bottle.



Image: A hand pressing the 'down' button on the electric wine opener, indicating the cork removal process.

3. Once the cork is fully extracted from the bottle, lift the opener away from the bottle.
4. To release the cork from the opener, press and hold the**UP** button. The corkscrew will rotate counter-clockwise, releasing the cork.



Image: A hand pressing the 'up' button on the electric wine opener, illustrating the release of the cork from the device.



Image: A four-step visual guide demonstrating the process of removing a cork using the electric wine opener, from foil removal to cork release.

Using the Wine Pourer

Insert the wine pourer into the neck of the opened wine bottle. It helps to aerate the wine and prevent drips while pouring.

Using the Wine Stopper

After pouring, insert the wine stopper firmly into the bottle neck to preserve the wine's freshness. This stopper creates an airtight seal.

Maintenance

- **Cleaning:** Wipe the exterior of the electric wine opener and the storage base with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Foil Cutter, Pourer, and Stopper:** These accessories can be rinsed with warm water and mild soap. Ensure they

are completely dry before storing.

- **Storage:** Store all components in the provided storage base in a cool, dry place when not in use.
- **Battery Replacement:** Replace all 4 AA batteries when the opener's performance diminishes.

Troubleshooting

Problem	Possible Cause	Solution
Opener does not work.	Batteries are dead or incorrectly installed.	Replace batteries with new ones, ensuring correct polarity.
Cork is not fully extracted.	Opener not aligned vertically; cork is too tight or synthetic.	Ensure opener is perfectly vertical. For very tight or synthetic corks, multiple attempts or manual corkscrew may be needed.
Cork does not release from opener.	UP button not pressed or held long enough; cork is stuck.	Press and hold the UP button until the cork is fully released. If stuck, gently twist the cork while pressing the UP button.

Specifications

Brand: CIRCLE JOY

Model: HJ-VBGS-KB1-601807A-SS-FBA

Material: Stainless Steel

Color: Silver (5-in-1 Battery Operated Wine Set)

Power Source: 4 x AA Batteries (not included)

Item Weight: Approximately 15.9 ounces

Manufacturer: KLT



Image: A visual representation of key product specifications, including material, color, and finish type.

Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact CIRCLE JOY customer service directly. Contact details can typically be found on the manufacturer's official website or through your point of purchase.

© 2024 CIRCLE JOY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question