Nonbliep RH-069

Nonbliep RH-069 Wireless Game Controller Instruction Manual

Model: RH-069

Brand: Nonbliep

1. Introduction

This manual provides detailed instructions for the Nonbliep RH-069 Wireless Game Controller. This versatile gamepad is designed for use across multiple platforms, including PC, Android devices, and Nintendo Switch. It offers various connection methods to ensure a seamless gaming experience.

2. Package Contents

- Nonbliep RH-069 Wireless Game Controller x1
- USB-C Charging Cable x1
- USB Dongle x1
- Instruction Manual x1
- Warranty Card x1

3. Product Overview

The Nonbliep RH-069 controller features a standard gamepad layout with additional programmable buttons and a turbo function. It includes dual analog sticks, a D-pad, action buttons (A, B, X, Y), and shoulder/trigger buttons. The controller also incorporates vibration feedback for an immersive experience.



Figure 3.1: Front view of the Nonbliep RH-069 Wireless Game Controller. This image displays the controller's ergonomic design, dual analog sticks, D-pad, A/B/X/Y action buttons, and the illuminated Home button.

Button Layout

- **Left Analog Stick:** For movement and camera control.
- **Right Analog Stick:** For camera control and aiming.
- **D-Pad:** Directional input.
- **Action Buttons (A, B, X, Y):** Primary interaction buttons.
- **START/+ Button:** Pause, menu access.
- **SELECT/- Button:** Menu access, secondary functions.
- **Home Button:** Power on/off, system menu.
- **T Button:** Activates Turbo function for assigned buttons.
- **Shoulder Buttons (L1/LB, R1/RB):** Top-mounted buttons.
- **Trigger Buttons (L2/LT, R2/RT):** Rear-mounted analog triggers.
- **SET Button (on back):** For programming macros or custom button assignments.

- **USB-C Port:** For charging and wired connection.

4. Setup and Connection

4.1 Charging the Controller

Connect the supplied USB-C charging cable to the USB-C port on the controller and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The indicator light will show charging status. A full charge typically takes approximately 2-3 hours.

4.2 Connecting via Bluetooth (PC/Android/Switch)

1. Ensure the controller is sufficiently charged.
2. Press and hold the Home button for 3-5 seconds until the indicator lights begin to flash rapidly, indicating pairing mode.
3. On your device (PC, Android, Switch), navigate to Bluetooth settings.
4. Search for available devices and select "Pro Controller" or similar (name may vary).
5. Once connected, the indicator light on the controller will become solid.

4.3 Connecting via USB Dongle (PC/Android TV/Consoles)

1. Insert the USB dongle into an available USB port on your PC, Android TV, or compatible console.
2. Turn on the controller by pressing the Home button.
3. The controller should automatically connect to the dongle. The indicator light on the controller will become solid once connected.

4.4 Wired Connection (PC)

Connect the controller directly to your PC using the USB-C charging cable. The controller will be recognized as a wired gamepad and can be used immediately without requiring battery power.

5. Operating Instructions

5.1 Power On/Off

- **Power On:** Press the Home button.
- **Power Off:** Press and hold the Home button for 5 seconds. The controller will also automatically shut down after 5 minutes of inactivity to conserve battery.

5.2 Programmable Buttons (Macros)

The controller features programmable buttons on the back. To program a button:

1. Press the **SET** button on the back of the controller. The indicator light will flash.
2. Press the programmable button you wish to assign (e.g., M1, M2).
3. Press the sequence of buttons you want to assign to it.
4. Press the **SET** button again to save the macro. The indicator light will stop flashing.

5.3 Turbo Function

The Turbo function allows a button to repeatedly register input when held down.

1. Press and hold the **T** button.
2. While holding **T**, press the action button (e.g., A, B, X, Y, L1, R1, L2, R2) you wish to set to Turbo mode.
3. Release both buttons. The selected action button will now function in Turbo mode.
4. To disable Turbo for a button, repeat the process.

6. Maintenance

To ensure the longevity and optimal performance of your Nonbliep RH-069 controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Impact:** Do not drop or subject the controller to strong impacts, as this can damage internal components.
- **Liquid Exposure:** Keep the controller away from liquids. If it comes into contact with liquid, power it off immediately and allow it to dry completely before attempting to use it again.

7. Troubleshooting

7.1 Controller Not Connecting

- **Check Battery:** Ensure the controller is fully charged.
- **Re-pair:** Try re-pairing the controller via Bluetooth or re-inserting the USB dongle.
- **Device Bluetooth:** Verify that Bluetooth is enabled on your device and that it is discoverable.
- **Interference:** Move closer to your device and away from potential sources of wireless interference.

7.2 Buttons Not Responding Correctly

- **Reset Controller:** Locate the small reset button (often a pinhole) on the back of the controller and press it with a thin object (e.g., paperclip).
- **Recalibrate (if applicable):** Some systems allow controller calibration. Check your device's settings.
- **Firmware Update:** Check the Nonbliep official website for any available firmware updates for the controller.

7.3 Vibration Not Working

- **Game Support:** Ensure the game you are playing supports vibration feedback.
- **System Settings:** Check your device's system settings to ensure vibration is enabled for controllers.

8. Specifications

Product Name	Wireless Game Controller
Model No.	RH-069 (also referred to as JYS-069)
Battery Capacity	500mAh
Charging Voltage	DC 5V / 1A
Connection Method	Bluetooth / USB Dongle / Wired USB-C
Applicable Platform	Android, iOS, Nintendo Switch, PC
Product Dimensions	Approx. 3 x 2 x 2 inches (7.6 x 5.1 x 5.1 cm)
Product Net Weight	Approx. 12.9 ounces (365 grams)

9. Warranty and Support

The Nonbliep RH-069 Wireless Game Controller comes with a warranty. Please refer to the included Warranty Card for specific

terms and conditions. It is recommended to retain your purchase receipt and the instruction manual for future reference.
For technical support, troubleshooting assistance, or warranty claims, please contact Nonbliep customer service through their official website or the retailer where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question