TACTACAM c-fb-6

TACTACAM 6.0 Action Camera Instruction Manual

4K 60 FPS, 8X Zoom, Waterproof, Integrated Image Stabilization, One Touch Operation

Introduction

The TACTACAM 6.0 Action Camera is designed for outdoor enthusiasts seeking high-quality video and photo capture in challenging environments. With its robust construction and advanced features, it allows you to record your adventures with exceptional clarity and stability. This manual provides essential information for setting up, operating, and maintaining your TACTACAM 6.0.



Figure 1: TACTACAM 6.0 Action Camera

What's in the Box

- Battery
- Camera Body
- Remote Control
- Mount

Setup

1. Battery and Micro SD Card Installation

To install the battery and Micro SD card, twist the rear cap of the camera counter-clockwise to unlock and remove it. Insert the Tactacam Lithium-Ion battery with the gold-plated end facing inward. Insert the Micro SD card (sold separately) into its slot with the gold-plated contacts facing up until it clicks into place. Replace the rear cap and twist clockwise to lock.



Figure 2: Inserting Micro SD Card

2. Charging the Camera

The TACTACAM 6.0 can be charged by connecting the included USB-C cable to the port located at the rear of the camera (under the cap) and a power source. The battery can be charged while in the camera.



Figure 3: Camera Charging

3. App Connection (TACTACAM Connect)

Download the TACTACAM Connect app from your device's app store. This app allows you to control camera settings, view live footage, and manage media wirelessly. Ensure your phone's Wi-Fi is enabled and connect to the camera's generated Wi-Fi network. The app will guide you through the connection process.

Video 1: Control settings via Tactacam Connect app - Tactacam 6.0. This video demonstrates how to connect your TACTACAM 6.0 to the mobile app and adjust various settings.

Operating

1. One-Touch Operation

The TACTACAM 6.0 features simple one-touch operation. Press the power button once to turn on the camera and begin recording. The camera will vibrate twice to confirm it is recording. Press the power button again to pause recording. The camera will vibrate once to confirm pausing.

Video 2: Getting Started Tactacam 6.0. This video provides a comprehensive guide to the basic operation of the TACTACAM 6.0, including power on/off and recording.

2. Integrated Display Screen

The TACTACAM 6.0 features a newly integrated display screen that shows recording status, battery life, and remaining SD card space. You can also preview your footage directly on the screen without connecting to a smartphone.



Figure 4: TACTACAM 6.0 Integrated Display Screen

3. Mode Selection

The camera comes with preset modes for different recording scenarios (e.g., 4K 60 FPS, 1080p with 8x zoom, slow motion). You can switch between these modes directly on the camera's touchscreen or via the TACTACAM Connect app. The app also allows for customization of these modes.

4. Image Stabilization

The TACTACAM 6.0 features integrated image stabilization to ensure smooth and shake-free footage, even during dynamic activities. This feature can be enabled or disabled via the TACTACAM Connect app settings.

5. Mounting Options

The TACTACAM 6.0 is designed for versatile mounting. It can be attached to various equipment such as bows, firearms, and other accessories using compatible mounts (some sold separately). This allows for first-person perspective recording of your activities.



Figure 5: TACTACAM 6.0 mounted on a rifle



Figure 6: TACTACAM 6.0 mounted on a bow

Maintenance

1. Battery Care

Ensure the battery is fully charged before each use for optimal performance. Store the battery in a cool, dry place when not in use. Avoid extreme temperatures.

2. SD Card Management

Regularly offload your recorded footage from the Micro SD card to a computer or external storage device. Format the SD card periodically using the camera's settings or the TACTACAM Connect app to maintain optimal recording performance and prevent data corruption.

3. Cleaning

Wipe the camera body and lens with a soft, lint-free cloth. For stubborn dirt, use a slightly damp cloth. Do not use harsh chemicals or abrasive materials, as they may damage the camera's finish or lens.

Troubleshooting

If you encounter issues with your TACTACAM 6.0, try the following basic troubleshooting steps:

- **Camera Not Turning On:** Ensure the battery is fully charged and properly inserted.
- **Recording Issues:** Check if the Micro SD card is inserted correctly and has sufficient free space. Try formatting the SD card.
- **App Connectivity Problems:** Ensure the camera's Wi-Fi is enabled and your phone is connected to the camera's Wi-Fi network. Restart both the camera and the app.
- **Poor Video Quality:** Check your selected recording mode and ensure sufficient lighting. Verify image stabilization is enabled if needed.

For more detailed troubleshooting or persistent issues, refer to the official TACTACAM support resources.

Specifications

Feature	Detail
Brand Name	TACTACAM
Item Weight	11.3 ounces
Package Dimensions	8.46 x 4.49 x 1.93 inches
Item Model Number	c-fb-6
Special Features	Time Lapse
Video Capture Resolution	4K
Maximum Focal Length	30
Maximum Aperture	6 f
Flash Memory Type	Micro SD
Supported Audio Format	AAC, MP3
Screen Size	1.5 Inches
Connectivity Technology	Wi-Fi

Warranty & Support

For warranty information and technical support, please visit the official TACTACAM website or contact their customer service. Keep your proof of purchase for warranty claims.

TACTACAM Support:

Email: support@tactacam.com

Phone: (218) 282-5650

Website: www.tactacam.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question