Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit 219863500

ZdalaMit 219863500 Replacement Remote Control User Manual

For Epson Projectors

Introduction

This manual provides instructions for the ZdalaMit 219863500 replacement remote control, designed for use with various Epson projector models. This remote offers direct functionality without the need for programming, ensuring a straightforward user experience.

Please read this manual thoroughly to understand the remote's features and ensure proper operation.

Setup

1. Battery Installation

The remote control requires two (2) 1.5V AA Alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

Note: *Ensure batteries are inserted with correct polarity to prevent damage to the remote control.*

2. Initial Use

No programming is required for this replacement remote control. Once batteries are installed, it is ready for immediate use with compatible Epson projectors.




LAN
1
2
3
4
5
6
7
8
9
Auto
Num
0/All
ID
Menu
Esc
User
Default
Color Mode
E-Zoom
Volume
Aspect
A/V Mute
Split
Freeze
Home
Projector

Image 1: Front view of the ZdalaMit 219863500 replacement remote control, showing all buttons and their labels. This image illustrates the overall layout and design of the remote.

Operating Instructions

This section details the functions of the buttons on your ZdalaMit 219863500 remote control.

Button	Function
Power ( )	Turns the projector on or off.
HDMI, Computer, USB, LAN	Selects the corresponding input source for the projector.
Source Search	Initiates an automatic search for active input sources.
1-9, Num, Auto 0/All, ID	Numeric input and specific functions depending on projector model (e.g., selecting channels, auto-adjustment, or projector ID).
Menu	Opens the projector's on-screen menu.
Navigation Arrows (▲, ▼, ◄, ►)	Navigates through menu options and adjusts settings.
Enter (↵)	Confirms selections in the menu.
Esc	Exits the current menu or cancels an operation.
User	Activates a user-defined function (if configured on the projector).
Default	Resets certain settings to their factory defaults.
Color Mode	Cycles through available color modes (e.g., Dynamic, Cinema, Presentation).
E-Zoom (+/-)	Digitally zooms in or out on the projected image.
Volume (+/-)	Adjusts the audio output volume.
Aspect	Changes the aspect ratio of the projected image.
A/V Mute	Temporarily mutes audio and blanks the video output.
Split	Activates the split-screen function (if supported by the projector).
Freeze	Pauses the current projected image.
Home (⌂)	Returns to the projector's home screen or main menu.
Projector	A dedicated button for projector-specific functions, often used to switch between multiple projectors or control specific projector settings.


HDMI
Computer
Source Search
USB
LAN
1
2
3
4
5
6
7
8
9
Num
Auto
0/All
Menu
ID
Esc
User
Color Mode
Default
E-Zoom
Volume
Aspect
A/V Mute
Split
Freeze
Home
Projector

Image 2: Angled view of the ZdalaMit 219863500 remote control, highlighting the ergonomic design and button placement for ease of use.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new 1.5V AA Alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or solvents, as these can damage the remote's finish or internal components.

Troubleshooting

- **Remote not responding:**
  - Ensure batteries are correctly installed with the proper polarity.
  - Replace old batteries with new 1.5V AA Alkaline batteries.
  - Check for any obstructions between the remote and the projector's IR receiver.
  - Ensure you are within the effective operating range of the projector.
- **Intermittent functionality:**
  - This may indicate low battery power. Replace batteries.
  - Ensure a clear line of sight to the projector.





Image 3: Side view of the ZdalaMit 219863500 remote control, illustrating its slim profile and button depth.

Specifications

- **Model:** 219863500
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AA Alkaline Batteries
- **Product Dimensions:** 5.76 x 1.99 x 0.55 inches
- **Item Weight:** 2 ounces
- **Compatible Devices:** Various Epson Projector Models (e.g., EX3280, EX5280, EX9230, VS260, EB-992F, EB-982W, EB-972, EB-118, EB-W49, EB-X49, EB-E20, EB-FH52, EB-W52, EB-W51, EB-X51, EB-E10, EB-FH06, EB-W06, EB-X06, EB-E01, EB-X500, EB-E500, EB-1485Fi, EB-1480Fi, EB-1481Fi, EB-735Fi, EB-750F, EB-755F, EB-735F, EB-725Wi, EB-725W, EB-720, EB-L200F, EB-L200W, EB-L200X, V11H994020, EH-TW750, EH-TW740, EH-TW710, Pro EX7280, Pro EX9240, Powerlite EB-L200SW, Powerlite EB-L200SX)

Warranty and Support

For any queries or assistance regarding your ZdalaMit 219863500 replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific warranty information and contact details.

We are committed to providing support for our products.

© 2023 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B7W71QQN

More documents and user manuals: **https://manuals.plus/**