ZdalaMit RC2443802/01

RC2443802/01 Replacement Remote Control User Manual

Brand: ZdalaMit | **Model:** RC2443802/01

Introduction

This manual provides instructions for the ZdalaMit RC2443802/01 Replacement Remote Control, designed for various Sharp TV models. This remote control is a direct replacement and requires no programming for immediate use.

Compatible Sharp TV Models:

- LC-42SB48UT
- LC-32SB28
- LC-32SB28UT
- LC-32SB28UT-A
- LC-42SB48
- LC-42SB48UT-A
- LC-42SB45U
- LC-47SB57UT
- LC42SB48UT
- LC32SB28
- LC32SB28UT
- LC32SB28UTA
- LC42SB48
- LC42SB48UTA
- LC42SB45U
- LC47SB57UT

Setup

To begin using your new replacement remote control, follow these simple steps:

1. **Unpack the Remote:** Carefully remove the remote control from its packaging.
2. **Install Batteries:** Locate the battery compartment on the back of the remote control. Insert two (2) 1.5V AAA alkaline batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
3. **Ready for Use:** The remote control is pre-programmed and ready for immediate use with compatible Sharp TV models. No additional programming or setup is required.





Image: Front view of the RC2443802/01 Replacement Remote Control. This image shows the full layout of the buttons, including the power button, number pad, navigation controls, and function buttons.

Operating Instructions

This section details the primary functions of the buttons on your replacement remote control.



Image: Angled view of the RC2443802/01 Replacement Remote Control. This perspective highlights the ergonomic design and button placement from a side angle.

Remote Control Button Functions

Button Name	Function
Power (Red Button)	Turns the TV on or off.
SOURCE	Selects input source (e.g., HDMI, AV, Component).
MUTE	Mutes or unmutes the TV audio.
Number Pad (0-9)	Direct channel selection.
DISPLAY	Displays on-screen information (e.g., channel number, time).
MENU/EXIT	Accesses the TV menu or exits current menu/screen.
VOL +/-	Adjusts the volume level up or down.
CH +/-	Changes the channel up or down.
Navigation Pad (Up, Down, Left, Right, OK/Enter)	Navigates through menus and confirms selections.
FAV	Accesses favorite channels.
ADD FAV	Adds current channel to favorites.
CC	Activates or deactivates Closed Captions.
WIDE	Adjusts screen aspect ratio.
MTS/SAP	Selects Multi-channel Television Sound/Secondary Audio Program.
AUDIO ADJ	Adjusts audio settings.
VIDEO ADJ	Adjusts video settings.
SLEEP	Sets the sleep timer.
TV	Switches to TV input mode.
COMP VIDEO	Switches to Component Video input.
HDMI/PC	Switches to HDMI or PC input.

Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to clean the surface of the remote. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new 1.5V AAA alkaline batteries.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

Troubleshooting

If you encounter issues with your remote control, refer to the following common problems and solutions:

Problem	Solution
Remote is not responding.	◦ Check if the batteries are inserted correctly with the correct polarity. ◦ Replace old batteries with new 1.5V AAA alkaline batteries. ◦ Ensure there are no obstructions between the remote control and the TV's infrared sensor. ◦ Confirm the remote is pointed directly at the TV's sensor.
Some buttons are not working.	◦ Clean the remote control buttons and surrounding areas with a soft, dry cloth to remove any debris. ◦ Replace batteries, as low power can sometimes cause intermittent button functionality.
Remote works intermittently.	◦ This often indicates low battery power. Replace the batteries. ◦ Ensure the TV's infrared sensor is not blocked or dirty.

Specifications

Feature	Detail
Model Number	RC2443802/01
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	5 x 1.5 x 0.5 inches
Item Weight	2 ounces
Color	Black
Special Feature	Pre-Programmed (No setup required)
Compatible Devices	Sharp Televisions (Specific models listed in Introduction)

Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the seller or retailer from whom the product was purchased. Typically, replacement parts may come with a limited warranty against manufacturing defects.
For any queries or assistance, please contact the seller directly. The product description states:*"Please feel free to contact us if you have any query, thanks!"*
You can often find seller contact information on the platform where you made your purchase (e.g., Amazon

seller page).

© 2023 ZdalaMit. All rights reserved.

Note: This manual is for informational purposes only. Product specifications and appearance may change without notice.