Buture Pro VC50

BuTure VC50 Cordless Vacuum Cleaner User Manual

Model: VC50 | Brand: Buture Pro

1. Introduction

Thank you for choosing the BuTure VC50 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read this manual thoroughly before first use and keep it for future reference.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Read all instructions before using this appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.

- Do not pick up toxic material, such as chlorine bleach, ammonia, or drain cleaner.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not charge the unit outdoors.
- Use only the charger specified by the manufacturer.
- Store the appliance indoors after use to prevent damage.

3. Package Contents

Please check the package contents upon opening to ensure all parts are present and undamaged. If any items are missing or damaged, please contact customer support.



Image: The BuTure VC50 vacuum cleaner disassembled, showing the main unit, extension wand, floor brush, various cleaning tools, wall mount, and spare filters.

- Main Vacuum Unit (with dustbin and motor)
- Extension Wand
- Motorized Floor Brush
- 2-in-1 Brush Tool
- Long Crevice Tool

- Wall Mount Bracket
- Power Adapter/Charger
- Spare HEPA Filter
- Spare Sponge Filter

4. Product Overview

Familiarize yourself with the main components and features of your BuTure VC50 vacuum cleaner.

4.1. LED Display



Image: A detailed view of the vacuum's LED display, indicating AUTO mode, MANUAL mode, battery level, and blockage alerts.

The intuitive LED display provides real-time status updates:

- **AUTO Mode Indicator (A):** Shows when the vacuum is operating in automatic suction adjustment mode.
- **MANUAL Mode Indicator (M):** Shows when the vacuum is operating in manual suction mode.
- **Battery Indicator:** Displays the current battery charge level.
- **Blockage Indicator:** Alerts you if there is a blockage in the vacuum's airflow path.

- **Suction Power Indicator:** Shows the current suction power level.

4.2. High-Efficiency Filtration System



Image: An exploded view diagram illustrating the multi-stage filtration system, including cyclonic filtration, stainless steel mesh filtration, air inlet sponge filtration, and HEPA filtration.

The BuTure VC50 features a multi-stage filtration system designed to capture fine dust and allergens, ensuring cleaner air output. This includes:

- Cyclonic Filtration
- Stainless Steel Mesh Filtration
- Air Inlet Sponge Filtration
- HEPA Filtration

5. Setup and Initial Use

5.1. Assembly

Follow these steps to assemble your vacuum cleaner:

1. Insert the extension wand into the main vacuum unit until it clicks securely into place.
2. Attach the motorized floor brush to the other end of the extension wand, ensuring it clicks firmly.
3. For handheld use, attach desired accessories (2-in-1 brush tool or crevice tool) directly to the main vacuum unit.



Image: The main vacuum unit, extension wand, and floor brush, illustrating how they connect to form the complete vacuum.

5.2. Charging the Battery

Before first use, fully charge the battery. The battery can be charged while attached to the vacuum on the wall mount, or separately.



Image: The BuTure VC50 vacuum cleaner docked on its wall mount, connected to the power adapter for charging. This image highlights the 2-in-1 charging and storage solution.

- **Charging on Wall Mount:** Install the wall mount in a convenient location near a power outlet. Hang the vacuum cleaner on the mount and connect the power adapter to the charging port on the mount.
- **Separate Battery Charging:** The battery pack is removable. You can detach the battery from the main unit and charge it directly using the power adapter.
- The LED display will show the charging status. A full charge typically takes approximately 4 hours.
- The battery provides up to 55 minutes of runtime on a full charge, depending on the operating mode.



Image: The BuTure VC50 vacuum cleaner shown charging on its wall mount, alongside a separate battery pack being charged independently. This illustrates the flexibility of charging options.

6. Operating Instructions

6.1. Power On/Off and Mode Selection

To turn on the vacuum, press the power button. The vacuum will start in the last used mode or default to AUTO mode. Use the mode selection button on the LED display to switch between modes.



Image: A hand interacting with the BuTure VC50's LED display, highlighting the AUTO and MANUAL mode selection buttons and indicators for battery and blockage.

- **AUTO Mode:** In this intelligent mode, the vacuum automatically adjusts suction power based on the detected dust level and floor type (e.g., carpet or hard floor). This optimizes cleaning efficiency and battery life.
- **MANUAL Mode:** Allows you to manually select the desired suction power level for specific cleaning tasks.



Image: A visual representation of the intelligent automatic suction mode, showing the vacuum adjusting its power when transitioning from a hard floor to a carpet.

6.2. Using the Vacuum

The BuTure VC50 is versatile and can be used for various cleaning scenarios:



Image: A woman operating the BuTure VC50 cordless vacuum cleaner on a hard kitchen floor, demonstrating its powerful 33Kpa suction.

- **Floor Cleaning:** Use the motorized floor brush for effective cleaning on both hard floors and carpets.
- **Handheld Cleaning:** Detach the extension wand and attach the 2-in-1 brush tool or crevice tool directly to the main unit for cleaning furniture, car interiors, stairs, or tight spaces.



Image: A collage showcasing the versatility of the BuTure VC50, demonstrating its use as a full-size stick vacuum, a handheld vacuum with a brush attachment for surfaces, a handheld with a crevice tool for tight spots, and for cleaning stairs.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

7.1. Emptying the Dustbin

Empty the dustbin regularly, ideally after each use, to maintain strong suction power.

1. Press the dustbin release button to detach it from the main unit.
2. Hold the dustbin over a trash can and press the bottom release latch to open the dustbin flap and empty contents.
3. Close the flap and reattach the dustbin to the main unit until it clicks.

7.2. Cleaning the Filters

The filters should be cleaned regularly, approximately once a month, or more frequently with heavy use. Ensure filters are completely dry before reinstallation.



Image: An exploded view diagram showing the various filter components of the BuTure VC50, including the HEPA filter, sponge filter, and stainless steel mesh filter.

1. Remove the dustbin.
2. Twist and pull out the filter assembly (HEPA filter, sponge filter, and stainless steel mesh filter).
3. Tap off loose dust from the filters. You can rinse the sponge filter and stainless steel mesh filter under running water. Do NOT wash the HEPA filter with water; tap it clean.
4. Allow all washable parts to air dry completely for at least 24 hours before reassembling.

5. Reassemble the filters and place them back into the dustbin, then reattach the dustbin to the main unit.



Image: A set of spare HEPA and sponge filters, indicating the replaceable filter components of the vacuum cleaner.

7.3. Cleaning the Brush Roll

Periodically check the brush roll for tangled hair or debris and clean as needed.

1. Turn off the vacuum and detach the floor brush.
2. Locate the brush roll release latch on the side of the floor brush and open it.
3. Remove the brush roll. Use scissors to cut away any tangled hair or threads.
4. Clean any debris from the brush roll housing.
5. Reinsert the brush roll and secure the release latch.



Image: A close-up of the motorized floor brush's roller, which can be removed for cleaning.

8. Troubleshooting

If you encounter issues with your BuTure VC50, please refer to the table below for common problems and solutions. If the problem persists, contact customer support.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is not charged. Battery is not properly installed.	Charge the battery fully. Ensure the battery pack is securely clicked into place.
Weak suction power.	Dustbin is full. Filters are clogged. Airflow path is blocked.	Empty the dustbin. Clean or replace the filters. Check the extension wand, floor brush, and main unit for blockages.
Brush roll not spinning.	Brush roll is tangled with hair/debris. Floor brush is not properly attached.	Clean the brush roll. Reattach the floor brush securely.
Vacuum makes unusual noise.	Blockage in the airflow path. Filters are not properly installed.	Check for and remove any blockages. Ensure all filters are correctly seated.
Battery runtime is short.	Battery not fully charged. Operating in high power mode constantly. Battery life degrading over time.	Ensure battery is fully charged. Use AUTO mode or lower power settings when possible. Contact customer support for battery replacement options if battery life significantly decreases.

9. Specifications

Technical specifications for the BuTure VC50 Cordless Vacuum Cleaner:

Feature	Detail
Brand	Buture Pro
Model Number	VC50
Color	Blue
Dimensions (Package)	44.1 x 35.6 x 19.9 cm
Capacity (Dustbin)	1.2 Liters
Power	400 Watts
Item Weight	4.3 Kilograms
Battery Type	1 Lithium-ion (included)

Feature	Detail
Runtime	Up to 55 minutes
Charge Time	Approx. 4 hours
Surface Recommendation	Carpet, Hard Floors
Power Source	Battery Powered
Cordless	Yes
Form Factor	Stick

10. Warranty and Customer Support

BuTure products are manufactured to the highest quality standards. For information regarding your product's warranty, please refer to the warranty card included with your purchase or visit the official BuTure website.
If you have any questions, require technical assistance, or encounter issues not covered in this manual, please contact BuTure customer support. Please have your model number (VC50) and purchase information ready when contacting support.

Contact Information:

Website: www.buture.com (*Please check the official website for the most up-to-date contact methods.*)

Email: support@buture.com

© 2023 Buture Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question