Technology Parts Store 532125907

Technology Parts Store Ground Drive Belt 532125907 Instruction Manual

Compatible with Craftsman Tractor Model 917.289220

1. Introduction

This manual provides essential instructions for the proper installation, operation, and maintenance of your Technology Parts Store Ground Drive Belt, model 532125907. This belt is designed for use with Craftsman Tractor Model 917.289220. Please read this manual thoroughly before attempting any installation or maintenance procedures to ensure safe and effective use of the product.

2. Safety Information

Always prioritize safety when working with machinery. Failure to follow safety precautions can result in serious injury or damage to equipment.

- **Wear Protective Gear:** Always wear work gloves to protect your hands during installation and maintenance. Safety glasses are also recommended.
- **Disconnect Power:** Before beginning any work on the tractor, ensure the engine is off, the ignition key is removed, and the spark plug wire is disconnected to prevent accidental starting.
- **Secure Equipment:** If lifting the tractor, ensure it is securely supported on jack stands or ramps to prevent it from falling.
- **Read Tractor Manual:** Refer to your Craftsman tractor's original owner's manual for specific safety procedures and belt replacement instructions pertinent to your model.
- **Proper Tools:** Use appropriate tools for the job to avoid damage to components or injury.

3. Product Overview

The ground drive belt is a critical component that transmits power from the engine to the transmission, enabling the tractor to move. This replacement belt is a classic V-belt style, measuring 1/2 inch in width and 90 inches in length (A88 4L900).



Figure 3.1: The Technology Parts Store Ground Drive Belt 532125907.

This belt is designed as a compatible replacement for Craftsman OEM part number 532125907 (also known as 125907) and is specifically compatible with Craftsman Tractor Model 917.289220. It is an aftermarket product, not an OEM belt, but is manufactured to meet the necessary specifications for proper function.

3.1 Belt Construction

Understanding the belt's construction helps in appreciating its function and durability. A typical V-belt consists of a top rubberized fabric cover, tensile cords, and a natural rubber body.

Top Rubberized Fabric Cover: Envelopes the entire belt, providing protection against heat, oil, abrasion, and erosion.

Cords (Tensile Member): The load-carrying section, providing strength and ensuring uniform load distribution. A buffer layer around the cords absorbs impact during operation.

Natural Rubber Body (Compression Section): Resists compression fatigue, dissipates internal heat, and provides firm lateral pressure against the pulley sidewall. This compound offers excellent physical and mechanical properties, oil and heat resistance, and maintains flexibility in a wide temperature range (-50°C/-58°F to +90°C/194°F).




Figure 3.2: Detailed diagram illustrating the internal components and construction of a V-belt.

4. Installation

Replacing the ground drive belt requires careful attention to detail. Always follow the safety guidelines outlined in Section 2 before proceeding.

1. **Prepare the Tractor:** Park the tractor on a flat, level surface. Engage the parking brake. Turn off the engine, remove the ignition key, and disconnect the spark plug wire.
2. **Access the Belt:** Depending on your specific Craftsman model, you may need to remove the mower deck or other covers to gain access to the ground drive belt system. Refer to your tractor's owner's manual for precise access instructions.
3. **Document Belt Routing:** Before removing the old belt, carefully observe and diagram its routing around all pulleys, idlers, and tensioners. Taking photos can be very helpful for reassembly.
4. **Relieve Tension:** Locate the belt tensioner pulley (often spring-loaded) and relieve the tension to allow the old belt to be removed.
5. **Remove Old Belt:** Carefully remove the old, worn, or broken ground drive belt from all pulleys.
6. **Install New Belt:** Route the new Technology Parts Store Ground Drive Belt 532125907 according to your documented diagram. Ensure the belt is seated correctly in all pulley grooves.
7. **Apply Tension:** Re-engage the belt tensioner, ensuring the belt is taut but not overly tight. The tension should be sufficient to prevent slippage without causing excessive wear on the belt or bearings.
8. **Verify Routing:** Double-check that the new belt is correctly routed and seated on all pulleys. Incorrect routing is a common cause of premature belt failure.
9. **Reassemble:** Reinstall any covers or the mower deck that were removed.
10. **Test Operation:** Reconnect the spark plug wire. Start the tractor and slowly engage the drive system to ensure the belt operates smoothly without slipping or unusual noises.




Figure 4.1: Example diagram illustrating pulley and tensioner components, useful for understanding belt routing and adjustment.

5. Maintenance

Regular inspection and proper maintenance will extend the life of your ground drive belt and ensure optimal tractor performance.

- **Regular Inspection:** Periodically inspect the belt for signs of wear, cracking, fraying, glazing, or damage. Replace the belt if any significant wear is observed.
- **Cleanliness:** Keep the belt and pulleys free from dirt, debris, oil, and grease. Contaminants can cause the belt to slip or wear prematurely.
- **Proper Tension:** Ensure the belt maintains proper tension. A belt that is too loose will slip, causing wear and inefficient power transfer. A belt that is too tight can put excessive strain on bearings and the belt itself.
- **Pulley Condition:** Inspect pulleys for wear, damage, or misalignment. Worn or damaged pulleys can quickly destroy a new belt.
- **Storage:** If the tractor is stored for an extended period, ensure the belt is not under extreme tension or exposed to harsh environmental conditions.

6. Troubleshooting

If you experience issues with your ground drive system, consider the following common troubleshooting steps:

Symptom	Possible Cause	Solution
Tractor not moving or moving slowly	Loose or worn belt, incorrect belt routing, damaged pulleys.	Inspect belt tension and condition. Verify correct belt routing. Check pulleys for damage. Replace belt if worn.
Squealing noise from belt area	Belt slippage due to low tension, glazed belt, or contamination (oil/grease).	Adjust belt tension. Clean belt and pulleys. Replace belt if glazed or contaminated.
Belt breaking prematurely	Incorrect belt tension (too tight), misaligned pulleys, worn pulleys, foreign objects.	Ensure correct tension. Check pulley alignment and condition. Remove any debris.
Vibration or rough operation	Damaged belt, unbalanced pulleys, incorrect installation.	Inspect belt for damage. Check pulleys for balance and proper seating. Re-verify installation steps.

7. Specifications

Feature	Detail

Feature	Detail
Product Name	Ground Drive Belt
Brand	Technology Parts Store
Model Number (TPS)	TPS00030612
Compatible OEM Part No.	Craftsman 532125907 (125907)
Compatible Tractor Model	Craftsman 917.289220
Belt Style	Classic V-belt (A88 4L900)
Dimensions (Length x Width)	90 inches x 0.5 inches (1/2")
Item Weight	8.8 ounces
Color	Black
Manufacturer	Aftermarket
Unit Count	1 Count

8. Warranty and Support

For specific warranty information regarding this product, please refer to the purchase documentation or contact the seller directly. If you require further assistance with installation, troubleshooting, or have questions about your Technology Parts Store Ground Drive Belt, please reach out to the retailer or manufacturer's customer support channels.
You can often find contact information on the product packaging or the seller's storefront page on the platform where the purchase was made.

© 2023 Technology Parts Store. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question