Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BCXY CS-FE110SL

Instruction Manual for BCXY Battery Replacement

Model: CS-FE110SL

1. Introduction

This manual provides essential information for the safe and effective use of your BCXY replacement battery, model CS-FE110SL. This battery is designed for compatibility with Musicman MA Soundstation and Musicman BT-X1 devices. Please read this manual thoroughly before installation and use to ensure optimal performance and safety.



Image 1: Front view of the BCXY replacement battery.

2. Safety Information and Precautions

Your safety is paramount. Please observe the following warnings and precautions to prevent injury or damage to the battery and device.

- **DO NOT** attempt to disassemble, open, or service the battery pack.
- **DO NOT** crush, puncture, short external contacts, or dispose of in fire or water.
- **DO NOT** store above 60°C (140°F).
- Replace only with the battery pack designated for this product.
- New battery pack must be fully charged before use.
- Read instructions in operating guide before using the battery.
- Warranty void if label is removed.



Image 2: Rear view of the battery showing safety warnings and serial number.

3. Setup and Installation

Before installing the new battery, ensure your device is powered off and disconnected from any power source. Refer to your device's original instruction manual for specific battery compartment access and removal procedures.

1. Locate the battery compartment on your Musicman MA Soundstation or Musicman BT-X1 device.
2. Carefully open the compartment, following your device's instructions.
3. Remove the old battery. Dispose of the old battery responsibly according to local regulations.
4. Align the new BCXY battery (Model: CS-FE110SL) with the battery contacts in the compartment. Ensure correct polarity.
5. Gently press the battery into place until it is securely seated.

6. Close the battery compartment cover.
7. It is recommended to fully charge the new battery before its first use.



Image 3: Angled view of the battery, highlighting the contact points for proper installation.

4. Operation

This Lithium-ion battery is designed for reliable power delivery. For optimal performance, follow these guidelines:

4.1 Charging

- Use only the original charger or a certified compatible charger provided with your Musicman device.
- Connect your device to a power source. The device's indicator light will typically show charging status.
- Allow the battery to fully charge before disconnecting, especially for the first few cycles.
- Avoid overcharging; modern devices and batteries have built-in protection, but prolonged connection after full charge is not recommended.

4.2 Discharging

- The battery will discharge during normal use of your Musicman device.
- It is generally not necessary to fully discharge Lithium-ion batteries before recharging.
- Avoid deep discharge (letting the battery completely drain to 0%) frequently, as this can reduce overall battery lifespan.

5. Maintenance and Storage

Proper care and maintenance will extend the life of your battery.

- **Temperature:** Store the battery in a cool, dry place, away from direct sunlight and extreme temperatures. Ideal storage temperature is between 0°C and 25°C (32°F and 77°F).
- **Charge Level for Storage:** If storing the battery for an extended period, charge it to approximately 50-60% capacity. Do not store a fully charged or completely depleted battery for long periods.
- **Cleaning:** Keep battery contacts clean. Use a dry, soft cloth to wipe them if necessary.
- **Avoid Physical Damage:** Protect the battery from drops, impacts, and crushing.

6. Troubleshooting

If you encounter issues with your battery, consider the following common solutions:

Problem	Possible Cause	Solution
Battery not charging	Incorrect installation, faulty charger, dirty contacts, or battery issue.	Ensure battery is correctly seated. Check charger and cable. Clean battery and device contacts. If problem persists, contact support.
Short battery life	Normal wear, high power consumption, or improper charging habits.	Ensure full charges. Reduce device usage that consumes high power. Consider battery age.
Device not powering on	Battery not charged, incorrect installation, or device issue.	Charge battery fully. Re-install battery. Test device with another known good battery if possible.

7. Specifications

Detailed technical specifications for the BCXY CS-FE110SL battery:

Attribute	Value
Model Number	CS-FE110SL
Compatible Models	Musicman MA Soundstation, Musicman BT-X1
Battery Type	Lithium-ion
Voltage	3.7V
Capacity	1000mAh
Watt-Hours (Wh)	3.7Wh
Dimensions (L x W x H)	46.2 x 34.14 x 5.68mm (1.82 x 1.34 x 0.22 inches)
Weight	42.5g (1.5 ounces)
Certifications	ISO9001, RoHS, CE, UN38.3, MSDS



Image 4: Close-up of the battery label displaying model number, capacity, and voltage.

8. Warranty and Support

BCXY batteries are manufactured to strict quality standards and are certified with ISO9001, RoHS, CE, UN38.3, and MSDS, ensuring a safe and durable product. Our batteries are designed with overcharge, over discharge, over voltage, and short circuit protection for enhanced battery life and safety.

For any questions, concerns, or professional suggestions regarding your battery, please contact BCXY customer support. When contacting support, please provide your battery details or pictures to assist in a quicker resolution.

For more information or to explore other products, visit the official BCXY store on Amazon:BCXY Store

© 2024 BCXY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B87GRH9G

More documents and user manuals: **https://manuals.plus/**