Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ONN 100068372

ONN 42-Inch Class Full HD (1080p) LED Smart TV

Model: 100068372
Brand: ONN

Introduction

This manual provides essential information for setting up, operating, and maintaining your ONN 42-Inch Class Full HD (1080p) LED Smart TV. This television integrates Roku TV, offering a wide range of streaming services and smart features. Please read this manual thoroughly before using your TV to ensure proper operation and to maximize your viewing experience.

What's in the Box

Carefully unpack all items from the box. Ensure you have all the components listed below. If any items are missing or damaged, please contact customer support.

- ONN 42-Inch Class Full HD (1080p) LED Smart TV
- Wall Mount Bracket (Note: Traditional TV stands are not included with this model.)
- Remote Control
- Power Cable
- Quick Start Guide (not included in this manual)



Image: ONN Roku TV and included wall mount bracket.

Setup

Mounting the TV

This TV is designed for wall mounting and includes a wall mount bracket. The rear panel of the TV features standard VESA mount screw holes for easy installation. Ensure you use appropriate wall anchors and follow the instructions provided with the wall mount for secure installation. Traditional stands are not included with this model.



Image: Rear view of the ONN Roku TV showing VESA mounting holes for wall mounting.

Connecting Power

Plug the power cable into the TV's power input, then plug the other end into a standard electrical outlet. The TV will enter standby mode.

Initial Setup (Roku TV)

Upon first power-on, the TV will guide you through the Roku TV setup process. This includes:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your home Wi-Fi network.
3. **Roku Account Setup:** Create a new Roku account or sign in to an existing one. This is required to access streaming channels.
4. **Channel Installation:** Select and install your desired streaming channels (e.g., Netflix, Disney+, Apple TV, HBO).
5. **Input Naming:** The TV can automatically detect and name connected HDMI devices (e.g., Nintendo Switch, Xbox). You can also manually rename inputs.

Operating Instructions

Using the Remote Control

The included remote control provides full functionality for navigating the Roku TV interface, controlling playback, and accessing settings.



Image: Roku TV remote control.

Accessing Streaming Services

From the Roku TV home screen, you can easily access pre-installed or added streaming channels such as Netflix, Disney+, Apple TV, HBO, Hulu, Prime Video, Tubi, Pluto TV, YouTube, and more. Navigate using the remote's directional pad and select the desired app.



Image: Front view of the ONN Roku TV displaying various streaming service logos.

Input Management

The Roku TV system intelligently identifies connected devices via HDMI. You can switch between inputs (e.g., Nintendo Switch, HDMI 2, HDMI 3 (ARC), AV, Live TV) directly from the home screen. The TV will automatically label inputs based on detected devices.

Voice Assistant Support

This TV supports multiple voice assistants, including Siri, Alexa, and Google Assistant. Use compatible voice-enabled devices to control your TV, play movies, TV shows, and more.

Maintenance

Cleaning the Screen

To clean the LED screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a screen-specific cleaning solution. Avoid using harsh chemicals or abrasive materials.

General Care

- Keep the TV in a well-ventilated area to prevent overheating.
- Avoid exposing the TV to direct sunlight or extreme temperatures.
- Do not place heavy objects on top of the TV.
- Unplug the TV during lightning storms or when unused for extended periods.

Troubleshooting

If you encounter issues with your TV, refer to the following common solutions:

- **No Power:** Ensure the power cable is securely connected to both the TV and the electrical outlet. Try a different outlet.
- **No Picture/Sound:** Verify that the correct input source is selected. Check all cable connections (HDMI, AV).
- **Remote Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
- **Network Connection Issues:** Restart your Wi-Fi router. Re-enter your Wi-Fi password in the TV's network settings.
- **App Not Loading:** Check your internet connection. Try restarting the TV. If the issue persists, try removing and re-adding the app.

For more complex issues, consult the Roku TV online support or contact ONN customer service.

Specifications

Feature	Specification
Brand	ONN
Model Name	ONN 42 inch (Model 100068372)
Screen Size	42 Inches (107 cm visible diagonal)
Display Technology	LED
Resolution	1080p (Full HD)
Aspect Ratio	16:9
Product Dimensions	37.4 x 8.7 x 23.5 inches

Connectivity Technology	USB, HDMI (3 ports, including ARC)
Supported Internet Services	Pandora, Hulu Plus, Amazon Instant Video, Netflix, YouTube, Disney+, Apple TV, HBO, and more via Roku TV
Special Feature	Flat Screen, Smart TV functionality, Voice Assistant Support (Siri, Alexa, Google Assistant)
Included Components	TV, Wall Mount (Note: Stands are not included)



Image: Energy Guide label for ONN TV Model 100068372.

Warranty and Support

This product is part of the Amazon Renewed program, meaning it has been professionally inspected and tested to work and look like new. Renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee if you are not satisfied with your purchase.
For technical support, troubleshooting assistance, or warranty claims, please refer to the Amazon Renewed Guarantee details or contact Amazon customer service directly. For general Roku TV support, visit the official Roku support website.

© 2023 ONN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B8FZP8F3

More documents and user manuals: **https://manuals.plus/**