ONN 100012589

Onn 32-Inch Class HD LED Smart TV Instruction Manual

Model: 100012589 | Brand: ONN

Introduction

This manual provides essential information for setting up, operating, and maintaining your Onn 32-Inch Class HD LED Smart TV. Featuring 720p resolution, a DLED display, and wireless streaming capabilities, this smart TV offers a comprehensive entertainment experience.

Important Safety Instructions

Always read and follow all safety instructions before using your television. Keep this manual for future reference.

- **Warning:** Do not expose this appliance to rain or moisture.
- **Caution:** To prevent electric shock, do not remove cover. No user-serviceable parts inside. Refer servicing to qualified service personnel.
- Ensure proper ventilation. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent tipping.
- Keep the TV away from heat sources and direct sunlight.
- Unplug the TV during lightning storms or when unused for long periods.

What's in the Box

Verify that all components are present:

- Onn 32-Inch HD LED Smart TV
- Remote Control
- Power Cable
- TV Stands (if not wall-mounted)



Figure 1: Onn 32-Inch HD LED Smart TV with its intuitive Roku interface.

Setup Guide

1. Attaching the TV Stands (Optional)

If you are not wall-mounting your TV, attach the included stands:

1. Carefully place the TV face down on a soft, clean surface to prevent screen damage.
2. Align each stand with the corresponding screw holes on the bottom of the TV.
3. Secure the stands using the provided screws. Do not overtighten.



Figure 2: Rear view of the TV illustrating stand attachment.

2. Connecting Devices

Your Onn Smart TV offers multiple connectivity options:

- **HDMI:** Connect up to three HDMI devices (e.g., gaming consoles, Blu-ray players) to the HDMI 1, HDMI 2, or HDMI 3 ports.
- **Composite:** Use the Composite input for older devices.
- **USB:** Plug in a USB drive to view media files.
- **Optical:** Connect to a soundbar or audio receiver for enhanced sound.
- **Coaxial/Cable:** Connect an antenna or cable TV input.
- **Headphone:** For private listening.



Figure 3: Available input ports on the side of the TV.

3. Initial Power On

After connecting all desired devices, plug the power cable into an electrical outlet. The TV will guide you through the initial setup process, including network connection and Roku account setup.

Operating Your Onn Roku TV

Remote Control

The included remote control provides easy navigation of the Roku TV interface. It features dedicated buttons for popular streaming services.



Figure 4: Onn Roku TV Remote Control.

Navigating the Interface

The Roku TV Home screen provides quick access to your installed apps, inputs, and recommended content. Use the directional pad on your remote to navigate and the OK button to select.

Streaming Services

Your Onn Smart TV comes with pre-installed access to popular streaming services like Netflix and YouTube. You can add more apps from the Roku Channel Store.

Voice Assistants

This TV is compatible with Alexa and Google Assistant, allowing you to control your TV with voice commands for playing movies, TV shows, and more.

Maintenance

Cleaning Your TV

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, dampen the cloth with a small amount of screen cleaner. Do not spray cleaner directly onto the screen.
For the TV casing, use a soft, dry cloth. Avoid abrasive cleaners or solvents.

Software Updates

Your Roku TV will automatically check for and install software updates when connected to the internet. Ensure your TV is connected to a stable network for optimal performance and security.

Troubleshooting

Problem	Possible Solution
No Power	Check if the power cable is securely plugged into the TV and the electrical outlet. Test the outlet with another device.

No Picture/Sound	Ensure the correct input source is selected. Check all cable connections (HDMI, Composite).
Remote Not Working	Replace the batteries (requires AAA). Ensure no obstructions between the remote and the TV's IR sensor.
Cannot Connect to Wi-Fi	Verify your Wi-Fi password. Restart your router and modem. Ensure the TV is within range of your Wi-Fi signal.

Product Specifications

Screen Size: 32 Inches

Display Technology: LED

Resolution: 720p (HD)

Refresh Rate: 60 Hz

Dimensions (D x W x H): 6"D x 22"W x 15"H

Item Weight: 10.13 pounds

Connectivity: 3 HDMI, 1 Composite, 1 USB, 1 Optical, 1 Coaxial/Cable, 1 Headphone

Voice Assistant Compatibility: Alexa, Google Assistant



Figure 5: TV dimensions.



Figure 6: Energy Guide for Model 100012589.

Warranty and Support

This Onn Smart TV is a renewed product. Please refer to the specific warranty information provided by Amazon Renewed at the time of purchase for details on coverage and duration. For technical support or service inquiries, please contact Amazon Renewed customer service or refer to the official ONN support channels.
For further assistance, visit the Amazon Renewed Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question