JVC UX-C25DAB

JVC UX-C25DAB Micro Hi-Fi System User Manual

Model: UX-C25DAB

Introduction

Thank you for purchasing the JVC UX-C25DAB Micro Hi-Fi System. This manual provides essential information for the safe and efficient operation of your new audio system. Please read it thoroughly before use and keep it for future reference.
The JVC UX-C25DAB is a versatile micro Hi-Fi system offering multiple audio sources including CD, USB, Bluetooth, DAB+, FM radio, and a Line-In connection. It features a powerful amplifier with 2 x 7W output and Bass Reflex speakers for enhanced sound quality.

Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury to persons.

- Do not expose this appliance to rain or moisture.
- Do not block any ventilation openings.
- Ensure proper ventilation around the unit.
- Do not place the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

What's in the Box

Verify that all components are present in the packaging:

- Main Unit (JVC UX-C25DAB)

- Speakers (x2)
- IR Remote Control with Battery
- FM/DAB Antenna
- Instruction Manual (this document)

Product Overview

The JVC UX-C25DAB system consists of a central main unit and two separate speakers. Familiarize yourself with the various parts and connections.



Front view of the JVC UX-C25DAB Micro Hi-Fi System, showing the central unit with display, control knob, CD tray, USB port, and Line-In jack, flanked by two black speakers.



Angled view of the JVC UX-C25DAB Micro Hi-Fi System, highlighting the compact design of the main unit and its accompanying speakers.

Main Unit Controls and Ports:

- **Power Button:** Turns the unit on/off.
- **Display:** Shows current mode, track information, radio frequency, etc.
- **Control Knob:** Adjusts volume, navigates menus.
- **CD Tray:** For inserting audio CDs.
- **USB Port:** For connecting USB storage devices for audio playback.
- **Line-In (AUX) Jack:** For connecting external audio devices via a 3.5mm cable.
- **Speaker Terminals:** Connects to the included speakers.
- **Antenna Input:** For connecting the FM/DAB antenna.



The infrared remote control for the JVC UX-C25DAB, featuring buttons for power, source selection, playback controls, volume, and EQ presets.

Setup

1. Placement

Place the main unit and speakers on a stable, flat surface. For optimal stereo sound, position the speakers equidistant from the listening position and spaced apart from the main unit.



Example of the JVC Micro Hi-Fi System placed on a shelf, demonstrating suitable placement for optimal sound and aesthetics.

2. Connecting Speakers

Connect the speaker wires from each speaker to the corresponding speaker terminals on the rear of the main unit. Ensure correct polarity (red to red, black to black) for proper sound reproduction.

3. Connecting the Antenna

Connect the supplied FM/DAB antenna to the antenna input on the rear of the main unit. Extend the antenna fully for best reception.

4. Power Connection

Plug the power cord into the AC inlet on the rear of the main unit, then plug the other end into a suitable wall outlet (AC 220V).

Operating Instructions

Power On/Off

Press the **Power** button on the front panel or the remote control to turn the unit on or off.

Source Selection

Press the **Source** button on the remote control or the main unit repeatedly to cycle through available input sources: CD, USB, Bluetooth, DAB+, FM, Line-In.

CD Playback

1. Select the "CD" source.
2. Press the **Open/Close** button to open the CD tray.
3. Place a CD with the label side up into the tray.
4. Press the **Open/Close** button again to close the tray. Playback will start automatically.
5. Use **Play/Pause**, **Stop**, **Skip Forward/Backward** buttons for control.

USB Playback

1. Insert a USB storage device into the USB port.
2. Select the "USB" source. The unit will automatically scan and begin playback of compatible audio files (WAV, MP3, AAC).
3. Use playback controls as with CD.

Bluetooth Pairing and Playback

1. Select the "Bluetooth" source. The display will show "PAIRING" or "BT PAIR".
2. On your Bluetooth device (e.g., smartphone), enable Bluetooth and search for "JVC UX-C25DAB".
3. Select "JVC UX-C25DAB" from the list to pair. Once connected, the display will show "CONNECTED".
4. Start playing audio on your Bluetooth device. The sound will be streamed to the Hi-Fi system.

DAB+ Radio Operation



The DAB+ logo, indicating support for Digital Audio Broadcasting Plus.

1. Select the "DAB+" source.
2. The unit will automatically perform a full scan for available DAB+ stations upon first use.
3. Use the **Tune +/-** buttons to navigate through the list of available stations.
4. To save a preset: Tune to the desired station, press and hold the **Preset** button, select a preset number using the **Tune +/-** buttons, and press **Enter** to confirm.

FM Radio Operation

1. Select the "FM" source.
2. Press and hold the **Scan** button to automatically scan and save available FM stations.
3. Alternatively, use the **Tune +/-** buttons for manual tuning.
4. To save a preset: Tune to the desired station, press and hold the **Preset** button, select a preset number using the **Tune +/-** buttons, and press **Enter** to confirm.

Line-In (AUX) Usage

1. Connect an external audio device (e.g., MP3 player, smartphone) to the Line-In jack on the front panel using a 3.5mm audio cable.
2. Select the "Line-In" or "AUX" source.
3. Control playback from your connected external device.

Equalizer Presets

The system includes 5 preset equalizer modes. Press the **EQ** button on the remote control to cycle through the available sound modes (e.g., Flat, Rock, Pop, Jazz, Classic) to suit your listening preference.

Maintenance

Cleaning the Unit

Wipe the unit with a soft, dry cloth. For stubborn stains, dampen the cloth with a mild detergent solution and wipe gently, then dry thoroughly. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

CD Lens Care

Avoid touching the CD lens. If the lens becomes dirty, use a commercially available CD lens cleaner.

Speaker Care

Keep speakers free from dust. Do not press on the speaker cones.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected securely.	Check power cord connection to the unit and wall outlet.
No sound	Volume is too low; Speakers not connected; Incorrect source selected.	Increase volume; Check speaker connections; Select correct input source.
CD/USB not playing	Disc/USB is dirty or damaged; Incorrect format.	Clean or replace disc/USB; Ensure files are in supported formats (MP3, WAV, AAC).
Poor radio reception	Antenna not extended or positioned correctly; Weak signal.	Extend and adjust antenna position; Try relocating the unit for better signal.
Bluetooth pairing fails	Bluetooth device too far; Unit not in pairing mode; Interference.	Move device closer; Ensure unit is in Bluetooth pairing mode; Turn off other Bluetooth devices.

Specifications

Feature	Description
Model Name	UX-C25DAB
Output Power	2 x 7 W
Supported Audio Formats	WAV, MP3, AAC (via USB/CD)
CD Compatibility	CD DA, CD-R/RW
Tuner	DAB+, FM RDS
Bluetooth	A2DP compatible
Connectivity	USB Port, Line-In (3.5mm)
Equalizer Presets	5 (Flat, Rock, Pop, Jazz, Classic)
Power Supply	AC 220V
Main Unit Dimensions (W x H x D)	180 x 120 x 250 mm (approx.)
Speaker Dimensions (W x H x D)	128 x 227 x 127 mm (approx.)
Weight	3.4 kg (approx.)
Included Components	Main unit, 2 speakers, IR remote control, FM/DAB antenna, instruction manual

Warranty and Support

JVC products are manufactured to the highest quality standards. For warranty information, please refer to the warranty card included with your product or contact your local JVC authorized dealer or service center. Keep your purchase receipt as proof of purchase.
For technical support or service inquiries, please visit the official JVC website or contact their customer service department in your region. Do not attempt to repair the unit yourself.

© 2024 JVC. All rights reserved.